

Installation/User Manual



- Make sure to read the cautions for safety before installation and use, and use it correctly.
- It is intended to keep protect the safety of the installer and user and to prevent the property damage, etc.
- After reading the user manual, please keep it at a place where user can access any time.

Model Name: BACnet Gateway (ACP BACnet) Model No.: PQNFB17C1, PQNFB17C0



P/NO : MFL67709501

www.lge.com

Explanatory Notes

Copyrights

The contents of this ACP BACnet User Guide are protected by international copyright laws, and the Computer Program Protection Act. The contents of the User Guide and the programs mentioned herein may only be used under license from LG Electronics in strict adherence to the user agreement.

You may not reproduce or distribute, by any means, copies of this User Guide, or any part of it, without prior approval from LG Electronics.

Copyright © 2013 LG Electronics. All rights reserved. Twin Towers 20, Yeouido, Yeongdeungpo-gu, Seoul

Registered Trademarks

ACP BACnet is a registered trademark of LG Electronics. All other products and company names are trademarks of their respective owners and are used for illustrative purposes only.

TIPS FOR SAVING ENERGY

Here are some tips that will help you minimize the power consumption when you use the air conditioner. You can use your air conditioner more efficiently by referring to the instructions below:

- Do not cool excessively indoors. This may be harmful for your health and may consume more electricity.
- · Block sunlight with blinds or curtains while you are operating the air conditioner.
- · Keep doors or windows closed tightly while you are operating the air conditioner.
- · Adjust the direction of the air flow vertically or horizontally to circulate indoor air.
- Speed up the fan to cool or warm indoor air quickly, in a short period of time.
- Open windows regularly for ventilation as the indoor air quality may deteriorate if the air conditioner is used for many hours.
- Clean the air filter once every 2 weeks. Dust and impurities collected in the air filter may block the air flow or weaken the cooling / dehumidifying functions.

Notes

The product images and descriptions included in this manual are stated based on ACP BACnet Free volt (Model No.: PQNFB17C0).

- ACP BACnet Free volt (PQNFB17C0)
- ACP BACnet 24V (PQNFB17C1)

For your records

Staple your receipt to this page in case you need it to prove the date of purchase or for warranty purposes. Write the model number and the serial number here:

Model number :

Serial number :

You can find them on a label on the side of each unit.

Dealer's name :

Date of purchase :

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING THE APPLIANCE.

Always comply with the following precautions to avoid dangerous situations and ensure peak performance of your product

It can result in serious injury or death when the directions are ignored.

It can result in minor injury or product damage when the directions are ignored.

- Installation or repairs made by unqualified persons can result in hazards to you and others.
- Installation MUST conform with local building codes or, in the absence of local codes, with the Nation Electrical Code NFPA 70/ANSI C1-1003 or current edition and Canadian Electrical Code Part1 CSA C.22.1.
- The information contained in the manual is intended for use by a qualified service technician familiar with safety procedures and equipped with the proper tools and test instruments.
- Failure to carefully read and follow all instructions in this manual can result in equipment malfunction, property damage, personal injury and/or death.

Installation

- Any question about the product installation should be asked to the service center or the professional installation agency.
 - It may cause fire, electric shock, explosion or injury.
- Consult the service center or the professional installation agency about reinstalling the installed product.
 - It may cause fire, electric shock, explosion or injury.
- Please use the standardized parts.
 - It may cause fire, electric shock, explosion, injury, or failure.
- · Do not keep or use combustible gas or inflammable material near the product.
 - IT may cause fire or electric shock.
- Do not disassemble, repair or modify the product at random.
 - It may cause failure of the product.

- Do not install where raindrop can fall.
 - It may cause failure of the product.
- Do not install the product at wet place.
 - It may cause failure of the product.
- · Provided product and adaptor shall only be installed and used inside a building.
 - It may cause fire or failure of the product.
 *Do not install or use outside.
- Install stably in a place that can endure the weight of the ACP BACnet.
 - If the installation place is not strong enough, the ACP BACnet may fall and damaged.
- Make sure to enquire to the specialty store of the product purchase or service center for electric works.
 - It may cause fire or electric shock.
- Do not damage the power cord or bend it by force.
 - It may cause fire or electric shock.
- You need to use a safely insulated power supply which follows IEC61558-2-6 and NEC Class2
 If you do not follow, It may cause fire, electric shock, explosion or injury.
- · Do not connetion 220V power to 24V products
 - If you do not follow, It may cause fire, electric shock, explosion or injury.
- Do not connect power cord to the control signal connector.
 - It may cause fire or explosion.

Operation

- Do not change or extend the power cord with your own discretion.
 - It may cause fire or electric shock
- Do not place any heating device near the product.
 - It may cause fire.
- Do not use any heating device near the power cord.
 - It may cause fire or electric shock.
- Do not let water flow into the product.
 - It may cause electric shock or failure.
- Do not put heavy weight on the power cord.
 It may cause fire or electric shock.
- Do not put heavy weight on the product.
 - It may cause the failure of the product.

ENGLISH

- If the product is flooded, consult the service center or the professional installation agency.
 It may cause fire or electric shock.
- Let the children or the old and the weak be controlled by the guardian to use.
 - It may cause accident or failure.
- Do not give any shock to the product.
 - Any shock to the product may cause failure.
- Grab the head of the plug of the power cord to pull when disconnecting the plug, and do not click the plug with wet hands.
 - It may cause fire or to deform the product.
- · Do not use the product in certain environments as follows.
 - If the product is used in a place with oil, steam, or sulfuric acid gas, performance may be degraded or product may be damaged.
- · Do not press the switch or button with sharp objects.
 - It may cause electric shock or failure of the product.
- Please check the operation temperature.
 - If the product is used in an environment with the temperature exceeding the operation boundary, it may cause a severe damage.
 Please check the usage temperature boundary in the manual. If there is no specified temperature, please use the product within the boundary of 0~40°C.
- · Do not put a container, etc. with water on the product.
 - It may cause fire or electric shock.
- Do not click the switch with wet hand.
 - It may cause electric shock or failure of the product.
- · Please read installation and user manual for connection with PC or peripheral devices.
 - It may cause fire or failure of the product.
- If a warning window appears on PC, product stops, or it does not work, immediately stop the usage.
 - It may cause fire or failure of the product.



Operation

- Do not use strong detergent such as solvent, but a soft cloth.
 - It may cause fire or to deform the product.
- Please check the rated capacity of the power.
 - It may cause fire or failure of the product.

ENGLISH

Table Of Contents

ACP BACnet FUNCTIONS AND SPECIFICATION

- 1 ACP BACnet Functions
- 3 ACP BACnet Components
- 4 Names of each part of ACP BACnet
- 6 ACP BACnet Hardware Specification

7 Starting

- 7 Login and logout
- 9 Home screen composition and features

1 Using the Program

- 11 Control/Monitor
- 38 Schedule
- 45 Auto Logic
- 67 Statistics
- 70 Report
- 72 Installing
- 80 Environment

97 Installing ACP BACnet

- 97 Installing ACP BACnet
- 98 Check points during the ACP BACnet installation
- 99 Setting the indoor unit address
- 101 Setting the PI485 and connecting the cable
- 103 Installing ACP BACnet and connecting cables
- 108 Setting the ACP BACnet network address
- 117 Setting the functions of the ACP BACnet

133 LG's ACP BACnet Agreement

135 Functional Specifications ACP BACnet

191 **notes**

- 191 Troubleshooting
- 195 Guide to Open Source Software
- 196 BIBBs
- 205 ACP-BACnet Error Response Table

ACP BACnet FUNCTIONS AND SPECIFICATION

ACP BACnet is the central controller that can manage up to 256 equipments in one space individually or as combined. ACP BACnet can monitor or control the equipments installed in each room of the building from the places such as the management office of a building or the administration office of a school.

ACP BACnet Functions

Major functions of the ACP BACnet are as follows.

Environment setting function using the ACP BACnet external buttons ACP BACnet can use the external buttons installed outside of the ACP BACnet to set the following functions.

- · Set Network environment (IP address, Net mask, Gateway)
- · Set the function to use between Peak/demand function
- SW upgrade function
- · Data backup function
- · Data recovery function
- · Set the ID of ACP BACnet when connected with demand function
- · Fire Alarm function
- · Fahrenheit/Celsius setting function
- · Device ID setting function
- · Vnet number setting function
- · Foreign Device register function



Embedded web server function

window using Internet Explorer, the central control program in ACP BACnet web server is automatically run, and the functions of various contents can be used.





- · Controlling of up to 256 air conditioner indoor units
- · Monitoring of error and operation status
- · Controlling the peak power / demand power
- · System setting function

Devices that can interface with ACP BACnet

Device	ACP BACnet
AC Ez	0
Simple Central Controller	0
AC-Smart	0
AC Manager	0
Air Conditioner	0
Ventilation	0
AWHP	0
Fire Alarm	0
Chiller	x
AHU	0

ACP BACnet Components

Inside the packaged box of the ACP BACnet, there are the components as in the following drawing.

Open the packaged box of the ACP BACnet, and check if all of the corresponding components are included.



ACP BACnet



ACP BACnet Quick Manual



Power Supply Adaptor Input: 100~240V AC 50/60Hz 3.33A Output: DC 12V 3.33A, 40W MAX Power Cord 250V AC, 3A ACP BACnet Installation/User Manual CD



Power Supply Adaptor and Power Cord are not included in PQNFB17C1.

Names of each part of ACP BACnet

ACP BACnet is composed as follows.





Notes

No. 3 and No. 4 may be different for each model.

Number	Item	Description
1	Cover	Front cover of the ACP BACnet
2	RS-232 console port	Reserved communication port
3	Adaptor connection jack	Jack for DC 12V to connect to the power supply adaptor (not supported by PQNFB17C0.)
(4)	Power port	AC24V port for power connection (not supported by PQNFB17C0)
5	Buttons and LCD	Buttons and LCD to set network environment and to display other information
6	Optional input/ output and RS-485 communication port	Connection port to connect to external input/output signals and RS-485 communication port for external expansion. (8 DI's, 2 DO's, 2 RS-485 communication ports)
0	RS-485 communication port	RS-485 communication ports to connect to air conditioner and ventilation equipment (4 in total)
8	Mini USB port	USB to Serial port for software debugging
9	USB port	For software update and data backup
10	SD card slot	For RS-485 communication data backup.
(1)	Ethernet port	Ethernet port to connect to internet and AC Manager
12	Power switch	Switch to turn on or off the power of the ACP BACnet

Caution

If four times the power connector for the connection, as shown by using the right connection, but please note that an electric shock.

Use the designated parts must be connected to a power source.

 Connector manufacturers: PHOENIX CONTACT PartNo: MVSTBR 2,5 / 2-ST-5, 08 2P 5.00MM



ACP BACnet Hardware Specification

ACP BACnet hardware specification is as follows.

Category	Description
Boundary of usage temperature	0°C~40°C
CDU	i.MX515
CFU	32Bit 800MHz speed
RAM	128MB DDR2 SDRAM * 2EA
ROM	4GB i-NAND Flash
Communication ports	 Ethernet 10 / 100 BASE-T USB : USB Host (SW upgrade, data backup) mini USB Device (Debug) RS-485 communication ports 6EA SD card slot (RS-485 communication logging) RS-232 Console Port (HMI)
External input/output ports	DI, DO
LED	27EA (RS communication status, Ethernet communication status, power status, operation status)
LCD	20 x4 Character-LCD (network environment setting and information display)



Notes

License policy

This product follows GPL (General Public License) for the use of Embedded Linux.

Starting

Login and logout

The following explains how to log in/out ACP BACnet.

Connected to the ACP BACnet

How to Connect to the ACP BACnet is as follows.

1. Connected to the ACP BACnet enter the IP address of the ACP BACnet in the Internet Browser.

Login

You can login as follows.

- 1. Run ACP BACnet.
- 2. After entering your ID and password in the login window, click [Confirm].
 - You are now logged in.

ID	system admin	-
Passwd	Input Password,	
	✓ save ID	
	Confirm	

Logout

You can logout as follows.

- 1. On the top right of the ACP BACnet screen, click the **[Logout]** button.
 - You are now logged out.

Running Status(Unit)			Time				
			03:1	2™	-	2013,04,05	FRI
74			Today's Sch	edule			+
	160		1		12:00_abc		
	100		e	vent			
Running Stop Error	100		l e	vent			
Error	SCUMPE 30	0		vent		*	
Running Stop Firor Control/Monitor	Schedule	AutoLogic	e A ^B c Statistics	vent	Installing	Environment	

Home screen composition and features

The following explains the home screen composition and features.



Number	Item	Description
1	Running Status (Unit)	Checks if all the devices are operating, has stopped, or has already been checked.
2	Time	Check the current date and time. (You need Internet connection to check the weather.)
3	Today's Schedule	 Check the registered schedules in chronological order. Click the [+] button to move to the schedule menu.
(4)	Main Menu	Use ACP BACnet main menu.
5	Home	Return to the home screen.
6	View Menu	Display the active menu.
7	Current Menu	Display the name of the active menu.

Using the Program

The following explains how to use the ACP BACnet functions.

Control/Monitor

Control/Monitoring is managing multiple devices collectively as one. The following explains the Control/Monitor menu options.

Control/Monitoring screen composition and features

The following explains Control/Monitoring screen composition and features.



Number	Item	Description
1	Select/Deselect All	Select/deselect all devices in a group.
2	[Drawing] Button	View floor plans of a group.
3	[Filter] Button	Select device types for which you want to check the control status.
(4)	View Type Select	Select a view type for the monitoring screen (Icon/Simple/Detailed) (For more on View Type , refer to page 12)
5	Group List	Check device group listings.

Number	Item	Description
6	Monitoring Screen	Check the control status of a device.
1	Device Control Box	 Display the device control menu. The device control box shows different menus depending on the device. (For more on Control Menu per Device on page 17)

View Type

Control/Monitor menu has three types of views (icon, simple, and detailed). The following shows the screen composition and features per view type.

lcon

The control status is shown in icons. The device icon has a composition and feature as follows.



Number	Item	Description
1	Operation Mode and Device Status Icon	The color at the top of the icon box shows the current operation mode, and the status of the device is indicated as an icon.
2	Device Icon	The device to be controlled is indicated as an icon. The device shown may not represent the appearance of the actual unit.
3	Current Temperature	Display the current temperature.
(4)	Operation Mode	Display the operation mode of the device.
5	Desired Temperature	Display the desired temperature.
6	Device Name	Display the name of the device.

Simple

The control device and operation mode are displayed only.



Number	Item	Description
1	Operation Mode	The color of the box indicates the current operation mode.
2	Device Icon	The device to be controlled is indicated as an icon.

Details

All properties of the control device are tabulated in details.

Monitoring screen colors and icons

Box colors and operation mode per icon

Color	lcon	Operation Mode
	*	Cooling
(Blue)	1	Ventilation, General
	-ċ;-	Heating
(Orange)	*	Ventilation, Electric Heat
(Navy)	٥	Dehumidification
(Sky Blue)	爭	Fan
(Green)	ė	Power Saving
	(AII)	Auto
(Purple)	<u> </u>	Ventilation, Auto
(Yellow)	-	ON & Short
(Gray)	-	OFF & Open
	-	Error

Device status icon

Icon	Device Status
	Filter Exchange
Ŀ	Full Lock On
	Peak/Demand Control
	Schedule

Control device icon

Icon	Device Type
	Indoor Device
	Ventilators
(Fy)	AHU
	AWHP
	Chiller
(B)	DI
00	DO
	DOKIT

Device Control

You can control the devices as follows.

- 1. From the main menu, click the [Control/Monitor] menu icon.
- 2. Click the device group you want to control from the group list.
 - The monitoring screen for the device is displayed.
- 3. Click the device you want to control.
 - To select all devices, click the 🗸 button at the top.
 - The device control area appears at the bottom of the screen.
- 4. In the device control box, set the control status of the device.
 - The device control box shows a different menu depending on the device. For information about the control area for each device, GoTo the refer to **Control Menu per Device** on page 17.
- 5. Once you have finalized the settings, click the [Apply] button.

Control Menu per Device

The control box menu differs depending on the device. The following shows the control box menu per device.

Indoor Device

The following is the indoor unit control menu and features.

Operation		Room	Set Tempe	erature	Mode						
ON	OFF				本 COOL	☆ HEAT	@ AUTO	0 [DRY	歩 FAN	Apply
GoTo		23.°	25.0		Fan Speed				Swing		
Schee	dule 🕨			•	LOW	MED H	IIGH AU	ТО	Set	Clear	Detail. 🕨

Item	Description
Operation	[ON] Button: Starts the operation of the device.[Off] Button: Stops the operation of the device.
GoTo	[Schedule▶] Button: Move to Schedule menu.
Room	Display the current temperature.
Set Temperature	Click [▲] / [▼] to set the temperature. (The maximum/minimum temperatures that can be set may differ depending on the model.)
Mode	 [COOL] Button: Operates with Cooling Mode. [HEAT] Button: Operates with Heating Mode. [AUTO] Button: Evaluates the operating environment conditions and automatically sets the optimum temperature. [DRY] Button: Dehumidifies during rainy seasons or whenever humidity is high. You cannot set the temperature in this mode. [FAN] Button: Purifies the air. You cannot set the temperature in this mode.
Fan Speed	 [LOW] Button: Slow fan speed. [MED] Button: Medium fan speed. [HIGH] Button: Fast fan speed. [AUTO] Button: Loops from LOW to MEDIUM to HIGH speeds.
Swing	 [Set] Button: Turns on automatic oscillation for the fan. [Clear] Button: Turns off automatic oscillation for the fan.
[Detail.] Button	Controls details.

· Indoor unit fine control

DU					2Setpoint	
Operation		Set(℃)				
ON OFF				18	3.0 🔺	
Mode	1					
* COOL 🔅 HEAT @		(A) /	UTO	♦ DRY	굥 FAN	
Fan Speed	0.000					
LOW M		D	Н	IIGH	AUTO	
Swing		_	Filte	r Alarm		
Set Clear		r	Clear			
Partial Lock						
HardLock	Clea	r	ModeLock		Clear	
FanLock Clear		r	TempLock		Clear	
Set Temp Ra	nge(°C)					
• 1	6.0		~	30).0	
Car	ncel			Ар	ply	

Item	Description
Operation	[ON] Button: Starts the operation of the device.[Off] Button: Stops the operation of the device.
Set	Click [▲] / [▼] to set the temperature.
Mode	 [COOL] Button: Operates with Cooling Mode. [HEAT] Button: Operates with Heating Mode. [AUTO] Button: Evaluates the operating environment conditions and automatically sets the optimum temperature. [DRY] Button: Dehumidifies during rainy seasons or whenever humidity is high. You cannot set the temperature in this mode. [FAN] Button: Purifies the air. You cannot set the temperature in this mode.
Fan Speed	 [LOW] Button: Slow fan speed. [MED] Button: Medium fan speed. [HIGH] Button: Fast fan speed. [AUTO] Button: Loops from LOW to MEDIUM to HIGH speeds.
Swing	 [Set] Button: Turns on automatic oscillation of the fan. [Clear] Button: Turns off automatic oscillation of the fan.
Filter Alarm	Click the Disable button to deactivate the filter exchange alarm. (For other models, it may not work properly.)

Item	Description
Partial Lock	 [HardLock] Button: Disables remote control for all features. [Clear] Button: All functions are unlocked. [ModeLock] Button: Disables remote control for local mode setting. [Clear] Button: Mode is unlocked. [FanLock] Button: Disables remote control for local fan speed setting. [Clear] Button: Fan speed is unlocked. [TempLock] Button: Disables remote control for local temperature setting. [Clear] Button: Temperature setting is unlocked.
Set Temp Range	Click $[\blacktriangle]/[\triangledown]$ to set the temperature limit.
[2Setpoint] Button	Switches between cooling and heating within the selected temperature range.

• Indoor 2Setpoint (Auto Operation Mode)

AutoChangeOver			
ON OFF			
Lower(16~30)	Upper(*	16~30)	
▼ 20.0 ▲	•	27.0	
Setback			1.11
ON OFF			
Cooling Start Temp.	Heating	g Start Temp) .
▼ 40,0 ▲	•	6.0	
		1993 - M	_

Item	Description					
	(The auto change over function works well with "Heat Recovery" model. For other models, it may not work properly.)					
Auto Change Over	Set the auto change over function to switch the operation mode automatically to keep the proper room temperature.					
	 [ON] Button: Enable Auto Change Over [OFF] Button: Disable Auto Change Over 					
Lower	Click [▲] / [▼] to set the lower limit temperature range (16°C~30°C / 60°F~86°F).					
Upper	Click [▲] / [▼] to set the upper limit temperature range (16°C~30°C / 60°F~86°F).					

Item	Description
	(The setback function works well with "Heat Recovery" model. For other models, it may not work properly.)
Setback	Set the setback function to control the proper room temperature when the indoor unit is turned off.
	• [ON] Button: Enable temperature limits
	[OFF] Button: Disable temperature limits
Cooling Start Temp.	Click $[\blacktriangle]/[\lor]$ to set the cooling start temperature (21°C~40°C / 70°F~104°F).
Heating Start Temp.	Click [▲] / [▼] to set the heating start temperature (1°C~20°C / 34°F~68°F).

ERV

The following is the ERV control menu and features.

Operation		Room	Set Tempe	rature	Mode				
ON	OFF	10	475		AUTO	💥 HE	x <u>∞</u> 1	IORM.	Apply
GoTo		24.0	0		Fan Speed	ł			
Sche	dule 🕨				LOW	HIGH	SUPER	AUTO	Detail.

ltem	Description
Operation	[ON] Button: Starts the operation of the device.[Off] Button: Stops the operation of the device.
GoTo	[Schedule▶] Button: Move to Schedule menu.
Room	Display the current temperature.
Set Temperature	Click $[\blacktriangle]/[\forall]$ to set a desired temperature (the ventilator is not activated).
Mode	 [AUTO] Button: Evaluates the operating environment conditions and automatically sets the optimum temperature. [HEX] Button: Air supply and emissions are all ventilated through the heat exchanger. [NORM] Button: Ventilate emissions without passing through the heat exchanger.
Fan Speed	 [LOW] Button: Slow fan speed. [HIGH] Button: Fast fan speed. [SUPER] Button: Maximum fan speed. [AUTO] Button: Loops from LOW to HIGH to SUPER speeds.
[Detail. ▶] Button	Control details.

• ERV Fine Control

Operation		Set				
ON	OFF	w	🔺			
Mode						
AUTO	H	IEX	NORMAL			
Fan Speed						
LOW	HIGH	SUPER	AUTO			
Partial Lock						
Se	t	Clear				
Additional Fun	ction					
Drift	Q	uick Clear				
Heater On	Heater Off	Humid On	Humid Off			
Co-Aircondition	ner					
COOL HEAT		AUTO				

Item	Description			
Operation	 [ON] Button: Starts the operation of the device. [OFF] Button: Stops the operation of the device. 			
Set	Click $[\blacktriangle]/[\Psi]$ to set a desired temperature (the ventilator is not activated).			
Mode	 [AUTO] Button: Evaluates the operating environment conditions and automatically sets the optimum temperature. [HEX] Button: Air supply and emissions are all ventilated through the heat exchanger. [NORMAL] Button: Ventilate emissions without passing through the heat exchanger. 			
Fan Speed	 [LOW] Button: Slow fan speed. [HIGH] Button: Fast fan speed. [SUPER] Button: Maximum fan speed. [AUTO] Button: Loops from LOW to HIGH to SUPER speeds. 			
Partial Lock	 [Set] Button: Disables remote control for all features. [Clear] Button: Disable the lock. 			
Additional Function	 [Drift] Button: Reduces energy consumption by operating in the most efficient method possible. [Quick] Button: Operates at maximum performance to prevent the room's contaminated or humid air from entering other spaces. [Clear] Button: Disables power saving / rapid operation. [Heater On] Button: Enables the heater function to heat the room. [Heater Off] Button: Disables the heater function. Some additional function might not be provided according to your country such as U.S. 			

ERV DX

1

The following is the ERV DX control menu and features.

Operation		Room	Set Tempe	erature	Mode	- 25			
ON	OFF		10		AUTO	💥 HE	x 💌 🛚	NORM.	Apply
GoTo		24.0	24.0 18.0 Fan Speed						
Sche	dule 🕨			•	LOW	HIGH	SUPER	AUTO	Detail.

Item	Description
Operation	[ON] Button: Starts the operation of the device.[Off] Button: Stops the operation of the device.
GoTo	[Schedule▶] Button: Move to Schedule menu.
Room	Display the current temperature.
Set Temperature	Click [▲]/[▼] to set the temperature.
Mode	 [AUTO] Button: Evaluates the operating environment conditions and automatically sets the optimum temperature. [HEX] Button: Air supply and emissions are all ventilated through the heat exchanger. [NORM] Button: Ventilate emissions without passing through the heat exchanger.
Fan Speed	 [LOW] Button: Slow fan speed. [HIGH] Button: Fast fan speed. [SUPER] Button: Maximum fan speed. [AUTO] Button: Loops from LOW to HIGH to SUPER speeds.
[Detail. ▶] Button	Control details.

• ERV DX

Operation		Set			
ON	T	18.0			
Mode					
AUTO		NORMAL			
Fan Speed			_		
LOW	HIGH	SUPE	R AUTO		
Partial Lock					
Se	t		Cle		
Additional Fun	ction				
Drift	Q	uick		Clear	
Heater On	Heater Off	Humid	l On	Humi	
Co-Aircondition	ner				
COOL HEAT		AUTO)	STOP	

Item	Description
Operation	 [ON] Button: Starts the operation of the device. [OFF] Button: Stops the operation of the device.
Set	Click [▲]/[▼] to set the temperature.
Mode	 [AUTO] Button: Evaluates the operating environment conditions and automatically sets the optimum temperature. [HEX] Button: Air supply and emissions are all ventilated through the heat exchanger. [NORMAL] Button: Ventilate emissions without passing through the heat exchanger.
Fan Speed	 [LOW] Button: Slow fan speed. [HIGH] Button: Fast fan speed. [SUPER] Button: Maximum fan speed. [AUTO] Button: Loops from LOW to HIGH to SUPER speeds.
Partial Lock	 [Set] Button: Disables remote control for all features. [Clear] Button: Disables the lock.

Item	Description
Additional Function	 [Drift] Button: Reduces energy consumption by operating in the most efficient method possible. [Quick] Button: Operates at maximum performance to prevent the room's contaminated or humid air from entering other spaces. [Clear] Button: Disables power saving / rapid operation. [Heater On] Button: Enables the heater function to heat the room. [Heater Off] Button: Disables the heater function. [Humid On] Button: Enables the humidifier function for room humidity control. [Humid Off] Button: Disable the humidifier function (not activated). Some additional function might not be provided according to your country such as U.S.
Co- Airconditioner	 [COOL] Button: Operates with Cooling Mode. [HEAT] Button: Operates with Heating Mode. [AUTO] Button: Operates in Auto Mode. [STOP] Button: Stops the air conditioning function.
AHU

The following is the AHU control menu and features.

Operation		Room	Set Temper	rature	Mode					
ON	OFF		10		* COOL	🔅 HEA	T 哈 Fi	AN Ó DRY	🗑 Drift	Apply
GoTo		18.0	18.0		AutoVent	_	Humidify			
Sche	dule			•	Set	Clear	Set	Clear		Detail.

Item	Description
Operation	 [ON] Button: Starts the operation of the device. [Off] Button: Stops the operation of the device.
GoTo	[Schedule>] Button: Move to Schedule menu.
Room	Display the current temperature.
Set Temperature	Click [▲] / [▼] to set the temperature.
Mode	 [COOL] Button: Operates with Cooling Mode. [HEAT] Button: Operates with Heating Mode. [FAN] Button: Purifies the air. [DRY] Button: Dehumidifies the air during the rainy season or when humidity is high. [Drift] Button: Reduces energy consumption by operating in the most efficient method possible.
AutoVent	 [Set] Button: If the CO2 concentration level increases during cooling or heating, increase the outdoor air volume to reduce the CO2 concentration level. [Clear] Button: Disables AutoVent.
Humidify	 [Set] Button: Enables the humidifier function. [Clear] Button: Disables the humidifier function.
[Detail. ▶] Button	Control details.

AHU Fine Control

Operation				Set			_	_
ON		OFF						
Mode								
本 COOL ☆ HE		AT 🗣 FA		AN 🖒		DRY E		Drift
AutoVent	17			C02	(ppm	n)		
Set		Clear		V		100)0	
Humidify				Humidity(%)		(%)	, 111 111	
Set		Clear						
Partial Loo	ck			_				
	Set					Clear	-	
OA Dampe	er	ΕA	Damp	ber		MIX D	amp	er
SALA								
				-			3	_
	-							-

Item	Description
Operation	• [ON] Button: Starts the operation of the device.
Set	Click [▲]/[▼] to set the temperature.
	 [COOL] Button: Operates with Cooling Mode. [HEAT] Button: Operates with Heating Mode. [FAN] Button: Purifies the air.
Mode	• [DRY] Button: Dehumidifies the air during the rainy season or when humidity is high.
	 [Drift] Button: Reduces energy consumption by operating in the most efficient method possible.
AutoVent	• [Set] Button: If the CO ₂ concentration level increases during cooling or heating, increase the outdoor air volume to reduce the CO ₂ concentration level.
	[Clear] Button: Disables AutoVent.
CO2(ppm)	Use $[\blacktriangle]/[\heartsuit]$ to set the desired carbon dioxide emission level from 500 ppm to 1,500 ppm in intervals of 100 ppm (CO ₂ is not settable in some models.).
Humidify	 [Set] Button: Enables the humidifier function. [Clear] Button: Disables the humidifier function.
Humidity(%)	Use $[\blacktriangle]/[\forall]$ to set the desired humidity from 40% to 60% in intervals of 1%.
Partial Lock	 [Set] Button: Disables remote control for all features. [Clear] Button: Disables the lock.
OA Damper	Use [▲]/[▼] to set the OA damper from 0° to 90° in intervals of 1°.
EA Damper	Use $[\blacktriangle]/[\Psi]$ to set the EA damper openness from 0° to 90° in intervals of 1°.
MIX Damper	Use $[\blacktriangle]/[\nabla]$ to set the mix damper openness from 0° to 90° in intervals of 1°.

DOKIT

The following is the DOKIT control menu and features.

Operation		
ON	OFF	Apply
GoTo		
Sche	dule 🕨	Detail. 🕨

Item	Description				
Operation	[ON] Button: Starts the operation of the device.[Off] Button: Stops the operation of the device.				
GoTo	[Schedule>] Button: Move to Schedule menu.				

AWHP

The following is the AWHP control menu and features.

Operation		Mode							
ON OFF		@ AU	🐵 AUTO 🗚 COOL 🌣 HEAT					Apply	
GoTo		Air Ter	np.(°C)		HotWa	ter Temp.(°	C)		
Sche	dule 🕨		18.0		•	50.0		Detail. 🕨	

Item	Description
Operation	[ON] Button: Starts the operation of the device.[Off] Button: Stops the operation of the device.
GoTo	[Schedule▶] Button: Move to Schedule menu.
Mode	 [AUTO] Button: Evaluates the operating environment conditions and automatically sets the optimum temperature. [COOL] Button: Operates with Cooling Mode. [HEAT] Button: Operates with Heating Mode.
Air/Water Temp.	<pre>(Indicated as air or water temperature depending on the product.) Click [▲]/[▼] to set the air/water temperature.</pre>
HotWater Temp.	Click [▲]/[▼] to set the water heater temperature.
[Detail. ▶] Button	Control details.

AWHP Fine Control

Jperati	on	_	_		
	ON		-	OFF	
Hotwat	er				
	ON			OFF	
Partial	Lock				
	Set			Clear	
Mode				14	
	AUTO	CC	JOL	HEA	Т
Air Ter	np.(℃)		HotWa	ter Temp.(°(2)
•	18.0		•	50.0	

Item	Description
Operation	 [ON] Button: Starts the operation of the device. [OFF] Button: Stops the operation of the device.
Hotwater	[ON] Button: Enables the hot water function.[OFF] Button: Disables the hot water function.
Partial Lock	 [Set] Button: Disables remote control for all features. [Clear] Button: Disable the lock.
Mode	 [AUTO] Button: Evaluates the operating environment conditions and automatically sets the optimum temperature. [COOL] Button: Operates with Cooling Mode. [HEAT] Button: Operates with Heating Mode.
Air/Water Temp.	(Indicated as air or water temperature depending on the product.) Click [▲]/[▼] to set the air/water temperature.
Hot Water Temp.	Click [▲]/[▼] to set the water heater temperature.

DO

The following is the DO control menu and features.

Operation		
SHORT	OPEN	Apply
GoTo		
Schee	ule 🕨	Detail.

Item	Description
Operation	[SHORT] Button: Short signal output.[OPEN] Button: Open signal output.
GoTo	[Schedule▶] Button: Move to Schedule menu.

Registering Floor Plan

In the Control/Monitor menu, you can register floor plans to identify and locate each device and device group. On the floor plan, you can register space information as well as the location where a device is installed.

- 1. In the main menu, click the [Control/Monitor] menu icon.
- 2. Select the device group you want to monitor from the group list.
 - The monitoring screen for the device is displayed.
- 3. Click [Drawing] button.

Control/Monitor	< 🖌 DXHRV (7)		Drawing	Filter 🔻 Icon 👻
AC UNIT	○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○○			and the second
VENT	24° 165	24° 16.0	24° 16.0	24 [°] 16 [°]
VENT_2	VENT_UNIT_01	VENT_UNIT_02	VENT_UNIT_03	VENT_UNIT_04
DXHRV	And Annual States	James New William	ATTAL Name OF HEY	
AHU	24.0 16.8	24.0 16.8	24.0 16.8	
AC UNIT_2	VENT_UNIT_05	VENT_UNIT_06	VENT_UNIT_07	
AWHP				

4. Click [Edit] button.

Control/Monitor	< 🖌 DXHRV (7)	Edit	List	Filter 🔻	lcon: •
AC UNIT	000	1.1	1		
VENT					
VENT_2					
DXHRV					
AHU		No Drawing Ir	nage		
AC UNIT_2	4	dd you own drawi	ng image		
AWHP					

5. [Add Drawing] button.

• The Open Floor Plan window is displayed.

<	/Monitor < V DXHRV (7)		
	VENT_UNIT_01		
	/ENT_UNIT_02		
	VENT_UNIT_03		
	/ENT_UNIT_04		
	/ENT_UNIT_05	No Drawing Image	
	/ENT_UNIT_06	Add you own drawing image	
	/ENT_UNIT_07		
	Add Drawing	Cancel	Apply
r.	Add Drawing	с	ancel

- 6. Select a desired floor plan from the Open Floor Plan window, then click [Confirm].
 - The floor plan image is displayed.

map/test.png	
map/base.png	
] map/mars.jpg	
map/img2.jpg	
map/img3.jpg	
map/base3.png	
map/img.jpg	
map/base2.png	•

7. In the device list, select a device you want to display on the floor plan and click the device location on the plan.



• To delete a device from the plan, double-click its icon.

8. To complete the registration of the floor plan, click the [Apply] button.



Checking Floor Plan

In Control/Monitoring, you can check floor plans. On the floor plan, you can register space information as well as the location where a device is installed.

- 1. In the main menu, click the [Control/Monitor] menu icon.
- 2. Select the device group you want to monitor from the group list.
 - The monitoring screen for the device is displayed.
- 3. Click [Drawing] button.
 - The registered floor plan is displayed.



Editing the Floor Plan

You can edit a registered floor plan.

- 1. In the main menu, click the [Control/Monitor] menu icon.
- 2. Select the device group you want to monitor from the group list.
 - The monitoring screen for the device is displayed.
- 3. Click [Drawing] button.

Control/Monitor	< 🖌 DXHRV (7)		Drawing	Filter 🔻 Icon	٠
AC UNIT	() 影 新 () ()	a seancar			
VENT	24° 165	24° 16.0	24° 16°	24° 16°	
VENT_2	VENT_UNIT_01	VENT_UNIT_02	VENT_UNIT_03	VENT_UNIT_04	
DXHRV	And Annual Market	JUNE, None W. HEY	ATTA New WINY		
AHU	24. 16.	24.0 16.8	24. 16.8		
AC UNIT_2	VENT_UNIT_05	VENT_UNIT_06	VENT_UNIT_07		
AWHP					

4. Click [Edit] button.

Control/Monitor	< .	DXHRV (7)	Edit	List	Filter 💌	lcon. •
AC UNIT					+	
VENT		16	-10 14		und prod	
VENT_2						
DXHRV				inen Bernstary #		
AHU		Concher Room				
AC UNIT_2			1 70.			
AWHP				100	To VI	

- 5. To change floor plan, click [Change] button.
 - The Open Floor Plan window is displayed.
- 6. Select a desired floor plan from the Open Floor Plan window, then click [Confirm].
 - The floor plan image is displayed.

7. To change the location of a device, click the icon of the device and then click the location to which you want to move that device.



8. To complete floor plan editing, click the [Apply] button.



Deleting the Floor Plan

You can delete a registered floor plan.

- 1. In the main menu, click the [Control/Monitor] menu icon.
- 2. Select the device group you want to monitor from the group list.
 - The monitoring screen for the device is displayed.
- 3. Click [Drawing] button.
 - The registered floor plan is displayed.
- 4. Click [Edit] button.
- 5. To delete a floor plan, click the [Delete] button.



6. When you are prompted to confirm the deletion, click [Confirm].

Monitoring a Device

You can check the control state of registered devices.

- 1. In the main menu, click the [Control/Monitor] menu icon.
- 2. Select the device group you want to monitor from the group list.
 - · The monitoring screen for the device is displayed.
- 3. Click a device you want to monitor.
- 4. Please check the device information in the monitoring screen.
 - The information on the monitoring screen differs depending on the view type. For details about the view types, View Type on page 12.

Control/Monitor	< 🖌 AC UNIT (16)	1	Drawing	Filter 💌 Ico	n •
AC UNIT			10. et al (27.)	Ross and	
VENT	23.0 + 20.0 °	Now ⊕ FAN 23 [℃] # 26,0 [℃] + 22,0 [℃]	23 [°] + 25.0 [°] 23 [°] + 25.0 [°]	≥ New * COOL 23° + 25,0° + 20,0°	
VENT_2	AC_UNIT_00	AC_UNIT_01	AC_UNIT_02	AC_UNIT_03	
DXHRV		「「「ない」」			
AHU	23.0 ± 18.0°	23.0 + 18.0 ^T	23.0 + 25.0°C	23° 25°	
AC UNIT_2	AC_UNIT_04	AC_UNIT_05	AC_UNIT_06	AC_UNIT_07	
AWHP	23,° 18,5	Now ★ COOL 23 th 25 th 25 th	الله المعالي معالي معالي معالي معالي م معالي معالي	23.° 18.°	
	AC_UNIT_08	AC_UNIT_09	AC_UNIT_0A	AC_UNIT_0B	
~					¥

5. To check the control status of the device, click the [Detail.] button.

Schedule

The Schedule feature allows you to program the behavior of the devices. If a device must adhere to a certain schedule, you can program the device to operate only at scheduled times. Scheduled devices do not activate unless programmed to do so and are managed centrally. This can significantly reduce energy consumption.

Schedule Screen composition and features

The following explains Schedule Screen composition and features.



Number	Item	Description
1	[Today] Button	Display today's date, the current week, or the current month.
2	Dates	 Displays the selected date. Use [<]/[>] to move to the previous/next date.
3	View Type	[W] Button: Converts to Week View.[M] Button: Converts to Month View.
(4)	[Total] Button	View full schedule list.
5	Calendar	Displays the schedules for the selected dates.Today's date is marked in light blue.
6	Schedule List	Displays registered schedules by name.

Number	Item	Description
0	[Add a Schedule] Button	Registers new schedules.

Creating Schedules

You can configure and add a schedule for a device.

- 1. In the main menu, click [Schedule] menu icon.
- 2. [Add a Schedule] Button.
 - The Add Schedule window opens.
- 3. In the group list, click a device for which a schedule is applied.
 - The selected device is displayed in the applied device area of the control command configuration.

V AC UNIT	•		Schedule Name				
VENT	-		Please, Enter the na	me of schedule.			
e veni			Time	Period			
VENT_2	•		PM 12:00	2012-12-05	~	2012-12-05	
V DXHRV			Repeat Pattern	Select day			
VENT UNIT 01			Everyday 💌	Sun Mon	V Thu	√Wed √ Th	u 🗸 Fri 🗸 S
				Cor	mmand		
VENT_UNIT_02			Apply to		Comm	and summary	
VENT_UNIT_03							
VENT_UNIT_04			Please select	units on the list,		No com	mand
VENT_UNIT_05		w					
					Са	ncel	Confirm

Schedule

龠

pply to					
V RAC			Schedule Name		
			schedule1		
✓ vent	. ^		Time	Period	
✓ VENT_UNIT_29			PM 12:00	2013-04-2	2 ~ 2013-04-22
VENT_UNIT_2A			Repeat Pattern	Select day	
VENT_UNIT_2B			Everyday 🔻	√Sun √Mon √	Tue 🗸 Wed 🗸 Thu 🗸 Fri
				Comma	ind
VENT_UNIT_2C			Apply to	1	Command summary
VENT_UNIT_2D			ERV(1)		ERV No command
VENT_UNIT_2E					
VENT UNIT 2F		*			

Item	Description			
Schedule Name	Click the input box. Enter the name of the schedule			
Time	 Click the time area and then the [+]/[-] button to select the desired time. Click the [AM]/[PM] button to select before or after midday. 			
Period	Click the period area and then the [+]/[-] button to select the desired period.			
Repeat Pattern	 Click the Repetition Pattern area and select a desired pattern. Select Day: Selected days the schedule will be performed. Once: Applies a schedule once on a selected date. Everyday: Applies the same schedule Everyday. Mon - Fri: Applies a schedule repeatedly from Monday to Friday. Mon - Sat: Applies a schedule repeatedly from Monday to Saturday. 			
Select day	Click a desired day to apply a schedule.			

AM 10:26

- 5. Click the device icon of the applied device.
 - The control configuration window for the device is displayed. The control configuration window differs depending on the device.

mand summary
No command
ancel Confirm
The second

- 6. Configure the device control status, then click the [Confirm] button.
 - The control list configured in the Command Summary area is displayed.

Operation		Set	
ON	OFF	v	A
Mode		-	
AUTO	Н	EX	NORMAL
Fan Speed			
LOW	HIGH	SUPER	AUTO
Partial Lock			
S	et	С	lear
Additional Fu	nction		
Drift	Qu	uick	Clear
Heater On	Heater Off	Humid Or	Humittor
Co-Airconditi	oner		
COOL	HEAT	AUTO	STOP
Can	cel	C	onfirm

7. To complete the schedule configuration, click the [Confirm] button.

Checking Schedules

You can check registered schedules.

- 1. In the main menu, click the [Schedule] menu icon.
- 2. In the Date area, click the [4]/[b] button to select a schedule search period.
 - The number of schedules are displayed for the selected date.

Foday		2	013.4.		•	W M		Total
Sun	Mon	Tue	Wed	Thu	Fri	Sat	Conference	*
	1	2	3	4	5	6		
7	8	9	10	11	12	13		
14	15	16	17	18	19	20		
21	22	23	24	25	26	27		
28	29	30						
							Add a schedule	

- 3. To check schedule details, click a schedule you want to check in the schedule list.
 - Schedule details are displayed.

oday	•	2	2013.4.		•	W M	Total
Sun	Mon	Tue	Wed	Thu	Fri	Sat	Conference
	1	2	3	4	5	6	Repeat Once
7	8	9	10	11	12	13	Time 12:00
14	15	16	17	18	19	20	No,Unit 1units
21	22	23	24	25	26	27	Edit Delete
28	29	30					
							Add a schedule

Editing Schedules

You can modify the content of a registered schedule as follows.

- 1. In the main menu, click the [Schedule] menu icon.
- 2. Click a schedule you wish to modify from the schedule list.
 - · Schedule details are displayed.
- 3. Click the [Edit] button.
 - The schedule configuration screen is displayed.

•	2	2013.4.		•	W M	Total
Mon	Tue	Wed	Thu	Fri	Sat	Conference
1	2	3	4	5	6	Repeat Once
8	9	10	11	12	13	Period 2013-04-05 ** 2013-04-05 Time 12:00
15	16	17	18	19	20	No.Unit lunits
22	23	24	25	26	27	Edit Delete
29	30					
						Add a saferdida
	 Mon 1 8 15 22 29 	Mon Tue 1 2 8 9 15 16 22 23 29 30	X000 Tue Wed 1 2 3 8 9 10 15 16 17 22 23 24 29 30	Mon Tue Wed Thu 1 2 3 4 8 9 10 11 15 16 17 18 22 23 24 25 29 30	Mon Tue Wed Thu Fri 1 2 3 4 5 1 <td< td=""><td>Mon Tue Wed Thu Fri Sat 1 2 3 4 5 6 1 2 3 4 5 6 1 2 1 12 13 8 9 10 11 12 13 15 16 17 18 19 20 22 23 24 25 26 27 29 30 </td></td<>	Mon Tue Wed Thu Fri Sat 1 2 3 4 5 6 1 2 3 4 5 6 1 2 1 12 13 8 9 10 11 12 13 15 16 17 18 19 20 22 23 24 25 26 27 29 30

- 4. Modify the schedule information and device control configuration, then click the [Confirm] button.
 - The changed data will be saved.

Deleting Schedules

You can delete a registered schedule as follows.

- 1. In the main menu, click the [Schedule] menu icon.
- 2. Click a schedule you wish to delete from the schedule list.
 - Schedule details are displayed.
- 3. Click the [Delete] button.

oday	•	2	2013.4.		*	W M	Total
Sun	Mon	Tue	Wed	Thu	Fri	Sat	Conference
	1	2	3	4	5	6	Repeat Once
7	8	9	10	11	12	13	Time 12:00
14	15	16	17	18	19	20	No.Unit lunits
21	22	23	24	25	26	27	Edit Delete
28	29	30					
							Add a schedule

- 4. When you are prompted to confirm the deletion, click [Confirm].
 - The selected schedule is deleted.

the selected schedule?

Auto Logic

Auto Logic allows the system to automatically control the power consumption of external devices. You can also set the indoor temperature to automatically adjust to outdoor conditions or activate devices for certain periods of time.

Notes

If you set a device control value in the auto logic status view, the device can operate based on that value.

Peak Control

Peak control limits peak power consumption. You can set the target operating rate so that total power consumption does not exceed the set limit. To prevent power consumption from exceeding the limit, the system will automatically change cooling mode to fan mode and cancel heating mode.



Depending on the installation site specifications, either of the peak control and demand control functions can be selected. Go to **Environment > Advance Setting > Peak/Demand Set** and select a desired control type.

Editing Groups

The auto logic designates the registered devices as a group and controls them by group. The following explains how to create groups and how to edit the created groups.

Adding Groups

You can create a group as follows.

- 1. In the main menu, click the [AutoLogic > Peak Control] menu icons.
- 2. Click the [Edit Group] button.
 - The screen converts to Edit Group.
- 3. Click the [Add Group] button.

Notes

By clicking **[Apply default group]**, you can create a group automatically based on the group and indoor unit configuration set in the Device Management menu.

- 4. When the window to input a group name is displayed, enter a group name and click the **[Confirm]** button.
 - The group is added to the group list.

Apply default group			AHU AWAP	CHILLER DOKIT DO DI
ac III ⁰	Registered Unit (32)		4	
ac2	✓ 🍛 AC_UNIT_00			
ac3	AC_UNIT_01			
ac4	Group Name			
ac5	Input the group name.			
ac6	Cancel	Confirm		
ac7	AC_UNIT_05			
	✓ 🧼 AC_UNIT_06			
	V 🐼 AC_UNIT_07			
Add Group Rename Del Grou	P		Cancel	Apply
AutoLogic				PM 05:28

5. In the group list, click the group added in Step 4.

6. In the non-registered device area, click a device to add to the new group and click the [Add] button.

Apply default gro	up				IDU	ERV	AHU	AWH	CHILLER	DOKIT	DO	DI
AC UNIT	IIII	\checkmark	Regist	tered Unit (2)				\checkmark	Unregist	ered Ur	nit (1)	
group	1000	~		AC_UNIT_02				~		AC_UNIT	_03	
		~	4	AC_UNIT_06		Extra	Add act ▶					
Add Group Rename	Del Group						Can	cel			Aboly	
AutoLogi											PI	vi 04

• The selected device is moved to the registered device area.

Notes

Peak control is only limited to indoor devices, therefore you cannot register other devices such as the ventilator, AHU or AWHP.

7. To complete group creation, click the [Apply] button.

Changing Group Name

You can change the name of a registered group as follows.

- 1. In the main menu, click the [AutoLogic > Peak Control] menu icon.
- 2. Click the [Edit Group] button.
 - The screen converts to Edit Group.
- 3. In the group list, click a group whose name you want to change and click the [Rename] button.



- 4. Enter a new group name and click the [Confirm] button.
 - The group name is now changed.

Deleting Groups

You can delete a registered group.

- 1. In the main menu, click the [AutoLogic > Peak Control] menu icon.
- 2. Click the [Edit Group] button.
 - The screen converts to Edit Group.
- 3. In the group list, click a group to be deleted and click the **[Del Group]** button.

Apply default	group				iou	ERV	AHU	AWHP	CHILLER	DOKIT	DO	i) Di
AC UNIT	IIII	\checkmark	Regist	ered Unit (2)				\checkmark	Unregist	ered Ur	nit (1)	
group		~		AC_UNIT_0	2			× .	4	C_UNIT	r_03	
		\checkmark		AC_UNIT_0	6							
						٩	Add					
						Extr	act▶					
dd Group Renam	e Del Group						Can	cel	- Y			
		,										

- 4. When you are prompted to confirm the deletion, click [Confirm].
 - The selected group is deleted and the tab removed.



- The group configured in Peak Control is also applied to Demand Control.
- If you change the group configuration in the device management menu, the group configured in Peak Control is initialized.

Configuring Peak Control

You can configure Peak Control as follows.

- 1. In the main menu, click the [AutoLogic > Peak Control] menu icon.
- 2. Select the control status in the control configuration area.

Peak Co	ntrol	TimeLimitControl	InterLock	ling
GroupName	Priority	Operation Status Priority		
C UNIT	ШĽ	Operation	ShiftTime(M	/lin.)
CUNIT_2		Run Stop	•	5 ^
		Target ratio(%)		
				00
				99
		0 10 20 30 40 50 60 Current Runing(%)	70 80 90 100	
				02
				93
Edit Group	J		Cancel	Apply
AutoLo	ogic			PM 0

Number	Item	Description
1	Group List	Displays the device group list and group priority.
2	Control Configuration Area	 Configures Peak Control configuration and details. Operation Status Can be configured in [Environment > Advance Setting]. Priority Control: Control based on group priority Outdoor Unit Control: Controls based on outdoor unit capacity limit.

Number	Item	Description		
2	Control Configuration Area	 (Operation Status - Priority Control selected) Operation [Run] Button: Operates the device. [Stop] Button: Stops the operation of the device. Shift Time(Min.): Click [▲]/[▼] to set the time in minutes to force the operation to switch over. Target ratio(%): Click [▲]/[▼] or drag to set the target rate. Current Running(%): Displays the current rate. (Operation Status - Outdoor unit capacity control selected) Operation [Run] Button: Operates the device. [Stop] Button: Stops the operation of the device. Target ratio(%): Click [▲]/[▼] or drag to set the target rate. 		
3	[Edit Group] Button	Edit a control group.		
(4)	[Cancel] Button	Cancels control configuration.		
5	[Apply] Button	Applies control configuration.		

3. To complete configuration, click the **[Apply]** button.

Configuring Priority

- 1. In the main menu, click the [AutoLogic > Peak Control] menu icon.
- 2. In the group list, click the priority icon () of the group in question and then select a desired priority.

	Very High	
0	High	IIII
0	Normal	
0	Low	
0	Very Low	linit.

Notes

Basically, a newly added group has the highest priority. If a group is added, re-configure the priority for all groups.

Checking Peak Control Status

You can check the Peak Control configuration status as follows.

- 1. In the main menu, click the [AutoLogic > Peak Control] menu icon.
- 2. Check how Peak Control is configured.

Peak Co	ntrol	TimeLimi	itControl		InterLock	ing
GroupName	Priority	Operation Status	Priority			
AC UNIT		Operation			ShiftTime(N	Min.)
AC UNIT_2	IIIII	Run Stop	P		•	5 -
		1 arget ratio(%)	40 50 60	1 1 1 1 70 80		93
Edit Group		~		Cantel		Apply
AutoLo	ogic					PM 04:21

Item	Description				
	Configure Peak Controls.				
	Operation Status				
	 Can be configured in [Environment > Advance Setting]. 				
	- Priority: Controls based on group priority				
	 Outdoor unit capacity control: Controls based on outdoor unit capacity limit. 				
	(Operation Status - Priority Control selected)				
	Operation				
Control	- [Run] Button: Operates the device.				
Area	- [Stop] Button: Stops the operation of the device.				
	• ShiftTime(Min.): The cycle by which the operation switches over.				
	 Target ratio(%): Displays the target operation rate. 				
	 Current Running(%): Displays the current rate. 				
	(Operation Status - Outdoor unit capacity control selected)				
	Operation				
	- [Run] Button: Operates the device.				
	- [Stop] Button: Stops the operation of the device.				
	 Target ratio(%): Displays the target operation rate. 				

Checking Demand Control Status

You can check the Peak Control configuration status as follows.

- 1. In the main menu, click the [AutoLogic > Demand Control] menu icon.
- 2. Check how Demand Control is configured.



Number	ltem	Description			
1	Comm. Status with Demand Controller	Displays the communication status between demand controller and ACP BACnet.			
2	Control Configuration Area	 Checks the demand configuration details. Operation Status Can be configured in [Environment > Advance Setting]. Priority Control: Control based on group priority Outdoor Unit Control: Controls based on outdoor unit capacity limit. 			

Number	Item	Description
2	Control Configuration Area	 (Operation Status - Priority Control selected) Operation [Operate] Button: Operates the device. [Stop] Button: Stops the operation of the device. Shift Time(Min.): The cycle by which the operation switches over. Target ratio(%): Displays the target operation rate. Current Running(%): Displays the current rate. (Operation Status - Outdoor unit capacity control selected) Operation [Run] Button: Operates the device. [Stop] Button: Stops the operation of the device.

Time-limit Operation

The time-limit operation is to limit the amount of time the devices (indoor unit, ventilator, DOKITs, AWHP, and AHU) are running individually. By setting the device operation time in advance, you can control for how long a device works and have it stop automatically.

Editing Groups

The auto logic designates the registered devices as a group and controls them by group. The following explains how to create groups and how to edit the created groups.

Adding Groups

You can create a group as follows.

- 1. In the main menu, click the [AutoLogic > TimeLimitControl] menu icon.
- 2. Click the [Edit Group] button.
 - The screen converts to Edit Group.
- 3. Click the [Add Group] button.



By clicking **[Apply default group]**, you can create a group automatically based on the group and indoor unit configuration set in the Device Management menu.

- 4. When the window to input a group name is displayed, enter a group name and click the **[Confirm]** button.
 - The group is added to the group list.

Apply default group			Allo	AWHP CHILL	ER DOKIT DO	N N
	Registered Unit (0)			V Unreg		
				V @	AC_UNIT_00	
				V @	AC_UNIT_01	
	Group Name			< @	AC_UNIT_02	
	Input the group name,			v @	AC_UNIT_03	
	Cancel	Confirm		< @	AC_UNIT_04	
				V @	AC_UNIT_05	
				10	AC_UNIT_06	
				< 0	AC_UNIT_07	*
Add Group			Can	cel	Apply	
AutoLogic					F	M 05:32

- 5. In the group list, click the group added in Step 4.
- 6. In the non-registered device area, click a device to add to the new group and click [Add] button.
 - The selected device is moved to the registered device area.

Apply default group	Contraction (Contraction)	ERV AHU	AWHP CHILLER DOKIT DO DI
AC0~2~3	Registered Unit (4)		VInregistered Unit (5)
VENT	✓ 🧼 AC_UNIT_00		✓ 🐼 AC_UNIT_01
DX	VENT_UNIT_08		VENT_UNIT_00
AHU	✓ 💓 AHU00	◀ Add	AC_UNIT_10
DOKIT	✓ 🖥 AC_UNIT_11		V
AWHP		Extract >	V
group			
Add Group Rename Del Group		Car	icel Apply
AutoLogic			PM 04:35

Notes

For the time-limit operation, you cannot register DI/DO.

7. To complete group creation, click the [Apply] button.

Changing Group Name

You can change the name of a registered group as follows.

- 1. In the main menu, click the [AutoLogic > TimeLimitControl] menu icon.
- 2. Click the [Edit Group] button.
 - The screen converts to Edit Group.
- 3. In the group list, click a group whose name you want to change and click the [Rename] button.

	IDU	ERV AHU	AWHP CHILLES	R DOKIT DO DI
Registered Unit (4)			Vinregis	stered Unit (5)
✓ 🍛 AC_UNIT_00			√ 🍩	AC_UNIT_01
VENT_UNIT_08			< ⊕	VENT_UNIT_00
🗸 🐼 AHU00		▲ Add	× 8	AC_UNIT_10
✓ 🚺 AC_UNIT_11			✓ 創	AWHP_UNIT_01
		Extract ►	✓ 自	AWHP_UNIT_00
l.				
2		Can	icel	Apply
	Registered Unit (4) AC_UNIT_00 VENT_UNIT_08 AC_UNIT_00 AC_UNIT_01 AC_UNIT_01 AC_UNIT_02 AC_UNIT_03 AC_UNIT_04 AC_UNIT_05 AC_UNIT_11	Image: Point of the second s	Image: Note of the second se	IDU ERV ARW ANNP CHILLES Image: Registered Unit (4) Image: Chilles Image: Chilles Image: Chilles Image: Chilles Image: Chilles Image: Chilles Image: Chilles

- 4. Enter a new group name and click the [Confirm] button.
 - The group name is now changed.

Deleting Groups

You can delete a registered group.

- 1. In the main menu, click the [AutoLogic > TimeLimitControl] menu icon.
- 2. Click the [Edit Group] button.
 - The screen converts to Edit Group.
- 3. In the group list, click a group to be deleted and click the **[Del Group]** button.

Apply default group	200 100	ERV ARU	AWHP CHILLER DOKIT DO DI
AC0~2~3	Registered Unit (4)		Unregistered Unit (5)
VENT	✓ 🍛 AC_UNIT_00		✓ 🧼 AC_UNIT_01
DX	VENT_UNIT_08		VENT_UNIT_00
AHU	✓ 🐼 AHU00	◀ Add	AC_UNIT_10
DOKIT	✓ 🖥 AC_UNIT_11		AWHP_UNIT_01
AWHP		Extract >	V
group			
dd Group Rename Del Gr	oup	Can	cel Apply
AutoLogic			PM 04

- 4. When you are prompted to confirm the deletion, click [Confirm].
 - The selected group is deleted and the tab removed.
Configuring Time-Limit Operation

- 1. In the main menu, click the [AutoLogic > TimeLimitControl] menu icon.
- 2. In the group configuration status area, click a group to be controlled.
 - The device list, status information, and condition details of the group are displayed.

Peak Contro	ol	TimeLimitCont	rol			InterLocking			
roup List		Status in the group				(Condition		
GroupName	enable/disab	UnitName	UnitName Oper ToOff(Mi					_	
C0~2~3	disable	AC_UNIT_02	Stop	30		Run	Stop		
ENT	disable	AC_UNIT_03	Stop	30		Hours to Off(H	lour)		
x	disable	AC_UNIT_04	Stop	30		0.5 1	2 3	4	
HU	disable	AC_UNIT_05	Stop	30		Days			
OKIT	disable	AC_UNIT_06	Stop	30		🗸 Sun 🗸 I	Mon 🗸 Tue 🗸	Wed	
WHP	disable	AC_UNIT_07	Stop	30		🗸 Thu 🗸	Fri 🗸 Sat		
		AC_UNIT_08	Stop	30	-				
		~	1. 17						
Edit Group					Cance	el	Apply		
AutoLogic								P	

3. Select the control status in the conditions configuration area.

Item	Description
Oper	 Choosing whether to run Time-Limit Operation [Run] Button: Run the time-limit operation. [Stop] Button: Stops the time-limit operation.
Hours to Off(Hour)	 Select the operation time limit of an operation group. The devices included in the group operates for the selected time then stops automatically.
Days	Select a day on which to run the time-limit operation.

4. To run the time-limit operation on the group, in the group configuration operation status area, click the **[disable]** button.

Peak Cont	rol	TimeLimitCon	trol			InterL	ocking		
Group List		Status in the group				Condition			
GroupName	enable/disab	UnitName	Oper 1	ToOff	(Min)	Oper			
AC0~2~3	enable	AC_UNIT_02	Stop	30	*	Run	Stop	-	
VENT	disable	AC_UNIT_03	Stop	30		Hours to Off(He	our)		
DX	disable	AC_UNIT_04	Stop	30		0.5 1	2 3	4	
AHU	disable	AC_UNIT_05	Stop	30		Days			
DOKIT	disable	AC_UNIT_06	Stop	30		🗸 Sun 🗸 M	lon 🗸 Tue 🗸	Wed	
AWHP	disable	AC_UNIT_07	Stop	30		V Thu V	ri 🗸 Sat		
		AC_UNIT_08	Stop	30	+				
		~							
Edit Group					Cance	el	Apply		
AutoLog	c						р	M 04:4	

• The button changes to [enable].

5. To complete the configuration, click the [Apply] button.



If you change the operation stop standby time, it takes about 15 seconds to apply it.

InterLocking

You can integrate the system with external devices, like fire alarms, to halt the operation of all indoor units and ventilators. For InterLocking, you should create a pattern for devices and apply the control configuration. The following explains how to create and manage a pattern and control device integration.

Managing Pattern

The following explains how to register integrated devices as a pattern and how to modify or delete a registered pattern.

Adding Pattern

You can add a pattern as follows.

- 1. In the main menu, click the [AutoLogic > InterLocking] menu icon.
- 2. Click the [Add] button.
 - · A window to create a pattern is displayed.
- 3. Type a new pattern name in the pattern name input window.

Input Device (0) (Dutput	Device (0)	Cor	nd, AN	0 0	R	IDU	ERV	AHU	AWHP	CHILLER	DOKIT	DO	DI
×		Unit N	lame			Ad	dress				Unre	gistere	ed Units	(259)	
										\checkmark		Unit N	ame	Add	ress
								4	Add	V		AC_U	UNIT_00	00	
		3	No Device						Auu	~		AC_U	JNIT_01	01	110
										\checkmark	۲	AC_U	JNIT_02	02	
									drect	\checkmark		AC_U	UNIT_03	03	
Oper	Settemp(*	C)	Mode							\checkmark		AC_U	JNIT_04	04	
ON OFF			COOL	HEAT	AUTO	DRY	FAN			\checkmark	63	AC_U	INIT_05	05	v
			Lock							-			1	20 74	_
FROOD			Total	Mo	de T	emper.	Ean				Cance	el			

4. Click the [Input Device] tab.

Input	Device ((0)	Output	Device (0)	Cor	nd, AN	0 0	R	IDU	ERV	AHU /	WHP	CHILLER	DOKIT	DO	DI
×			Unit N	lame			Ad	dress				Unre	gister	ed Units	(99)	
											\checkmark		Unit Na	ame	Add	ress
										Add	~		AC_U	INIT_00	00	
			1	No Device					C	Auu	~	0	AC_U	INIT_01	01	
											~		AC_U	INIT_02	02	
										dract.	\checkmark	-	AC_U	INIT_03	03	
Oper		Settemp	(℃)	Mode					1		\checkmark	-	AC_U	NIT_04	04	
ON	OFF			COOL	HEAT	AUTO	DRY	FAN			~	63	AC U	INIT 05	05	v
				Look							-	-		1		-
	and		v	Total	Mor	ie Te	mner	Fan				Cance	al			

5. In the non-registered device area, click a device to be registered and click the [Add] button.

- 6. In the input device list, click the device you want to control.
- 7. Select a control status in the control configuration area.
- 8. Click the [Output Device] tab.
- 9. In the non-registered device area, click a device to be registered and click the [Add] button.

			D (0)	1				42		<i>z.</i>]	相	ē.	181	50	0
Input Device ((0)	Jutput	Device (3)	Con	d. ANI	0 0	R	IDU	ERV	AHU	AWHP	CHILLER	DOKIT	DO	DI
×		Unit N	lame			Ad	dress				Uni	egister	ed Units	(96)	
🗸 🍩 AC	UNIT_00						00			\checkmark		Unit N	ame	Add	ress
🗸 🧼 AC	_UNIT_01						01		Add			AC_L	INIT_03	03	
🗸 🍩 AC	UNIT_02						02		Huu	J 🗸		AC_U	INIT_04	04	
								1		V		AC_L	INIT_05	05	
								Ex	tract P	~		AC_U	INIT_06	06	
Oper	Settemp(C)	Mode							\checkmark		AC_U	INIT_07	07	
ON OFF			COOL	HEAT	AUTO	DRY	FAN			V	63	AC L	INIT 08	08	v
			Lock							-	-	1000	10000-0000	1 2252	-
		۳	Total	Mod	ie Te	mper,	Fan	1			Cano	el			

- 10. In the output device list, click the device you want to control.
- 11. Select a control status in the control configuration area.
- 12. To complete the adding of a pattern, click the [Apply] button.

Editing Pattern

You can edit a pattern as follows.

- 1. In the main menu, click the [AutoLogic > InterLocking] menu icon.
- 2. Select a pattern and click the [Edit] button.
 - The pattern editing screen opens.
- 3. Modify the pattern configuration information and click the [Apply] button.

Deleting Pattern

You can delete a pattern as follows.

- 1. In the main menu, click the [AutoLogic > InterLocking] menu icon.
- 2. Select a pattern to be deleted and click the [Delete] button.
- 3. When you are prompted to confirm the deletion, click [OK].
 - · The selected pattern is deleted.

Checking InterLocking

- 1. In the main menu, click the [AutoLogic > InterLocking] menu icon.
- 2. Click a pattern for which you want check the device integration.
 - The device integration status for the pattern is displayed.

	Peak Cor	ntrol		TimeLimit	Control	InterLock	ting
Pat	tern			Input Device (1)			
No	Pattern Name	enable/disa		Unit Type	UnitName	Address	Operation
1	a	disable		IDU	AC_UNIT_06	06	©
2	8888	enable					
3	bbb	enable					
4	ccc	enable	•	Output Device (1)			
5	ddd	enable		IDU	AC_UNIT_07	07	0
6	eee	enable					
	Add Edit	Delete					
-	AutoLo	gic					PM 04:5

Statistics

The following explains how to use statistics and graphs to check the power consumption and operation time of a device.

Statistics Screen Composition and Features

The following explains the statistics screen composition and features.

1	2	(3		(4) (i
tatistics	Power Ru	InTime Monthly	Daily	2013-3-25	~ 2013-3-3
All Group				Date	Usage
ac1				2013,03,25	1065,3 kWh
N.82				2013,03,26	22,6 kWh
ac2				2013,03,27	0,0 kWh
ac3				2013,03,28	0,0 kWh
				2013,03,29	235,6 kWh
ac4	-			2013,03,30	40,9 kWh
				2013,03,31	0.0 kWh
ac5					
ac6	2013,03,25 2013,03,31 Power Consumption	(kWh)			
	Period Usage	Daily Average	Total		
	1364,4	194,9	1364.4],	
Table Initial Date	25.		Email	The second se	Save to USB.
					DALO

Number	Item	Description
1	Group List	Displays the device group list.
2	Statistics Items	 [Power] Button: You can check the power consumption of each group and total power consumption. [RunTime] Button: You can check the operating time and the total operating time of indoor units in each group.
3	Query Unit	 [Monthly] Button: Queries on monthly consumption within the last four months. [Daily] Button: Queries on daily consumption within the query period.

Number	Item	Description
(4)	Query Period Selection Area	 Selects the period for which you want to query statistics details for daily. The start date should be no more than 31days before the end date.
(5)	Displays Statistics Information	 Statistics data per period: Displays power consumption per unit of query or operation time statistics and graphs. Power consumption: Displays power consumption and use time.
6	[Table]/[Graph] Button	 Converting Statistics Data View Table: Views the queried statistics data in a table format. Graph: Views the queried statistics data in a graphic format.
7	[Initial Date] Button	 Selects Statistics Reference Date. Move to Settings > General Settings > Statistics Reference Date.

Querying Statistics

You can query the power consumption of a device or operation time statistics data as follows.

- 1. In the main menu, click the [Statistics] menu icon.
- 2. Click the device group you want from the group list.
- 3. Click the button of the statistics item you want.
 - [Power] Button: You can check the power consumption of each group and total power consumption.
 - [RunTime] Button: You can check the operating time and the total operating time of indoor units in each group.
- 4. In the query period selection area, click the date button and [+]/[-] button to select the desired period.
 - The start date should be no more than 31days for daily before the end date. The query period for monthly is automatically fixed to the last four months.

5.	Check the	statistics	details	in the	statistics	information	display	area.
----	-----------	------------	---------	--------	------------	-------------	---------	-------

• To change the statistics information view type, click the [Table] or [Graphic] button.

Statistics		Power	RunTime	Monthly	Daily	2013-3-25	~ 2013-3-3
All Group]					Date	Usage
ac1						2013,03,25	1065,3 kWh
						2013.03.26	22.6 kWh
ac2	1					2013,03,27	0.0 kWh
						2013,03,28	0,0 kWh
aco						2013.03.29	235.6 kWh
ac4						2013,03,30	40.9 kWh
						2013,03,31	0,0 kWh
ac5	1						
ac6	2 P	013,03,25 2013,0 ower Consumpt	3,31 ion (kWh)				
		Period Usage	Daily	Average	Total		
		1364.4	1 18	194,9	1364.4	1,	
Table	Initial Date 25.						
Ctobio	ting						PM 04

Notes

The statistics data is stored up to 6 months.



- Devices which can query the Run Time: Indoor units
- Devices which can query the Power consumption: devices which can be used with the PDI (For further information about the devices can be used with the PDI, please refer to the PDI manual.)

Report

The following explains how to query the device control information or error information.

Report screen composition and features

The following explains the report screen composition and features.

	Date	Time	UnitName	Code	Detail Information
2	013-03-21	15:45:22	NONAME	_ м	TimeLC Setting
2	013-03-21	15:43:36	NONAME	Ш м	Peak/Demand Setting
2	013-03-21	15:41:36	NONAME	Ш м	System Setting
2	013-03-21	15:29:36	NONAME	Ш М	Group Setting
2	013-03-21	15:26:58	NONAME	П м	Group Setting
2	013-03-21	14:41:02	AC_UNIT_F1	覡 S	COOL/18.0/ON by USER
2	013-03-21	13:38:33	NONAME	М []	Group Setting
2	013-03-21	13:38:24	NONAME	Ш м	Group Setting
elete l	Report				Send Email Save to USB

Number	Item	Description
D	Report Items	 Selects report query items. [Total] Button: Queries all reports regarding control and error. [Control] Button: Queries control related reports only. [Error] Button: Queries error related reports only.
2	Query Period Selection Area	Selects the period for which you want to query report details.The starting date should be no more than three months from the ending date.
3	Report detail display area	Displays the reports related to control and error.
4	[Delete Report] Button	Deletes the selected report.

Querying Report

You can query the device control or error report as follows.

- 1. In the main menu, click the [Report] menu icon.
- 2. In the report item, click an item for which you want to query a report.
 - [Total] Button: Queries all reports regarding control and error.
 - [Control] Button: Queries control related reports only.
 - [Error] Button: Queries error related reports only.
- 3. In the query period selection area, click the date button and [+]/[-] button to select the desired period.
 - The starting date should be no more than three months from the ending date.
- 4. Check the report details in the report detail display area.

Repo	ort			Total	Control	Error	2013.03.21	~	2013.03.21		
\checkmark	Date	Time	UnitName	Code		Detail Information					
~	2013-03-21	15:45:22	NONAME	_ м	TimeLC Setting						
\checkmark	2013-03-21	15:43:36	NONAME	М []	Peak/Dema	and Setting					
~	2013-03-21	15:41:36	NONAME	Ш м	M System Setting						
\checkmark	2013-03-21	15:29:36	NONAME	П м	Group Setti						
\checkmark	2013-03-21	15:26:58	NONAME	М []	Group Setting						
\checkmark	2013-03-21	14:41:02	AC_UNIT_F1	🖷 S	COOL/18.0,	/ON by USER					
V	2013-03-21	13:38:33	NONAME	П м	Group Setti	ng					
\checkmark	2013-03-21	13:38:24	NONAME	М []	Group Setting						
Dele	ete Report										
ŧ	Repo	ort							AM 10:1		



You can query up to 200 reports. Up to 5000 reports are stored.

Installing

You can add a device or change the settings of a registered device.

Registering Device

After installing ACP BACnet, log into ACP BACnet to register the devices to be connected.

ACP BACnet can register a device by using one of two methods.

- · Registering Device Automatically
- · Registering Device Manually



To register a device on ACP BACnet, you should login with administrator permissions. If you have logged in already with standard user permissions, you cannot proceed with this process any further.

Registering Device Automatically

Devices connected to ACP BACnet are automatically searched for and registered. You can register a device automatically as follows.

- 1. In the main menu, click the [Installing] menu icon.
- 2. Click the [Installing] tab.
- 3. Click the [Auto Search] button.

Grouping	Inst	talling		CO IDU	ERV	AHU	AWHP	CHILLER	DOKIT	DO) D
DeviceType	Unit Name	e(20 Characters)	Addre	ss(00~FF)	Model(20 Ch	aracters)		Capacity			
ODU 🔻	Unit Nor		Add	uss	Mode)	Mode)				Ins	ert
Unit Statu	IS	DeviceType	Unit Na	me	Addr	/Port	3	Model		Capa	city
Total Unit 1 ODU 2 IDU 2 ERV 3 ERV 4 ERV 0 AHU 4 AWHP 2	130 2 ODU ODU[00] 40		ODU[00]	00		MULTIV			100		
	39 1	ODU	ODU[01]		01 MULTIV			100			
	2 40	IDU	AC_UNIT_03	03		AC AC			3		
CHILLER DOKIT	0 2 2	IDU	AC_UNIT_04k					3			
DI	2	IDU	AC_UNIT_05		0	5		AC		3	
Auto Searc	h	IDU	AC_UNIT_06		0	6		AC		3	٣
V IDU Addres	s Lock										
e	Installing									р	M 02:0

- 4. When you are prompted to confirm the setting, click [Confirm].
 - It takes 5 to 10 minutes to register a device automatically.

uto dearchi	
Find out the Auto Search will tal and installing information will be Before do this, please dias Do γου wan	connected unit ke about 5-10 minutes e replace with searched information bie the screen naver function, it to continue?

- 5. To save the searched devices, touch the [Apply] button.
 - Device registration is completed. 2 DIs and 2 DOs is always added to the Unit Status.

Registering Device Manually

Devices connected to ACP BACnet can be registered by the user by entering relevant information. You can register a device manually as follows.

- 1. In the main menu, click the [Installing] menu icon.
- 2. Click the [Installing] tab.
- 3. Type the device information and click the [Insert] button.

Grouping	Inst	talling	0	ERV AHU	AWHP CHILLER DOKIT	00	DI						
DeviceType	Unit Nam	e(20 Characters)	Address(00-FF)	Model(20 Characters)	Capacity	Inse	rt						
ODU 🔻	Unit Na	me	Address	Model	Capacity	in ac							
Unit State	us	DeviceType	Unit Name	Addr/Port	Model	Capaci	ty						
ODU IDU	2 40	ODU	ODU[00]	00	MULTIV	100							
ERV ERV DX	39 1	ODU	ODU[01]	01	MULTIV	100							
AHU AWHP	2 40 0 2	2 40 0 2	2 40 0 2	2 40	2 40	2 40	2 40	IDU	AC_UNIT_03	03	AC	3	
DOKIT				IDU	AC_UNIT_04k	04	AC	3					
DI	2	IDU	AC_UNIT_05	05	AC	3							
Auto Sear	ch	IDU	AC_UNIT_06	06	AC	3	•						
V IDU Addres	ss Lock												
ê II	Installing					PM	1 02:0						

Item	Description
Device Type	 Selects a device type. IDU(indoor unit,), ODU(Outdoor unit,), ERV(Energy Recovery Ventilator), ERV DX(Direct Expansion Energy Recovery Ventilator), DI/DO, DOKIT, AWHP, or AHU
Unit Name (20 Characters)	Enter the device name. • Up to 20 characters.
Address (00- FF)	 Type the physical address of the device. A physical address value is a number between 00 and FF. You cannot type the same value for the same device. You cannot enter a duplicate value for indoor devices and DOKIT.
Model (20 Characters)	Type the device model. Up to 20 characters.
Capacity (5-digit)	Type the maximum power consumption of the device.Up to 5 characters.The power consumption value of the actual device cannot exceed the input value.

- 4. To save the device, click the [Apply Change] button.
 - Device registration is completed.

Changing Device

You can change the settings of registered devices.

- 1. In the main menu, click the [Installing] menu icon.
- 2. Click the [Installing] tab.
- 3. Click a device to be changed in the device list.
 - The device information is displayed in the device information input box.
- 4. Type the device information and click the [Modify Unit] button.
 - The changed device information is applied.
- 5. To save a change, click the [Apply] button.

Deleting Device

Follow these steps to delete a device from the list.

- 1. In the main menu, click the [Installing] menu icon.
- 2. Click the [Installing] tab.
- 3. In the device list, click a device to be deleted and click the [Del Unit] button.
- 4. When you are prompted to confirm the deletion, click [Confirm].
 - · The selected device is deleted from the list.
- 5. To save a change, click the [Apply] button.

Managing Device

The following explains how to manage the information for a device added to the system.

Adding Groups

Follow these steps to add a new group.

- 1. In the main menu, click the [Installing] menu icon.
- 2. Click the [Grouping] tab.
- 3. Click the [Add Group] button.
- 4. When the window to type a group name is displayed, enter a group name and click the [Confirm] button.
 - The group is added to the group list.

Grouping Installing			AHL	AWHP CHELER	
ac	Registered Unit (32)			V Unregist	teres Unit (0)
dio	✓ 🍛 AC_UNIT_00				
ac2	V 🐼 AC_UNIT_01				
ac3	Group Name				
ac4					readered unit
ac5	Cancel	Confirm			nogistes dint.
ac6	AC_UNIT_05				
ac7	✓ 🧼 AC_UNIT_06				
	✓ 🧼 AC_UNIT_07				
Add Group Rename Del Grou	p		Canc	el	Apply
nstalling					PM 05:41

5. In Grouping, click the group added in Step 4.

6. In the non-registered device area, click a device to add to the new group and click the [Add] button.

Grouping	mataning				UCI	ERV	AHU	AWH	P CHILLE	R DOKIT	DO DI
AC UNIT			Regis	tered Unit (12)				\checkmark	Unregi	istered Ur	uit (4)
VENT		\checkmark		AC_UNIT_00				V		AC_UNI	r_04
VENT_2		\checkmark		AC_UNIT_01				V	٩	AC_UNI	r_06
DXHRV		\checkmark		AC_UNIT_02		4	Add	\checkmark		AC_UNI	r_07
AHU		\checkmark	۲	AC_UNIT_03				\checkmark		AC_UNI	ſ_08
AC UNIT_2		\checkmark		AC_UNIT_05		Ext	ract 🕨				
AWHP		\checkmark	۲	AC_UNIT_09							
		\checkmark		AC_UNIT_0A							
		\checkmark		AC_UNIT_0B	•						
Add Group Ren	ame Del Group	p				-	Car	ncel			Aboly

• The selected device is moved to the registered device area.

- 7. To complete group creation, click the [Apply] button.
 - When all non-registered devices are registered, the [Apply] button is enabled.

Changing Group Name

You can change the name of a registered group as follows.

- 1. In the main menu, click the [Installing] menu icon.
- 2. Click the [Grouping] tab.
- 3. In the device management list, click a group whose name you want to change and click the **[Rename]** button.

Grouping	Installing					iou	1	ERV	AHU	AWH	CHILLE	R DOKIT	DO	() D
AC UNIT		\checkmark	Regis	tered U	nit (12)					\checkmark	Unreg	stered U	nit (4)	
VENT		\checkmark		AC_U	NIT_00	4	•			\checkmark	0	AC_UNI	T_04	
VENT_2		\checkmark		AC_U	NIT_01					\checkmark		AC_UNI	T_06	
DXHRV		\checkmark	-	AC_U	NIT_02			۹.	Add	\checkmark		AC_UNI	T_07	
AHU		\checkmark		AC_U	NIT_03	-				\checkmark		AC_UNI	T_08	
AC UNIT_2		\checkmark		AC_U	NIT_05			Extr	act▶					
AWHP		\checkmark		AC_U	NIT_09									
		\checkmark		AC_U	NIT_0A									
		\checkmark		AC_U	NIT_0B	-								
dd Group	ame Del Group	p							Car	icel				
III Ins	stalling												PA	vi 05

- 4. Enter a new group name and click the [Confirm] button.
 - The group name is changed.

Deleting Groups

You can delete a registered group.

- 1. In the main menu, click the [Installing] menu icon.
- 2. Click the [Grouping] tab.
- 3. In the device management list, click a group to be deleted and click the **[Del Group]** button.

AC UNIT	V Registered Unit (12)			Unregistered Unit (1)
VENT	✓			✓ 🧼 AC_UNIT_04	1
VENT_2	✓ ▲ AC_UNIT_01			✓ 🧼 AC_UNIT_0€	3
DXHRV	✓ 🍛 AC_UNIT_02		◀ Add	✓ 🧼 AC_UNIT_07	
AHU	✓ 🍛 AC_UNIT_03	=		V AC_UNIT_OF	5
AC UNIT_2	✓ 🍛 AC_UNIT_05		Extract ▶		
AWHP	✓ 🧼 AC_UNIT_09				
	V 🍛 AC_UNIT_OA				
	V SAC_UNIT_OB	*			
dd Group Rename	Del Group		Car	ncel	

- 4. When you are prompted to confirm the deletion, click [Confirm].
 - The selected group is deleted and the tab removed.

Environment

The following explains how to configure the system environment for user convenience and how to check an already configured environment.

General Setting

The following explains how to configure the general system environment.

General Setting	General Setting	
Advance Setting	Language English	
Customer Setting	Time setting AM 10:05	
	Date setting 2013,04,08	
	Temperature display Celsius (°C)	
	Initial date for statistics	
	Rates per 1kWh 100 USD	
	Holiday setting (The day schedule is not work) Holiday setting (The day schedule is not work)	
	Version Information Ver.3.0.2t	
Environment		AM 10:05

ltem	Description
Language	Configures the language displayed on the screen (한국어(Korean)/ English).
Time setting	Configures system time.
Date setting	Configures system date.
Temperature display	Configures the temperature system.
Initial date for statistics	Configures the reference date for querying statistical data.
Rates per 1kWh	Configures the charge per 1kWh and currency.
Holiday setting (The day schedule is not work)	Selects the days for which schedules are not be applied.
Version Information	Checks the current software version.

Language

Configures the language displayed on the screen.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the settings list, click General Setting.
- 3. In the detailed settings list, click Language.
- 4. Click a language you want.
 - The selected language is applied as the system language.

Langu	age
۲	한국어(Korean)
۲	English
-	Cancel

Time setting

You can configure the time used for the system as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click General Setting.
- 3. In the detailed settings list, click **Time setting**.
- 4. Apply the current time and click the [Apply] button.
 - Click [+]/[-] button to select the time.
 - Click the [AM]/[PM] button to select before or after midday.

+	+	
05	15	PM
-	-	

Date setting

You can configure the date used for the system as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click General Setting.
- 3. In the detailed settings list, click **Date setting**.
- 4. Modify the pattern configuration information and click the [Apply] button.
 - Use [+]/[-] button to select a date.

						2012.12			
Year	Month	Date	Sun	Mon	Tue	Wed	Thu	Fri	Sat
+	+	+							1
2012	10	05	2	3	4	5	6	7	8
2012	IZ	00	9	10	11	12	13	14	15
-	-	-	16	17	18	19	20	21	22
			23	24	25	26	27	28	29
			30	31					

Temperature display

You can select a temperature system as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click General Setting.
- 3. In the detailed settings list, click Temperature display.
- 4. Click the temperature system you want.
 - When selecting the Celsius system, in the Minimum Celsius(°C) Temperature window, click the minimum temperature.

	-
Celsius (°C)	۲
Fahrenheit(°F)	•
Fahrenheit("F)	0

Initial date for statistics

Statistics Reference Date is the date for calculating the indoor unit's operation time by month. The operation time from this date through the previous date to the same date of the next month is calculated and provided as statistical data. You can configure Statistics Reference Date as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click General Setting.
- 3. In the detailed settings list, click Initial date for statistics.
- 4. [+]/[-] button to select a date you want and [Apply] button.

+	
25	

Rates per 1kWh

You can configure the charge per kWh and the currency as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click General Setting.
- 3. In the detailed settings list, click Rates set.
- 4. Configure the charge/kWh configuration information and click [Apply] button.
 - rates per(1kWh): Charge per 1kWh.
 - Currency: Click [▼] button to select the desired currency.

Rates set		
rates per (1kWh)	1	
Currency	USD	◄
C	ancel	Apply

Holiday setting(The day schedule is not work)

The following explains how to register an exception date or how to delete a registered date.

Adding Exception Date

You can add a desired exception date as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click General Setting.
- 3. In the detailed settings list, touch Holiday setting(Days in which the schedule is ignored).
 - The Exception Date Configuration window opens.

nonday Name	Date		
Please enter holiday	12/25	Christmas	
Month Date			
+ +			
04 16			
Add			Delete

- 4. Type a name for the exception date in the exception date input box.
- 5. [+]/[-] button to select an exception date.
- 6. To add the selected exception date, click [Add].
 - The exception date is registered on the exception date list.
- 7. To complete Exception Date Configuration, click the [Apply] button.

Deleting Exception Date

You can delete a registered exception date as follows.

- 1. In the main menu, click the [Environment]menu icon.
- 2. In the Settings list, click General Setting.
- 3. In the detailed settings list, touch Holiday setting(Days in which the schedule is ignored).
 - · The Exception Date Configuration window opens.

Holiday Name		Date		
Please enter	holiday	12/25	Christmas	
Month	Date			
+	+			
04	16			
_	_			
	Add			Delete

- 4. Click an exception date in the exception date list, and click the [Delete] button.
- 5. To complete Exception Date Configuration, click the [Apply] button.

Version Information

You can check the current version of the software as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click General Setting.
- 3. In the detailed settings list, click Version Information.
 - The current version of the system is displayed in a popup window.

Versio	on Inf	ormation
		Ver.3.0.2t Copyright © 2012 LG Electronics Inc.
		Confirm

Advance Setting

The following explains how to configure the functions necessary for device operation.

General Setting	Advance Setting	
Advance Setting	Set Interlocking	
Customer Setting	LGAP setting Master	
	Peak / Demand set	
	Peak / Demand set Demand control	
	Set the operation mode Priority	
	Temperature limit setting	
	Temperature difference for Setback/AutoChangeOver 0.5°C	
	Update S/W	
	Update S/W System update for new Software	*
n Environment		AM 10:09

Item	Description
LGAP setting	 Master: ACP BACnet must be set to only master. Slave: Not used.
Peak/Demand set	 Peak Control: You can use the peak control feature in the auto logic menu. Demand Control: You can use the demand control feature in the auto logic menu.
Set the operation mode	 Priority Control: In Peak/Demand Control menu, control the devices based on the priority of the group. Outdoor Unit Capacity Control: In the Peak/Demand Control menu, control the outdoor capacity rate per unit.
Temperature difference for Setback/ AutoChangeOver	[+]/[-] button to select the temperature gap.
Update S/W	Software upgrade using a USB memory stick.Complete upgrade and restart the system.
DB backup	Backup the DB onto a USB memory stick.
Recovery DB	Use the DB stored on the USB memory stick to restore the system.

LGAP setting

ACP BACnet can interface with another central controller to control a device. You can configure the interface type with other devices as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click Advance Setting.
- 3. In the detailed settings list, click LGAP setting.
- 4. Click a type you want.
 - Master: ACP BACnet must be set to only master.
 - · Slave: Not used.

Master	۲
Slave	0

Peak/Demand set

You can select a control type to be used for auto logic.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click Advance Setting.
- 3. In the detailed settings list, click Peak/Demand set.
- 4. Click a control type to be used for auto logic
 - Peak Control: You can use the peak control feature in the auto logic menu.
 - Demand Control: You can use the demand control feature in the auto logic menu.

Peak / Demand set	
Peak control	•
Demand control	۲
Cancel	

Set the operation mode

You can configure the operation type as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click Advance Setting.
- 3. In the detailed settings list, click **Set the operation mode**.
- 4. Click an operation type you want.

Set the operation mode	
Priority	۲
Outdoor unit capacity control	•
Cancel	

Temperature difference for Setback/AutoChangeOver

You can configure the temperature gap for auto changeover operation.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click Advance Setting.
- 3. In the detailed settings list, click Temperature difference for Setback/AutoChangeOver.
- 4. [+]/[-] button to select a temperature gap you want and [Apply] button.

+	
0.5	°
-	

Update S/W

You can upgrade the current version of software as follows.

Notes

To update the software, you need a USB memory stick which has patch.tar file in the ramdisk folder.

- 1. Connect the USB memory to ACP BACnet.
- 2. In the main menu, click the [Environment] menu icon.
- 3. In the Settings list, click Advance Setting.
- 4. In the detailed settings list, click Update S/W.
- 5. When the software update window appears, click the [Update S/W] button.
 - When the update has been completed, the program restarts.

You can be updated this de First, Insert a USB memory stic	evice using a USB memory stick. ck, then Press [S/W Update] button
At the last, restart the syste	em arter the update is completed.
At the last, restart the syste	em arter the update is completed.

DB backup

You can backup the database stored in the system to USB memory as follows.

- 1. Connect the USB memory to ACP BACnet.
- 2. In the main menu, click the [Environment] menu icon.
- 3. In the Settings list, click Advance Setting.
- 4. In the detailed settings list, click **DB backup**.
- 5. When the DB Backup window appears, click the [DB backup] button.

В васкир	
To store database	e to the USB momory,
Please press the button 'D m	B backup' after connecting USB emory



You can use the database stored on USB memory to restore the system database.

- 1. Connect the USB memory stick to ACP BACnet.
- 2. In the main menu, click the [Environment] menu icon.
- 3. In the Settings list, click Advance Setting.
- 4. In the detailed settings list, click Recovery DB.
- 5. When the DB Recovery window appears, click the [Recovery DB] button.
 - When the DB recovery has been completed, the program restarts.

Recovery DB	
Recovery the device using the Press the DB recovery button afte will be restarted after t	database stored on a USB memory er connecting USB memory . The syste the DB recovery is complete.
Cancel	Recovery DB

Customer Setting

Only the administrator account can change user environments.

General Setting	Customer Setting	
Advance Setting	Default	
Customer Setting	Change Password system_admin Change Password	
	Add user Add Administrator/User	
	User Management	
	User_1 ac1,ac2,ac3	Delete Edit
	system_admin1 ac6	Delete Edit
Environment		AM 10:

Item	Description
Change Password	Only the administrator account can change the password.
Add user	Add up to 30 new system users.
User Management	 [Delete] Button: Deletes a user. [Edit] Button: Changes user information.

Change Password

The administrator account can change a password as follows.

- 1. In the main menu, click the **[Environment]** menu icon.
- 2. In the Settings list, click Customer Setting.
- 3. In the detailed settings list, click Change Password.
- 4. After entering the current and new passwords, click [Confirm].
 - Current P/W: Enter the current password.
 - New P/W: Enter the new password a user desires.
 - Re-type P/W: Enter the new password to confirm that the new password has been entered correctly.

Current P/M	Please enter a nassword	
Guildhur744		a a password.
New P/W	Please entr	er a password,
Re-type P/W	Please ente	er a password,
Can	cel	Confirm

Add user

You can add a user as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click Customer Setting.
- 3. In the detailed settings list, click Add User.
- 4. When the system password input window appears, enter the password and click [Confirm].

Add user	
To add a user, the system par Enter the system password.	ssword is required.
Please enter a password	

- 5. When the Add a New User window appears, enter the user information and click [Confirm].
 - ID: Enter the user's ID for the email server.
 - Password: Enter the login password.
 - **Password 'Confirm'**: Re-enter the password.
 - · User Role: Select the user permission you want
 - Accessable Group: Select a controllable device group

Group (7)	
V AC UNIT	
VENT	
VENT_2	
V DXHRV	
V AHU	
	AC UNIT VENT VENT_2 DXHRV AHU



Notes

Use is limited depending on the user.

- · General user menu: auto logic, report, device configuration, settings
- · Administrator menu: Environment Configurations

User Management

The following explains how to delete a registered user or edit user information.

Deleting User Information

You can delete a registered user's information as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click Customer Setting.
- 3. In the user list, click the [Delete] button for the user information you want to delete.

General Setting	Customer Setting	
Advance Setting	Default	
Customer Setting	Change Password system_admin Change Password	
	Add user Add Administrator/User	
	User Management	
	User_1 acl,ac2,ac3	Delete Edit
	system_admin1 ac6	Delete Edit
Environment		AM 10

- 4. When the system password input window appears, enter the password and click [Confirm].
 - The user information is deleted.

Delete user	
To delete a user, the system Enter the system password.	password is required.
Please enter a password	
Cancel	Confirm

5. To complete user delete, click [Confirm].

Editing User Information

You can edit a registered user's information as follows.

- 1. In the main menu, click the [Environment] menu icon.
- 2. In the Settings list, click Customer Setting.
- 3. In the user list, click the [Edit] button for the user information you want to edit.

Advance Setting			
Rovance Setting	Default		
Customer Setting	Change Password system_admin Change Password		
	Add user Add Administrator/User		
	User Management		
	User_1 ac1,ac2,ac3	Delete	
	system_admin1 ac6	Delete Edit	
Environment		AM	

4. When the system password input window appears, enter the password, click [Confirm].



5. When the Edit User window appears, enter the user information and click [Confirm].The updated user information is applied.

ID	Accessable Group
User_1	Group (6)
Password	✓ ac1
Please enter a password. Modify	✓ ac2
	✓ ac3
User Role	✓ ac4
User	✓ ac5_
Administrator	✓ ac6

6. To complete user edit, click [Confirm].
Installing ACP BACnet

Installing ACP BACnet

This chapter describes how to install the ACP BACnet to use.

In order to use the ACP BACnet, the installation should be performed by the following order.

STEP 1. Check the cautions during the ACP BACnet installation Before installing the ACP BACnet, check the cautions.

STEP 2. Study the cable connections diagram of the entire system Study the cable connection diagram of the site where the ACP BACnet is installed.

STEP 3. Set the indoor unit address Set the address of the ACP BACnet not to be overlapped with the connecting indoor unit.

STEP 4. Set PI485 and connect cables Set DIP switch of PI485 correctly, and connect RS-485 communication cable.

STEP 5. Install ACP BACnet and connect cables Install the ACP BACnet, and set network and other settings.

STEP 6. Set ACP BACnet network address Set the network address to be able to access the ACP BACnet through internet.

STEP 7. Set ACP BACnet functions Set language, peak/demand, whether to use schedule, whether to use power display, etc.

STEP 8. Set Web GUI access environment Set the access environment in Web GUI, which is the operation program of the ACP BACnet.

STEP 9. Input indoor unit and ventilator information Set the access environment in Web GUI, which is the operation program of the ACP BACnet.

STEP 10. Verify and check ACP BACnet installation Verify and check whether the ACP BACnet is properly installed.

Caution

Installing the ACP BACnet

- The ACP BACnet installation work needs the professional technique. Therefore, the installation described in this chapter should be performed by the certified installation professional.
- Consult the service center or the professional installation agency certified by us about any question or request related to the installation.

Check points during the ACP BACnet installation

- · The number of PI485 connected to one RS-485 communication line
 - ACP BACnet provides 4 RS-485 ports for indoor unit connection. (CH 1~4)
 - Up to 16 PI485 for outdoor unit can be connected to one RS-485 port, and up to 31 PI485 for
 - SINGLE/ventilation can be connected.
- · The number of the indoor units that can be connected to one ACP BACnet
 - One ACP BACnet can be connected up to 256 indoor units. To one RS-485 port, all of 256 indoor units, which is the maximum number that can be connected to the ACP BACnet, may be connected.

But, to improve the communication performance of RS-485, it is recommended to be divided and connected to 4 ports.

- RS-485 communication cable connection
 - There is a polarity in RS-485 communication cable connection, so be careful not to reverse the connection of the two cables.
 - Do not let the length of RS-485 communication cable exceed total of 1 Km.
 - RS-485 communication cable must be connected with BUS type.
- · IP address of the ACP BACnet
 - IP address of the ACP BACnet, address of Gateway, and Net mask must be requested to the person in charge of the network of the corresponding site.

Caution

RS-485 Connection of the ventilation equipment

To connect ventilation equipment, it is recommended to use the ports other than RS-485 communication ports which are connected to air conditioners.

Setting the indoor unit address

By considering the entire installation configuration connecting to one ACP BACnet, set the address to each indoor unit not to be overlapped. 00~FF in hexadecimal can be set to the indoor unit address.



The following example sets the address to the indoor unit.



When the ACP BACnet is interconnected with the AC Manager, the ventilator can be installed together and controlled.

The above figure shows the example that sets the addresses of 30 and 31 to the ventilators and connects to the ACP BACnet.



How to set the central control address of the indoor unit

The central control address setting method may be different for each indoor unit product or remote control type, so set the address by referring to the manual of the indoor unit product or wired remote controller.

Setting the PI485 and connecting the cable

After setting the address of the indoor unit, install the PI485 and set the DIP switch.

And then, connect the RS485 cable for communication with the ACP BACnet.



Installing the PI485

- Installing the PI485 depends on the outdoor unit.
- So, install the PI485 by referring to the PI485 manual or the installation technique information.

To connect PI485 and the ACP BACnet, two RS-485 cables need to be connected to BUS-A and BUS-B of PI485. Connect RS-485 cable by referring to the following figure.



If several PI485 are connected to each other to be connected to one ACP BACnet, connect each BUS-A and BUS-B of PI485 to be connected to BUS-A and BUS-B of another PI485.

The following figure is an example of connecting several PI485 with each other to connect to one ACP BACnet.



Installing ACP BACnet and connecting cables

After setting PI485, the ACP BACnet shall be installed in an adequate place, and RS-485 cable shall be connected for the communication with PI485.

And, Ethernet cable (LAN cable) shall be connected for the connection with internet or AC Manager. To fix the ACP BACnet, the following 2 methods may be used.

Install in DIN RAIL or fix to the wall considering the environment of the site.



Installing the ACP BACnet in DIN RAIL

ACP BACnet can be installed in DIN RAIL with width 35mm and height 7.5mm.

Proceed as the follows to install the ACP BACnet in an adequate place.

The installation method of the ACP BACnet is explained here with the example of installing the ACP BACnet in DIN RAIL.

- · Decide the space to install the ACP BACnet.
- Before installing the ACP BACnet, check if it is the adequate place to connect the ACP BACnet with the power, RS-485, and LAN cable.
- · Install DIN RAIL.
- · Hook the top part of the ACP BACnet on DIN RAIL.
- Push the main body of the ACP BACnet until you hear the sound of installation.
- Pull the ACP BACnet to check if it is fixed.





- After installing to DIN RAIL, do not fix to the wall using screws.
- ACP BACnet may be damaged.
- DIN Rail fixing Screw Spec: M3, screw head height 2.0 \sim 1.75mm, screw head diameter 7.0 \sim 5.5mm

Fixing the ACP BACnet to the wall

ACP BACnet can be installed by fixing to the wall. To install the ACP BACnet in an adequate place, proceed according to the following explanation. It explains here on how to install the ACP BACnet with the example of installing the ACP BACnet on the wall.

- Decide the space to install the ACP BACnet. Before installing the ACP BACnet, check if it is the adequate place to connect the ACP BACnet with the power, RS-485, and LAN cable.
- Fix to the wall using the driver. It can be fixed as in the following figure according to the location to install.



Connecting RS-485 cable to the ACP BACnet

After fixing the ACP BACnet in the installation place, RS-485 cable that was connected to Pl485 shall be connected to the ACP BACnet. To connect RS-485 cable to the ACP BACnet, proceed as the following order.

- First, among the connectors that can be connected to the ACP BACnet, connect the end of RS-485 cable connected to BUS-A of PI485 to Tx part. Next, connect the end of RS-485 cable connected to BUS-B of PI485 to Rx part.
- RS-485 cable that was connected to PI485 shall be connected to CH port (RS-485 port) of the ACP BACnet.
 - Plug the connector connecting RS-485 cable into one of CH1 ~ CH4 ports.
 - There are 1~6 CH ports, and it must be plugged into one of 1~4 ports for use.



Information: Connecting RS-485 of the ACP BACnet

Up to 16 outdoor units can be connected to one RS-485 port of the ACP BACnet, and up to 256 indoor units can be connected to one ACP BACnet. If there are many outdoor units to connect, the outdoor unit connections shall be appropriately connected to CH1 to CH4 in BUS format. Otherwise, the ACP BACnet may malfunction.

The following is an example of dividing to CH1 and CH2 and connecting in BUS format.



The next shows the wrong example (STAR connection) of RS-485 connection of the ACP BACnet.



Caution

If a different type of connection is made other than BUS format as in the figure, the product may malfunction. So be careful during the installation.

Connecting Ethernet cable (LAN cable) to the ACP BACnet

After connecting the ACP BACnet and RS-485 cable, Ethernet cable shall be connected to the ACP BACnet.

ACP BACnet may be connected to hub through Ethernet cable, or directly to AC Manager.

Connecting the ACP BACnet and hub

It is the case of connecting the ACP BACnet to the basic internet network installed at the site, and it is generally connected to the hub.

In such case, Ethernet cable shall be connected as a direct cable.

Use Ethernet cable (direct cable) to connect to LAN port of the ACP BACnet.

Connecting ACP BACnet and PC

It is the case of installing AC Manager in a separate PC and connecting ACP BACnet and PC directly.

In such case, Ethernet cable shall be connected as a cross cable.

Use Ethernet cable (cross cable) to connect to LAN port of the ACP BACnet.





Ethernet cable types

- You must distinguish if the Ethernet cable to connect is a direct cable or a cross cable.
- Also, connect after checking the existence of problem in the cable using LAN tester.

Setting the ACP BACnet network address

After connecting the ACP BACnet to various devices via the cable, the network environment of the ACP BACnet should be set by driving the ACP BACnet. The following information should be set for using the ACP BACnet.

- · IP address of the ACP BACnet
- · Gateway address
- Net mask



Setting the network environment information

If the above information is not entered, the communication error may be occurred or it may be impossible to control by the ACP BACnet. So, be careful to correctly input.

Before configuring the ACP BACnet environment

The network environment of the ACP BACnet can be set by the LCD and the buttons at the front side of the ACP BACnet.

The current ACP BACnet information and the menu are displayed on the LCD, and the menu can be changed and selected by pressing SET and \square button and Up/Down/Left/Right (\blacktriangle , \triangledown , \triangleright , \triangleleft) buttons.



Turning on the ACP BACnet

Turn on the ACP BACnet to set the network environment of the ACP BACnet.



When the power switch is turned on, the ACP BACnet booting screen is displayed on the LCD as shown at the following figure, and when booting is completed, the initial ACP BACnet screen is displayed.





Software version

The software version of the current ACP BACnet is displayed at the initial ACP BACnet screen. Also, the software version may be different according to the manufacturing date of the ACP BACnet. LG ACP BACnet SW ver. (1.0.0) I P 192.168.1.100 GW 192.168.1.1

Entering into the environment setup mode

Press [SET] button of the ACP BACnet to enter into the environment setup mode of the ACP BACnet.

When the **[SET]** button is pressed for the first time, the menu to set the IP address is displayed as shown below.



Press up/down(\blacktriangle , \triangledown) button to place the arrow on the desired function.

- When you select [Network Info] and press "SET" button, it enters the No. 1 menu in the following figure.
- In [Network Info] menu, input the network information such as IP address of the ACP BACnet.
- When you select [Contents] and press "SET" button, it enters the No. 2 menu in the following figure.
- In [Contents] menu, you can set the functions of the ACP BACnet and select language to use.
- When you select [Function] and press "SET" button, it enters the No. 3 menu in the following figure.
- · In [Function] menu, ACP BACnet software service function is supported.
- When you select **[Register FD]** and press "SET" button, it enters the No. 4 menu in the following figure.

For more information, please consult with the experts of BMS.



Caution

- [Function] menu is used by the system air conditioner service technician, so user shallnever use this function.
- If this function is incorrectly used, it may cause disorder of the ACP BACnet.

How to set network address

In [Network Info] menu, use the category to set using "up" and "down" (\blacktriangle , \triangledown) buttons.

IP, Gateway, and Net mask settings are displayed in the initial screen of [Network Info] menu, and you can check MAC address and DHCP setting using "down" (▼) button.



To change the network setting, locate the arrow on the corresponding setting position, and press **[SET]** button to enter the corresponding setting screen.



The network address consists of four 3-digit numbers. In case of setting the network address, the, name of the related address is displayed on the LCD of the ACP BACnet, and press Up/Down/Left/ Right (\blacktriangle , \lor , \triangleleft , \triangleright) button to set.

Press Up/Down (\blacktriangle , \checkmark) button to increase/decrease the number of the digit where the cursor is on, and press Left/Right (\triangleleft , \blacktriangleright) button to move the digit of the network address to the left or right.

Example of pressing down (▼) button



Caution

Setting the network address

- The network address can be separated to 4 digits based on ., and each number shall be 255 or less.
- Number exceeding 255 may not be input.



Assigning the network address

- Network address shall be assigned by the person in charge of the network of the corresponding site. (IP address, Gateway address, Net mask)
- ACP BACnet can use both fixed IP type and dynamic IP type, but fixed IP type is recommended, and if dynamic IP type is used, it may cause inconvenience of the customer.
- Please refer to "Using dynamic IP using DHCP" for details.
- If fixed IP type is used, network address (IP address, Gateway address, and Net mask) shall be assigned by the person in charge of the network of the corresponding site.

Setting IP address

For user to use the functions of the ACP BACnet through the web, a unique IP address may be assigned to the ACP BACnet or dynamic IP setting may be used. The next is how to set fixed IP address.

Please proceed according to the order.

- 1. Press [SET] button of the ACP BACnet. The following menu screen will be displayed.
 - If you press [SET] button again, [Network Info] setting screen will be displayed.
 - While IP is selected, pressing [SET] button will display the screen to input IP address.



2. - Use up, down, left, right (\blacktriangle , \bigtriangledown , \blacklozenge , \blacktriangleright) buttons to input the desired IP address.



ENGLISH

Using dynamic IP using DHCP

For user to use the functions of the ACP BACnet through the web, a unique IP address may be assigned to the ACP BACnet or dynamic IP setting may be used.

The next is how to set dynamic IP address.

Please proceed according to the order.

- 1. Press [SET] button of the ACP BACnet. The following menu screen will be displayed.
 - If you press [SET] button again, [Network Info] setting screen will be displayed.
 - While DHCP is selected, if you press **[SET]** button, you can input whether to use DHCP function.



- 2. Use up and down (▲, ▼) buttons to set whether to use DHCP function.
 - When you press up (▲) button, DHCP function is set to use, and if down (▼) button is
 pressed, DHCP is set for no-use.
- 3. To use dynamic IP, set to use DHCP function.



Caution

• If dynamic IP type is used, the IP in use is returned by DHCP server and may not be able to access the ACP BACnet.

In such case, you can check the newly set IP address in the front LCD of the ACP BACnet.

• If you input the ACP BACnet IP address in the web browser, you can run the ACP BACnet program again.

Checking ACP BACnet access

It checks whether the ACP BACnet network address setting is properly done.

You can check the possibility of accessing the ACP BACnet through PING test.

1. You can open the following DOS window through Windows "Start", "Run", "cmd" input.



2. In DOS screen, input "ping <ACP BACnet IP address>" as follows to run PING test.



When the network setting is properly done



Notes

When you connected the ACP BACnet and PC through a cross cable, but you cannot access the ACP BACnet

Check IP address of the ACP BACnet and IP address of the PC.

Ex) If IP address of the ACP BACnet is 192.168.1.101 and Net mask is 255.255.255.0, check if the first three digits of the IP address of the PC is the same as the first three digits of the IP address of the ACP BACnet.

In such case, the IP address of the PC shall start with 192.168.1, and it shall be different from the IP address of the ACP BACnet. Set as follows, and try again.

- Setting of the ACP BACnet
 - IP address: 192.168.1.112
 - Gateway address: 192.168.1.1
 - Subnet Mask: 255.255.255.0
- Setting of the PC
 - IP address: 192.168.1.113
 - Gateway address: 192.168.1.1
 - Subnet Mask: 255.255.255.0
- · Check the status of the Ethernet cable (LAN cable).

Notes

When PC and ACP BACnet are connected together in a hub or a switch hub, and you cannot access the ACP BACnet.

- If it is right after changing the IP setting of the ACP BACnet, reset the power of the ACP BACnet.
- If it is right after connecting LAN cable to the hub or switch, it may take time for the hub or the switch to recognize the ACP BACnet. In such case, it may help to turn off and turn on the power of the hub or the switch.
- Check the status of the Ethernet cable (LAN cable).
- Check ARP table of the PC to see if the IP address of the ACP BACnet correctly corresponds to the MAC address. If duplicate MAC addresses correspond to one IP address, or if different address from the MAC address of the PC is output, there may be a host with the same IP address as the IP address of the ACP BACnet. In such case, the IP address of the ACP BACnet or the IP address of the corresponding host shall be changed.

∝ C:₩WINDOWS₩system32₩cmd.exe				
C:#Documents and Setting	ys₩Administrator>arp -a	ì		
Interface: 165.186.2.251 0x2				
Internet Address	Physical Address	Туре		
10.16.76.148	00-03-2e-05-08-b3	dynamic		
165.186.2.129	00-13-c3-86-67-ff	dynamic		
192.168.1.150	00-00-00-00-00	invalid		

Setting the functions of the ACP BACnet

The following functions can be set by using the menu of the ACP BACnet:

- Select Peak or Demand
- · Setting the attributes of CH6
- · Fire Alarm function
- · Fahrenheit/Celsius setting function
- · Device ID setting function
- · Vnet number setting function
- · Foreign Device register function

Before setting the functions of the ACP BACnet

The function setting of the ACP BACnet should be changed depending on the case that only the ACP BACnet is used or the case that the ACP BACnet is interconnected with the external devices such as AC Manager, power distribution indicator, and Demand controller.

In general, the function of the ACP	BACnet should be set and used as follows:
-------------------------------------	---

	When only ACP BACnet is used	When ACP BACnet interfaces with AC Manager
Peak or demand selection function	Set to peak function	Set to demand function
Schedule function	Set to use schedule function	Set to no-use of schedule function
Power display function	Set to use if it interfaces with power distribution indicator, and set to no-use if it does not interface	



Setting to use the power display

- If the ACP BACnet and the power distribution indicator are not connected, the power display function should be set to no-use.
- If it is set to use, be careful since the control speed of the ACP BACnet will be slower.

Selecting Peak or Demand

The ACP BACnet offers the function to manage the power consumed by the connected air conditioner, by which the electric charges can be effectively saved. The ACP BACnet offers two functions to limit the maximum power consumption of the air conditioner as follows:

- **Peak**: The maximum power consumption of the air conditioner can be managed by setting the maximum usage operation ratio in the ACP BACnet.
- **Demand**: It is set when it interfaces with AC Manager. When this function is set, the maximum usage operation ratio can be set in AC Manager to manage the maximum power consumption of the air conditioner.

One of these two methods can be selected and used in the ACP BACnet. And, if it is set by the menu of the ACP BACnet, the UI screen is differently displayed when accessing the web screen to set the function. The ACP BACnet should be set to the Demand function for the following cases:

· Interfacing with the AC Manager

Notes

Default value

The default value at factory ship-out is set to Peak.

Change the power control method as follows:

 When you press [SET] button, menu screen will be displayed. Use up and down (▲, ▼) buttons of the ACP BACnet to select [Contents], and press [SET] button again. While [Peak/Demand] is selected, pressing [SET] button will display the screen to select peak or demand method.



Use up and down (▲, ▼) buttons to set the desired power management method. If you press up
 (▲) button, it is set to demand method, and if you press down (▼) button, it is set to peak method.



[Set PeakDemand] PK(0) / DMD(1) : 1

Example of setting to use demand function

Setting whether to use FireAlarm function

ACP BACnet provides Fire Alarm function.

After connecting the fire sensor to ACP BACnet DI1, if the fire sensor detects fire, it stops the operations of all connected equipments except the Chiller.

Caution

Fire Alarm interface

- To use the Fire Alarm function, fire sensor needs to be connected to ACP BACnet DI1.
- Please refer to each fire sensor product manual for detail usage of fire sensors.



- When you press the [SET] button of the ACP BACnet, menu screen will be displayed. Use up and down (▲, ▼) buttons to select [Contents], and press [SET] button again.
 - While [FireAlarm] is selected, if you press [SET] button, you can set whether to use the Fire Alarm.

Setting whether to use CH6 function

To connect to the Chiller from the ACP BACnet, M (Chiller) shall be selected in CH6 USAGE.

D (demand controller) setting is not used.

- When you press the [SET] button of the ACP BACnet, menu screen will be displayed. Use up and down (▲, ▼) buttons to select [Contents], and press [SET] button again.
 - While **[CH6 USAGE]** is selected, if you press **[SET]** button, you can select one from D (Demand) or M (Modbus).



Software service function

The following software service function can be run using the menu of the ACP BACnet.

This function shall only be used by the specialized service technician, and negligent use may cause failure of the ACP BACnet system.

- Software update
- Data backup
- · Data recovery
- RS-485 data logging

Software update

When it is necessary to update the ACP BACnet software, it must be carried out by the specialized service technician.

Software update can be done with USB memory.

Proceed in the following order.

- 1. Create "ramdisk" folder in USB memory.
- 2. Put the S/W file to update in 'ramdisk' folder.
 - At this time, only one S/W file must be put. (New version software file can be downloaded from LG Electronics System Air Conditioner homepage.)





E: may be changed.



- 1. Press [SET] button of the ACP BACnet.
- 2. Select [Function] menu, and press [SET] button.
- 3. Select [S/W update] menu, and press [SET] button again.
- 4. To run the software update, press [SET] button again.
 - Wait while software is running.
- 5. After completing the update, press [SET] button to restart the ACP BACnet.
 - Even when you do not immediately restart, update will be applied only after rebooting the ACP BACnet in the future.





While software update is in progress and while "Please wait..." is displayed, turning off the power of the ACP BACnet or removing USB memory may cause severe disorder of the ACP BACnet.

Data backup

If ACP BACnet data backup is necessary, it must be carried out by the specialized service technician.

Data backup can be done with USB memory or SD card.

Proceed in the following or der.

1. Insert USB memory or SD card into the ACP BACnet. (Refer to software update for USB memory insertion.)



- 2. Press [SET] button of the ACP BACnet.
- 3. Select [Function] menu, and press [SET] button.
- 4. Select [DB back up] menu, and press [SET] button again.
- 5. Select [USB] or [SD card], and press [SET] button.
- 6. After completing backup, remove USB memory.



Caution

Before data backup is completed, turning off the power of the ACP BACnet or removing USB memory or SD card may cause severe disorder of the ACP BACnet.

Data recovery

If ACP BACnet data recovery is necessary, it must be carried out by the specialized service technician.

Data recovery can be done with USB memory or SD card.

Proceed in the following order.

- 1. Save the database file to recover in USB memory or SD card.
 - Save the files in "db" folder as follows.



- Insert USB memory or SD card into the ACP BACnet. (Refer to software update and data backup)
- 3. Press [SET] button of the ACP BACnet.
- 4. Select [Function] menu, and press [SET] button.
- 5. Select [DB recover] menu, and press [SET] button again.
- 6. Select [USB] or [SD card], and press [SET] button.
- 7. Remove USB memory after completing the data recovery.
 - ACP BACnet is automatically restarted for data recovery.





Before data recovery is completed, turning off the power of the ACP BACnet or removing USB memory or SD card may cause severe disorder of the ACP BACnet.

RS-485 data logging

If ACP BACnet RS-485 data logging is necessary, it must be carried out by the specialized service technician.

Data logging can be done with SD card.

Proceed in the following order.

- 1. Insert SD card into the ACP BACnet. (Refer to data backup)
- 2. Press [SET] button of the ACP BACnet.
- 3. Select [Function] menu, and press [SET] button.
- 4. Select [Data Logging] menu, and press [SET] button again.
- 5. Select whether to set data logging.



Register Foreign Device

- 1. In [Register FD] menu, use the category to set using "up" and "down" (▲, ▼) buttons.
- IP, PORT, TTL, and Activate of Foreign Device are displayed in the initial screen of [Register FD] menu, and you can check IP, PORT, TTL, and Activate of Foreign Device using "down" (▼) button.
- 3. To change the Foreign Device setting, locate the arrow on the corresponding setting position, and press **[SET]** button to enter the corresponding setting screen.

Example of IP setting





For more information, please consult with the experts of BMS.

##
LG's ACP BACnet Agreement

JMT (Joint Matching Test)

This is necessary for every independent BMS.

The case where a JMT is not necessary is where previously a successful JMT has been carried out and the BMS system has not been updated by software or hardware changes. In the case that the BMS has updated their system by either changes, a following JMT will be required.

ACP BACnet Diagnosis

Use of LG's ACP BACnet setup-tool is for confirming the operation/state of connected A/C units & address ID's, prior to connection with the BMS system.

BMS Engineering

Creating of the Points. This is NOT to be done by LG since it is directly related to the BMS side. The BMS engineer is to carry out the engineering of the Point, however LG is responsible for providing the method of how the Points are calculated.

Commission

First step, only using LG's ACP BACnet, without connecting BMS. This is to be carried out by LG engineering staff with the use of the ACP BACnet set up tool.

Discrepancy of operation of Gateway by BMS

In the case that the BMS maker feels that the ACP BACnet is not functioning correctly via the BACnet Protocol, a test with the use of LG's ACP BACnet Client software can confirm this. (This test is generally not required)



After the LG's ACP BACnet agreement part, please consult with the experts of BMS.



Functional Specifications ACP BACnet

Summary

The ACP BACnet, in response to the requests from the BMS (Building management system which supports BACnet-ANSI/ASHRAE135 protocol), status information of A/C/vent that are connected to the ACP BACnet's internal LG-NET will be sent in BACnet service form, and BACnet client provides a function that transmits control command to the A/C/vent system.

Configuration of Connection

A BACnet client that supports BACnet-ANSI/ASHRAE135 protocol allows direct connection via generally used HUBs or Ethernet. The image of its connection configuration is as shown below.



Objects - ACP BACnet/IP

ACP-BAC Point List : Indoor Unit

One indoor unit has a Point List as follows.

-		ObjectName Product	-q0	Unit					
Point	Control/monitoring	Name	ject	Inactive	Active				
		(XXX : Unit address)	Type	Text-0	Text-1	Text-2	Text-3	Text-4	Text-5
-	ON/OFF (Setting)	StartStopCommand_ XXX	BO	Stop	Start				
2	ON/OFF (Status)	StartStopStatus_XXX	BI	Stop	Run				
e	Lock (Setting)	LockCommand_XXX	BO	Permit	Prohibit				
4	Lock (Status)	LockStatus_XXX	BI	Permit	Prohibit				
5	Filter Sign	Filter Sign_XXX	В	Off	On				
9	Filter Sign Reset	Filter Sign Reset_ XXX	BV		Reset				
7	Operation Mode (Setting)	ModeCommand_XXX	MO		Cool	Dry	Fan	Auto	Heat
8	Operation Mode (Status)	ModeStatus_XXX	M		Cool	Dry	Fan	Auto	Heat
6	Swing (Setting)	SwingCommand_ XXX	BO	Stop	Run				
10	Swing (Status)	SwingStatus_XXX	BI	Stop	Run				
11	Fan Speed (Setting)	FanSpeedCommand_ XXX	MO		Low	Middle	High	Auto	
12	Fan Speed (Status)	FanSpeedStatus_ XXX	M		Low	Middle	High	Auto	
13	Set Room Temperature	SetRoomTemp_XXX	AV	ů					
14	Room Temperature	RoomTemp_XXX	AI	ů					
15	Alarm	Alarm_XXX	B	Normal	Abnor- mal				

		ObjectName Product	-do	Unit					
Point	Control/monitoring	Name	ject	Inactive	Active				
		(XXX : Unit address)	Type	Text-0	Text-1	Text-2	Text-3	Text-4	Text-5
16	Error Code	MalfunctionCodeXXX		Reference	LG Origina	l Error Cod	Ð		
17									
18									
19	Set Temperature Status	SetTempStatus_XXX	A	ပံ					
20	Power Distribution	AccumPowerStatus_ XXX	AI	Wattage v	alues (Unit	100Watt)			
27	Set Upper Temperature Setting	SetUpperTempCom- mand_XXX	AV	ပံ					
28	Set Lower Temperature Setting	SetLowerTempCom- mand_XXX	AI	°					
29	Set Upper Temperature Status	SetUpperTempSta- tus_XXX	AI	ပံ					
30	Set Lower Temperature Status	SetLowerTempSta- tus_XXX	AI	ç					
31	Mode Lock Setting	ModeLockCom- mand_XXX	BO	Permit	Prohibit				
32	Mode Lock Status	ModeLockStatus_ XXX	В	Permit	Prohibit				
33	Fan Lock Setting	Fan LockCommand_ XXX	BO	Permit	Prohibit				
34	Fan Lock Status	FanLockStatus_XXX	В	Permit	Prohibit				

ACP-BAC Point List : Ventilation

One Ventilation unit has a Point List as follows.

		ObjectName Prod-	40	Unit					
Point	Control/monitoring	Uct Name	ject	Inactive	Active				
		address)	Type	Text-0	Text-1	Text-2	Text-3	Text-4	Text-5
-	ON/OFF (Setting)	StartStopCommandXXX	BO	Stop	Start				
2	ON/OFF (Status)	StartStopStatus_XXX	Β	Stop	Run				
e	Lock (Setting)	LockCommand_XXX	BO	Permit	Prohibit				
4	Lock (Status)	LockStatus_XXX	В	Permit	Prohibit				
ى ك	Filter Sign	Filter Sign_XXX	B	Off	On				
9	Filter Sign Reset	Filter Sign Reset_ XXX	BV	I	Reset				
7	Operation Mode (Setting)	ModeCommand_XXX	MO		Heat Exchange	Auto	Normal		
œ	Operation Mode (Status)	ModeStatus_XXX	W		Heat Exchange	Auto	Normal		
6		1							
10	1	1							
11	Fan Speed (Setting)	FanSpeedCommand_ XXX	MO		Low	High	Super High	Auto	
12	Fan Speed (Status)	FanSpeedStatus_ XXX	M		Low	High	Super High	Auto	
13	1								
14									
15	Alarm	Alarm_XXX	В	Off	On				

		ObjectName Prod-	ę	Unit					
Point	Control/monitoring	uct Name	ject	Inactive	Active				
		address)	Type	Text-0	Text-1	Text-2	Text-3	Text-4	Text-5
16	Error Code	MalfunctionCode_ XXX	AI	Reference	LG Origina	I Error Cod	۵		
17	User Mode(Setting)	UserModeCom- mand_XXX	QM	Quick Fresh	Energy Saving	Heater			
18	User Mode(Status)	UserModeStatus_ XXX	W	Quick Fresh	Energy Saving	Heater			
19				ů					
20									
21	AC Operation Mode (setting)	HrvModeCommand_ XXX	QM		Cool	Auto	Heat		
22	AC Operation Mode (status)	HrvModeStatus_XXX	W		Cool	Auto	Heat		
23	AC ON/OFF (setting)	HrvStartStopCom- mand_XXX	BO	Stop	Run				
24	AC ON/OFF (status)	HrvStartStopStatus_ XXX	B	Stop	Run				
25	AC Humidify (setting)	HrvHumidifyCom- mand_XXX	BO	Off	On				
26	AC Humidify (status)	HrvHumidifyStatus_ XXX	B	Off	On				

ACP-BAC Point List : AHU

One AHU unit has a Point List as follows.

DbjectName Product Name (XXX: AHU address) Unit Active Active Text-1 Text-3 Ype Text-0 Text-1 Text-3 Text-4 Text-4 StartStopCommand_XXX B0 Stop Run Text-3 Text-4 Text-4 StartStopCommand_XXX B0 Stop Run Text-3 Text-4 Text-4 LockCommand_XXX B1 Stop Run Prohibit Prohibit
ObjectName Product Name (XXX: HU address) Ob- lect IIII (XX: HU address) Toxuck Active Active Active (XX: HU address) Type Text-0 Text-1 Text-3 Text-4 StartStopCommand_XXX BO Stop Run Text-3 Text-4 StartStopStatus_XXX BI Stop Run Pol Pol Pol LockStatus_XXX BI Permit Prohibit Pol Pol Pol Filter Sion XXX BI Off On On Pol Pol Pol
ObjectName Product Name (XXX : AHU address) Ob- ject Unit \frown Drand Commend_XXX : AHU address) Type Active Active Active StartStopCommand_XXX BO Stop Run Text-3 Text-3 StartStopStatus_XXX BO Stop Run Text-3 Lext-3 LockCommand_XXX BO Permit Prohibit Prohibit Prohibit LockStatus_XXX BI Off On Prohibit Prohibit Prohibit
ObjectName Product Name (XXX: AHU address) Ob- ject Type Unit Active Text-0 Type Text-0 Text-1 Text-2 Text-2 Text-2 StartStopCommand_XXX BO Stop Run Text-2 Text-2 StartStopStatus_XXX BI Stop Run Text-2 LeckCommand_XXX LockCommand_XXX BO Permit Prohibit Prohibit Prohibit LockStatus_XXX BI Permit Prohibit Prohibit Prohibit Filter Sign_XXX BI Off Off On Prohibit Prohibit
ObjectName Product Name (XXX : AHU address) Ob- ject Type Unit Inactive Contor StartStopCommand_XXX B/O Stop Run StartStopStatus_XXX B/O Stop Run LockCommand_XXX B/O Permit Prohibit LockStatus_XXX B/O Permit Prohibit Filter Sign_XXX B/O Off On
ObjectName Product Name (XXX : AHU address) Ob- ject Type Unit StartStopCommand_XXX BO Stop StartStopStatus_XXX BO Stop LockCommand_XXX BO Permit LockStatus_XXX BI Permit Filter Sign_XXX BI Permit
ObjectName Product Name (XXX: AHU address) Ob- ject ject StartStopCommand_XXX BO StartStopStatus_XXX BO LockCommand_XXX BO LockStatus_XXX BO LockStatus_XXX BO Filter Sign_XXX BI Filter Sign_Reset_XXX BV
ObjectName Product Name (XXX : AHU address) StartStopCommand_XXX StartStopStatus_XXX LockCommand_XXX LockStatus_XXX Filter Sign_XXX Filter Sign Reset_XXX

- \sim \sim 4 Ь 9 \sim

Point No.

 ∞ σ Reference LG Original Error Code

MalfunctionCode_XXX

Error Code

Alarm_XXX

Alarm

15 16

Abnormal

Normal

M Ā

ပ္

A

SetRoomTemp_XXX

ï

ï

ī ı

ı. i

10

ı

Ц 12 13 ပ္

₹

RoomTemp_XXX

Temperature

Room

14

Temperature

Set Room

			4	Unit					
Point	Control/monitoring	ObjectName Product Name	ject	Inactive	Active				
			Type	Text-0	Text-1	Text-2	Text-3	Text-4	Text-5
17		1							
18		1							
19	Set Temperature (Status)	SetTempStatus_XXX	A	ပ					
20	Fire Alarm (Setting)	FireAlarmCommand_XXX	BO	Stop	Run				
21	Fire Alarm (Status)	FireAlarmStatus_XXX	B	Stop	Run				
22	Set Humidify (Setting)	SetHumidify Command_XXX	AV	40~60					
23	Set Humidify (Status)	SetHumidifyStatus_XXX	AI	40~60					
24	Humidify (Setting)	HumidifyCommand_XXX	BO	Stop	Run				
25	Humidify (Status)	HumidifyStatus_XXX	B	Stop	Run				
26	Auto Ventilation (Setting)	AutoVentil Command_XXX	BO	Stop	Run				
27	Auto Ventilation (Status)	AutoVentilStatus_XXX	BI	Stop	Run				
28	Supply Temperature (Status)	SupplyTempStatus_XXX	AI	-127~127					
29	Outdoor Temperature (Status)	OutdoorTempStatus_XXX	AI	-127~127					
30	Mix Temperature (Status)	MixTempStatus_XXX	AI	-127~127					
31	Supply Humidity (Status)	SuppyHumidify Status_XXX	AI	30~90					
32	Outdoor Humidity (Status)	OutdoorHumidify Status_XXX	AI	30~90					
33	Ventilation Humidity (Status)	VentilHumidify Status_XXX	AI	30~90					
34	CO2 Value (Status)	CO2ValueStatus_XXX	AI	0~255 (Re CO₂ is 20'	al Value = '	Value*10, E n)	xample : In	case Value	is 20,
35	Humidify Unit (Status)	HumidifyUnitStatus_XXX	BI	Stop	Run				
36	Heater Unit (Status)	HeaterUnitStatus_XXX	B	Stop	Run				

		Text-5												
		Text-4												
		Text-3												
		Text-2												
	Active	Text-1	Run	Run										
Unit	Inactive	Text-0	Stop	Stop	06~0	06~0	06~0	06~0	06~0	06~0	06~0	06~0	06~0	06~0
đ	ject	Type	BI	BI	AI	AI	AI	AV	AI	AV	AI	AV	AI	AV
	ObjectName Product Name		VentilFANStatus_XXX	SupplyFANStatus_XXX	CurOADamper Status_XXX	CurEADamper Status_XXX	CurMixDamperStatus_XXX	OADamperCoolCommand_ XXX	OAD amper Cool Status_XXX	EADamperCoolCommand_ XXX	EADamperCoolStatus_XXX	MixDamperCoolCommand_ XXX	MixDamperCoolStatus_XXX	OADamperHeatCommand_ XXX
	Control/ monitoring	5	Ventilation FAN (Status)	Supply FAN (Status)	Current OA Damper (Status)	Current EA Damper (Status)	Current MIX Damper (Status)	Cool OA Damper (Setting)	Cool OA Damper (Status)	Cool EA Damper (Setting)	Cool EA Damper (Status)	Cool MIX Damper (Setting)	Cool MIX Damper (Status)	Heat OA Damper (Setting)
	Point		37	38	39	40	41	42	43	44	45	46	47	48

		Text-5											
		Text-4											
		Text-3											
		Text-2											
	Active	Text-1											
Unit	Inactive	Text-0	06~0	06~0	06~0	06~0	06~0	06~0	06~0	06~0	06~0	06~0	06~0
-do	ject	Type	AI	AV	AI	AV	AI	AV	AI	AV	AI	AV	AI
	ObjectName Product Name		OADamperHeatStatus_XXX	EADamperHeatCommand_ XXX	EAD amper Heat Status_XXX	MixDamperHeatCommand_ XXX	MixDamperHeatStatus_XXX	OADamperFANCommand_ XXX	OADamperFANStatus_XXX	EADamperFANCommand_ XXX	EADamperFANStatus_XXX	MixDamperFANCommand_ XXX	MixDamperFANStatus_XXX
:	Control/ monitoring	D	Heat OA Damper (Status)	Heat EA Damper (Setting)	Heat EA Damper (Status)	Heat MIX Damper (Setting)	Heat MIX Damper (Status)	Fan OA Damper (Setting)	Fan OA Damper (Status)	Fan EA Damper (Setting)	Fan EA Damper (Status)	Fan MIX Damper (Setting)	Fan MIX Damper (Status)
	Point		49	50	51	52	53	54	55	56	57	58	59

One	AW	/HP ι	unit has	аP	oint	List a	as fo	llow	S.					
		Text-5												
		Text-4												
		Text-3					Auto	Auto						
		Text-2					Heat	Heat						
	Active	Text-1	Run	Run	Run	Run	Cool	Cool						
Unit	Inactive	Text-0	Stop	Stop	Stop	Stop			ç	ç	ç	ç	ç	ŷ
-40	ject	Type	BO	B	BO	B	MO	M	AO	AI	AO	AI	AO	AI
ObjectName Product	Name /YYY · AWHD	address)	StartStopCommandXXX	StartStopStatus_XXX	LockCommand_XXX	LockStatus_XXX	ModeCommand_XXX	ModeStatus_XXX	SetRoomTempCom- mand_XXX	SetRoomTempSta- tus_XXX	SetHotWaterTemp- Command_XXX	SetHotWaterTemp- Status_XXX	SetPipeOutWater- TempCommand_XXX	SetPipeOutWater- TempStatus_XXX
	Control/monitoring		Run/Stop (setting)	Run/Stop (status)	Lock (setting)	Lock (status)	Operation Mode (setting)	Operation Mode (status)	Set Room Temperature (setting)	Set Room Temperature (status)	Set Hot Water Temperature (setting)	Set Hot Water Temperature (status)	Set PipeOut Water Tempera- ture (setting)	Set PipeOut Water Tempera- ture (status)
	Point		~	2	e	4	5	9	7	8	6	10	11	12

ACP-BAC Point List : AWHP

Functional Specifications ACP BACnet 145

		Text-5											
		Text-4											
		Text-3					ode						
		Text-2					al Error Co						
	Active	Text-1	Water	Hot Water Only		Error	LG Origina						
Unit	Inactive	Text-0	Air	Normal	Ŷ	No error	Reference	Ŷ	Ŷ	ç	ç	ç	Ŝ
ł	ject	Type	В	В	AI	B	AI	BO	B	AI	AI	AI	AI
ObjectName Product	Name /////	address)	AirWaterFlag_XXX	HotWaterOnlyFlag_ XXX	RoomTemp_XXX	Alarm_XXX	MalfunctionCode_ XXX	HotWaterCommand_ XXX	HotWaterStatus_XXX	PipeInTempSta- tus_XXX	TankTempStatus_ XXX	SolarTempStatus_ XXX	PipeOutTempSta- tus XXX
	Control/monitoring		Setting Temperature Refer- ence (Air/Water)	Hot Water Only Mode	Current Room Temperature	Alarm Event	Malfunction Code	HotWater On/Off (setting)	HotWater On/Off (status)	Pipe Inlet Temperature Status	Water Tank Temperature Status	Solar Temperature Status	Pipe Outlet Temperature Status
	oint		13	14	15	16	17	18	19	20	21	22	23

ENGLISH

Local Definition of Object ID - The instance number is a pair, this consists of the indoor unit No. and item.



**Device : Group of Product units(16EA)

Example of Point Table

The point table below is passed to BMS, and BMS registers the object.

С	а	s	е	I	n	d	0	or	
							• •		

Address	Object Type	Device No.	Product No.	Point	Instance No.	Name
0	4	0	0	1	0×00001(1)	ON/OFF : setting
0	3	0	0	2	0×00002(2)	ON/OFF : status
1	4	0	1	1	0×00101(257)	ON/OFF : setting
1	3	0	1	2	0×00102(258)	ON/OFF : status
15	4	0	15	1	0×00F01(3841)	ON/OFF : setting
15	3	0	15	2	0×00F02(3842)	ON/OFF : status
16	4	1	0	1	0×01001(4097)	ON/OFF : setting
16	3	1	0	2	0×01002(4098)	ON/OFF : status
17	4	1	1	1	0×01101(4353)	ON/OFF : setting
17	3	1	1	2	0×01102(4354)	ON/OFF : status
31	4	1	15	1	0×01F01(7937)	ON/OFF : setting
31	3	1	15	2	0×01F02(7938)	ON/OFF : status
32	4	2	0	1	0×02001(8193)	ON/OFF : setting
32	3	2	0	2	0×02002(8194)	ON/OFF : status
33	4	2	1	1	0×02101(8449)	ON/OFF : setting
33	3	2	1	2	0×02102(8450)	ON/OFF : status

Address	Object Type	Device No.	Product No.	Point	Instance No.	Name
47	4	2	F	1	0×02F01(12033)	ON/OFF : setting
47	3	2	15	2	0×02F02(12034)	ON/OFF : status

Case Vent

Address	Object Type	Device No.	Product No.	Point	Instance No.	Name
0	4	0	0	1	0×10001(65537)	ON/OFF : setting
0	3	0	0	2	0×10002(65538)	ON/OFF : status
1	4	0	1	1	0×10101(65793)	ON/OFF : setting
1	3	0	1	2	0×10102(65794)	ON/OFF : status
15	4	0	15	1	0×10F01(69377)	ON/OFF : setting
15	3	0	15	2	0×10F02(69378)	ON/OFF : status
16	4	1	0	1	0×11001(69633)	ON/OFF : setting
16	3	1	0	2	0×11002(69634)	ON/OFF : status
17	4	1	1	1	0×11101(69889)	ON/OFF : setting
17	3	1	1	2	0×11102(69890)	ON/OFF : status
31	4	1	15	1	0×11F01(73473)	ON/OFF : setting
31	3	1	15	2	0×11F02(73474)	ON/OFF : status
32	4	2	0	1	0×12001(73729)	ON/OFF : setting
32	3	2	0	2	0×12002(73730)	ON/OFF : status
33	4	2	1	1	0×12101(73985)	ON/OFF : setting
33	3	2	1	2	0X12102(73986)	ON/OFF : status
47	4	2	F	1	0×12F01(77569)	ON/OFF : setting
47	3	2	15	2	0×12F02(77570)	ON/OFF : status

Case AHU

Address	Object Type	Device No.	Product No.	Point	Instance No.	Name
0	4	0	0	1	20001(131073)	ON/OFF : setting
0	3	0	0	2	20002 (131074)	ON/OFF : status
1	4	0	1	1	20101 (131329)	ON/OFF : setting
1	3	0	1	2	20102 (131330)	ON/OFF : status
15	4	0	15	1	20F01 (134913)	ON/OFF : setting
15	3	0	15	2	20F02 (134914)	ON/OFF : status

Detailed Explanation of Object

Common to All Objects

Objects related to the air conditioner in communication are treated on the ACP BACnet as described below.

- · Air Conditioner in Normal Communication
 - Other ACP BACnet devices can access each object related to the air conditioner.
- Air Conditioner Unconnected
 - It seems to other ACP BACnet devices that no objects related to the air conditioner exist.
 - Therefore, when the ReadProperty/WriteProperty service is received, the following ErrorPDU will be returned.
 - Error class: OBJECT; Error type: UNKNOWN_PROPERTY
- Air Conditioner Communication Error
 - Other BACnet device can access the objects related to the air conditioners, but the Present_ Value Property will be read in a value immediately before the communication error.

Run/Stop (Setting)

- Point number: 1
- Object name: StartStopCommand_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Output
- · Meaning: This object is used to give Run/Stop commands to the air conditioner.
- Present_Value property:
- ACTIVE: Run command
- · INACTIVE: Stop command
- · Remarks:
 - 1. The command executed is transmitted to the A/C regardless of the status of the A/C.
 - 2. Present_Value property will not be used if a property has never been set in the past.

Run/Stop (Status)

- · Point number: 2
- Object name: StartStopStatus_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Input
- Meaning: This object is used to monitor the Run/Stop status of the air conditioner.
- Present_Value property:
- ACTIVE: Run
- INACTIVE: Stop
- Remarks: If there is an operation error, the Present_Value property will be set to ACTIVE
 regardless of whether the A/C is in operation or not.

Lock (Setting)

- Point number: 3
- Object name: LockCommand_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Output
- Meaning: This object is used to set the Lock of the A/C's control authority.
- Present_Value property:
- ACTIVE: Lock (Restricted)
- INACTIVE: Unlock (Not restricted)

Lock (Status)

- Point number: 4
- Object name: LockStatus_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Input
- Meaning: This object is used to monitor the Lock of the A/C's control authority.
- Present_Value property:
- · ACTIVE: Lock (Restricted)
- INACTIVE: Unlock (Not restricted)

Filter Sign

- Point number: 5
- Object name: FilterSign_XXX (XXX: Vent/AHU address)
- · Object type: Binary Input
- · Meaning: This object is used to monitor the status of the filters for vent.
- Present_Value property:
- ACTIVE: Filter sign information is turned ON.
- · INACTIVE: Filter sign information is OFF.
- Remarks: This object supports the Intrinsic Reporting function. When the Present_Value
 property changes, the corresponding Event will be transmitted if the Event has
 been registered.

Filter Sign Reset

- Point number: 6
- Object name: FilterSignReset_XXX (XXX: Vent/AHU address)
- · Object type: Binary Value
- Meaning: This object is used to reset the vent's limit indication.
- Present_Value property:
- INACTIVE: Filter indication information is reset.
- · Remarks:
 - 1. During a read operation of the Present_Value property, the Fliter Limit Sign Reset will be always the same value as the Filter Limit Sign object.
 - 2. Only if INACTIVE is written to the Present_Value property during a write operation, the filter sign information resets ON signs and nothing will be executed even if ACTIVE is written.
 - 3. This object supports the Intrinsic Reporting function. When the Present_Value property changes, the corresponding Event will be transmitted if the Event has been registered.

Operation Mode (Setting)

- Point number: 7
- Object name: ModeCommand_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Multistate Output
- · Meaning: This object is used to set the operation modes of the air conditioner.
- Present_Value property:

Indoor	Vent
1 : Cool	HEX

-

- 2 : Dry Auto
- 3 : Fan Normal
- 4 : Auto
- 5 : Heat

· Remarks:

- 1. The Present_Value property will be set to "1: Cool" as the default value if property has never been set in the past.
- The air conditioner will ignore the command to an object that does not have right to select operation mode. Therefore, the controlled/monitored system must not use this object for the air conditioner without the right to select operation mode.

Operation Mode (Status)

- Point number: 8
- Object name: ModeStatus_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Multistate Input
- · Meaning: This object is used to monitor the operation modes of the air conditioner.
- Present_Value property:

Indoor Vent

- 1 : Cool HEX
- 2 : Dry Auto
- 3 : Fan Normal
- 4 : Auto
- 5 : Heat

Swing (Setting)

- Point number: 9
- Object name: SwingCommand_XXX (XXX: Indoor address)
- · Object type: Binary Output
- · Meaning: This object is to set the air direction of the indoor unit.
- Present_Value property:
- ACTIVE: Run
- · INACTIVE: Stop

Swing (Status)

- Point number: 10
- Object name: SwingStatus_XXX (XXX: Indoor address)
- · Object type: Binary Input
- Meaning: This object is to monitor the air direction of the A/C.
- Present_Value property:
- ACTIVE: Swing_On
- INACTIVE: Swing_Off

Fan Speed (Setting)

- Fan Speed (Setting)
- Point number: 11
- Object name: FanSpeedCommand_XXX (XXX: Indoor/Vent address)
- Object type: Multistate Output
- Meaning: This object is to set the airflow of the A/C.
- Present_Value property:

Indoor	Vent
1 : Low	Low
2 : Middle	High
3 : High	Super High
4 : Auto	Auto

Remarks: The A/C will disregard the command which the object which can't select the operation mode.
 Therefore, controlled/monitored system shouldn't use the object which can't select the operation mode.

Fan Speed (Status)

- Point number: 12
- Object name: FanSpeedStatus_XXX (XXX: Indoor/Vent addresss)
- · Object type: Multistate Input
- Meaning: This object is to monitor the airflow of the A/C.
- Present_Value property:

Indoor	Vent
1 : Low	Low
2 : Middle	High
3 : High	Super High
4 : Auto	Auto

Remarks: Present_value property will be set to "1:Low" as the default result if the property has not been set in the past.

Set Room Temperature

- Point number: 13
- Object name: SetRoomTemp_XXX (XXX: Indoor/AHU address)
- · Object type: Analog Value
- · Meaning: This object is used to set the room temperature for the air conditioner.
- Present_Value property:
- Temperature(°C)
- · Remarks:
 - 1. This unit is for indoor units only, and the approximate set temperature range is 18 ~ 35°C.
 - 2. When COV registration is made, the COV will be reported the moment a temperature change of at least 1°C is detected.

Room Temperature

- Point number: 14
- Object name: RoomTemp_XXX (XXX: Indoor/AHU address)
- · Object type: Analog Input
- · Meaning: This object is used to monitor room temperature which the indoor unit is placed.
- Present_Value property:
- Temperature(°C)
- Remarks: This object is for indoor units only, and reports the room temperature data
 measured by the indoor units.

Alarm

- Point number: 15
- · Object name: Alarm_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Input
- · Meaning: This object is used to monitor the Alarm.
- Present_Value property:
- ACTIVE: Alarm_On
- INACTIVE: Alarm_Off

Error Code

- Point number: 16
- Object name: MalfunctionCode_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Analog Input
- · Meaning: This object is used to monitor the details of the error status when the air conditioner
- has an error.
- Present_Value property:
- Error code(Range is 1 to 255)
- Remarks: This object's error code descriptions should be referred to the corresponding table at the "Reference LG original Error Code".

User Mode (Setting)

- Point number: 17
- Object name: UserModeCommand_XXX (XXX: Vent address)
- · Object type: Multi-state Output
- · Meaning: This object is used to set the basic operation mode in vent and also additional
- operation mode (quick fresh, energy efficiency, and heating).
- Present_Value property:
 - 1: Quick
 - 2 : Saving
 - 3 : Heater
- Remarks: This object is for vent only, and will not apply if the property has not been set in the past.

<u>User</u> Mode (Status)

- Point number: 18
- Object name: UserModeStatus_XXX (XXX: Vent address)
- · Object type: Multi-state Input
- · Meaning : This object is used to monitor the basic operation mode in vent
- Property_Value property:
 - 1 : Quick
 - 2 : Saving
 - 3 : Heater
- Reamark : This object is for vent only, and will not apply if the property has not been in the past.

Set Temperature (Status)

- Point number: 19
- Object name: SetTempStatus_XXX (XXX: AHU address)
- · Object type: Analog Input
- · Meaning: This object is used to monitor the set temperature of the A/C's control authority.
- Present_Value property:
- Temperature(°C)
- Remarks : This object is for indoor units only, and reports the room temperature data measured by the indoor units.

Fire Alarm (Setting)

- Point number : 20
- Object name : FireAlarmCommand_XXX (XXX : AHU address)
- · Object type : Binary Output
- Meaning : This object is used to set the fire detection function.
- · Present Value property :
- ACTIVE : Run command
- · INACTIVE : Stop command

Fire Alarm (Status)

- · Point number : 21
- Object name : FireAlarmStatus_XXX (XXX:AHU address)
- · Object type : Binary Input
- · Meaning : This object is used to determine whether fire detection function settings.
- · Present Value property :
- · ACTIVE : Run Status
- · INACTIVE : Stop Status

Set Humidify (Setting)

- · Point number : 22
- Object name : SetHumidifyCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- · Meaning : This object is used to set desired humidity function.
- Present Value property : 40~60

Set Humidify (Status)

- · Point number : 23
- Object name : SetHumidifyStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- · Meaning : This object is used to monitor the desired humidity has been set.
- Present Value property : 40~60

Humidify (Setting)

- · Point number : 24
- Object name : HumidifyCommand_XXX (XXX : AHU address)
- · Object type : Binary Output
- · Meaning : This object is used to activate the humidifier function.
- · Present Value property :
- · ACTIVE : Run Setting
- · INACTIVE : Stop Setting

Humidify (Status)

- · Point number : 25
- Object name : HumidifyStatus_XXX (XXX : AHU address)
- · Object type : Binary Input
- · Meaning : This object is used to monitor whether or not to enable the humidifying function.
- · Present Value property :
- · ACTIVE : Run Status
- INACTIVE : Stop Status

Auto ventilation (Setting)

- Point number : 26
- Object name : AutoVentilCommand_XXX (XXX : AHU address)
- · Object type : Binary Output
- · Meaning : This object is used to set ventilatory function to operate automatically.
- · Present Value property :
- · ACTIVE : Run Setting
- INACTIVE : Stop Setting

Auto ventilation (Status)

- · Point number : 27
- · Object name : AutoVentilStatus_XXX (XXX : AHU address)
- · Object type : Binary Input
- Meaning : This object is used to monitor the presence or absence of the operation of the automatic ventilatory function.
- · Present Value property :
- · ACTIVE : Run Status
- · INACTIVE : Stop Status

Supply temperature (Status)

- · Point number : 28
- Object name : SupplyTempStatus_XXX (XXX : AHU address)
- · Object type : Analog Value
- · Meaning : This object is used to monitor the temperature of the air to be supplied.
- Present Value property : -127~127

Outdoor temperature (Status)

- Point number : 29
- Object name : OutdoorTempStatus_XXX (XXX : AHU address)
- · Object type : Analog Value
- · Meaning : This object is used to monitor the temperature of the outside air.
- Present Value property : -127~127

Mix Temperature (Status)

- Point number : 30
- Object name : MixTempStatus_XXX (XXX : AHU address)
- · Object type : Analog Value
- Meaning : This object is used to monitor the temperature of the air that is mixed.
- Present Value property : -127~127

ENGLISH

Supply Humidity (Status)

- Point number : 31
- Object name : SupplyHumidifyStatus_XXX (XXX : AHU address)
- · Object type : Analog Value
- · Meaning : This object is used to monitor the humidity of the air to be supplied.
- Present Value property : 30~90

Outdoor Humidity (Status)

- · Point number : 32
- Object name : OutdoorHumidifyStatus_XXX (XXX : AHU address)
- · Object type : Analog Value
- · Meaning : This object is used to monitor the humidity of the outside air.
- Present Value property : 30~90

Ventilation Humidity (Status)

- Point number : 33
- Object name : VentilHumidifyStatus_XXX (XXX : AHU address)
- · Object type : Analog Value
- Meaning : This object is used to monitor the humidity of the ventilation air is made.
- Present Value property : 30~90

CO2 Value (Status)

- · Point number : 34
- Object name : CO2ValueStatus_XXX (XXX : AHU address)
- · Object type : Analog Value
- Meaning : This object is used to monitor the humidity of the ventilation air is made.
- Present Value property : 0~255
- (Real Value = Value*10, Example : In case Value is 20, CO2 is 20*10=200ppm)

Humidify Unit (Status)

- Point number : 35
- Object name : HumidifyUnitStatus_XXX (XXX : AHU address)
- Object type : Binary Input
- · Meaning : This object is used to monitor the operating status of the humidifier.
- · Present Value property :
- · ACTIVE : Run Status
- · INACTIVE : Stop Status

Heater Unit (Status)

- · Point number : 36
- Object name : HeaterUnitStatus_XXX (XXX : AHU address)
- · Object type : Binary Input
- · Meaning : This object is used to monitor the operating state of the heater.
- · Present Value property :
- · ACTIVE : Run Status
- · INACTIVE : Stop Status

Ventilation FAN (Status)

- Point number : 37
- Object name : VentilFANStatus_XXX (XXX : AHU address)
- · Object type : Binary Input
- · Meaning : This object is used to monitor the operating status of FAN ventilation.
- · Present Value property :
- ACTIVE : Run Status
- INACTIVE : Stop Status

Supply FAN (Status)

- Point number : 38
- Object name : VentilFANStatus_XXX (XXX : AHU address)
- · Object type : Binary Input
- Meaning : This object is used to monitor the operating status of the air supply FAN.
- · Present Value property :
- · ACTIVE : Run Status
- · INACTIVE : Stop Status

Current OA Damper (Status)

- Point number : 39
- Object name : CurOADamperStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- · Meaning : This object is used to monitor the current opening degree of OA damper.
- Present Value property : 0~90

Current EA Damper (Status)

- Point number : 40
- Object name : CurEADamperStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- Meaning : This object is used to monitor the current opening degree of the EA damper.
- Present Value property : 0~90

Current MIX Damper (Status)

- Point number : 41
- Object name : CurMixDamperStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- Meaning : This object is used to monitor the degree of opening of the damper current Mix.
- Present Value property : 0~90

Cool OA Damper (Setting)

- · Point number : 42
- Object name : OADamperCoolCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- · Meaning : This object is used to set the opening degree of OA damper cooling.
- Present Value property : 0~90

Cool OA Damper (Status)

- Point number : 43
- Object name : OADamperCoolStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- Meaning : This object is used to monitor the degree of opening of OA damper cooling that has been set.
- Present Value property : 0~90

Cool EA Damper (Setting)

- · Point number : 44
- Object name : EADamperCoolCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- · Meaning : This object is used to set the opening degree of the EA damper cooling.
- Present Value property : 0~90

Cool EA Damper (Status)

- Point number : 45
- Object name : EADamperCoolStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- Meaning : This object is used to monitor the degree of opening of the EA damper cooling that
 has been set.
- Present Value property : 0~90

Cool MIX Damper (Setting)

- · Point number : 46
- Object name : MIXDamperCoolCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- Meaning : This object is used to set the degree of opening of the MIX cooling damper.
- Present Value property : 0~90

Cool MIX Damper (Status)

- Point number : 47
- Object name : MIXDamperCoolStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- Meaning : This object is used to monitor the degree of opening of the MIX cooling damper has been set.
- Present Value property : 0~90

Heat OA Damper (Setting)

- · Point number : 48
- Object name : OADamperHeatCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- · Meaning : This object is used to set the opening degree of OA damper Heating.
- Present Value property : 0~90

Heat OA Damper (Status)

- Point number : 49
- Object name : OADamperHeatStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- Meaning : This object is used to monitor the degree of opening of OA heating damper is set.
- Present Value property : 0~90

Heat EA Damper (Setting)

- Point number : 50
- Object name : EADamperHeatCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- Meaning : This object is used to set the opening degree of the EA damper Heating.
- Present Value property : 0~90

Heat EA Damper (Status)

- Point number : 51
- Object name : EADamperHeatStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- · Meaning : This object is used to monitor the degree of opening of the EA heating damper is set.
- Present Value property : 0~90

Heat MIX Damper (Setting)

- Point number : 52
- Object name : MIXDamperHeatCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- Meaning : This object is used to set the degree of opening of the MIX damper Heating.
- Present Value property : 0~90

Heat MIX Damper (Status)

- Point number : 53
- Object name : MIXDamperHeatStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- Meaning : This object is used to monitor the degree of opening of the MIX heating damper is set.
- Present Value property : 0~90

Fan OA Damper (Setting)

- · Point number : 54
- Object name : OADamperFANCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- Meaning : This object is used to set the blower damper opening degree of OA.
- Present Value property : 0~90

Fan OA Damper (Status)

- Point number : 55
- Object name : OADamperFANStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- Meaning : This object is used to monitor the degree of opening of OA ventilation damper set.
- Present Value property : 0~90

Fan EA Damper (Setting)

- Point number : 56
- Object name : EADamperFANCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- Meaning : This object is used to set the blower damper opening degree of the EA.
- Present Value property : 0~90

Fan EA Damper (Status)

- · Point number : 57
- Object name : EADamperFANStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- · Meaning : This object is used to monitor the degree of opening of the EA ventilation damper set.
- Present Value property : 0~90

Fan MIX Damper (Setting)

- Point number : 58
- Object name : MIXDamperFANCommand_XXX (XXX : AHU address)
- · Object type : Analog Value
- · Meaning : This object is used to set the blower damper opening degree of the MIX.
- Present Value property : 0~90

Fan MIX Damper :Status

- Point number : 59
- Object name : MIXDamperFANStatus_XXX (XXX : AHU address)
- · Object type : Analog Input
- · Meaning : This object is used to monitor the degree of opening of the MIX ventilation damper set.
- Present Value property : 0~90

Detailed attributes of each object, please refer to the table attributes on page 203

Objects (Modbus-TCP)

Supported Function Code

Monitoring and controlling items of air conditioners supported are assigned with general function

codes specified by Modbus-ICF	codes specifie	d by M	lodbus-TC	P.
-------------------------------	----------------	--------	-----------	----

Function Name	Code	Description
Read Single Coil	01h	Run/Stop(status), Lock(status), Swing(status), Alarm, Filter Sign(status), Mode Lock(status), Wind Flow Lock(status)
Read Holding Registers	03h	Operation Mode(status), Fan Speed(status), Room Temperature, Error Code, Set Room Temperature(status), Set Lower Temperature(status), Set Upper Temperature(status), User Mode(status)
Write Single Coil	05h	Run/Stop(setting), Lock(setting), Swing(setting), Filter Sign Reset, Mode Lock(setting), Wind Flow Lock(setting)
Write Single Registers	06h	Operation Mode(setting), Fan Speed(setting), Set Room Temperature(setting), Set Lower Temperature(setting), Set Upper Temperature(setting), User Mode(setting)

legister	Function	Name	Object Name (XXX : Unit address)	Inactive	Active
1		ON/OFF	StartStopStatus_XXX	Stop	Run
2		SWING	SwingStatus_XXX	Permit	Prohibit
S	Read	LOCK	LockStatus_XXX	Permit	Prohibit
4	Single	MODE LOCK	ModeLockStatus_XXX	Permit	Prohibit
5	Coil	FAN LOCK	WindFlowLockStatus_XXX	Permit	Prohibit
9		TEMP LOCK	SetTempStatus-XXX	Permit	Prohibit
7		ALARM	Alarm_XXX	Normal	Abnormal
1		ON/OFF	StartStopCommand_XXX	Stop	Run
2		SWING	SwingCommand_XXX	Permit	Prohibit
e	Write Single	LOCK	LockCommand_XXX	Permit	Prohibit
4	Coil	MODE LOCK	ModeLockCommand_XXX	Permit	Prohibit
5		FAN LOCK	WindFlowLockCommand_XXX	Permit	Prohibit
9		TEMP LOCK	SetTempCommand-XXX	Permit	Prohibit

Modbus Point List : Indoor Unit

Register	Function	Name	Object Name (XXX : Unit address)	Text-0	Text-1	Text-2	Text-3	Text-4	Text-5
-		OPERATION MODE	ModeStatus_XXX		Cool	Dry	Fan	Auto	Heat
2		FAN SPEED	FanSpeedStatus_XXX		Low	Middle	High	Auto	
с		SET ROOM TEMPERATURE	SetTempStatus_XXX	ပံ					
4	Read Redisters	UP_SETTEMP	SetUpperTemp Status_XXX	ပံ					
£	5	LO_SETTEMP	SetLowerTemp Status_XXX	ů					
9		ROOM TEMPERATURE	RoomTemp_XXX		ပံ				
7		ERROR CODE	MalfunctionCode_XXX	R	eferenc	e LG ori	ginal Erı	ror Code	0
-		OPERATION MODE	ModeCommand_XXX		Cool	Dry	Fan	Auto	Heat
7		FAN SPEED	FanSpeed Command_XXX		Low	Middle	High	Auto	
e	Write Single Registers	SET ROOM TEMPERATURE	SetTemp Command_XXX	ů					
4		UP_SETTEMP	SetUpperTemp Command_XXX	ů					
5		LO_SETTEMP	SetLowerTemp Command_XXX	ů					

Function Code : 0x03 and 0x06
Register	Function	Name	Object Name (XXX : Ventilation address)	Inactive	Active
-		ON/OFF	StartStopStatus_XXX	Stop	Run
2		LOCK	LockStatus_XXX	Permit	Prohibit
3		FILTER SIGN	FilterSign_XXX	Off	On
4	COII REAU	ALARM	Alarm_XXX	Stop	Run
5		HRV_AC_OPER	HrvStartStopStatus_XXX	Stop	Run
9		HRV_HUMIDIFY	HrvHumidifyStatus_XXX	Off	On
-		ON/OFF	StartStopCommand_XXX	Stop	Run
2		LOCK	LockCommand_XXX	Permit	Prohibit
3	Write Single Coil	FILTER SIGN RESET	FilterSignReset_XXX	Reset(Off)	Void(On)
5		HRV_AC_OPER	HrvStartStopCommand_XXX	Stop	Run
9		HRV_HUMIDIFY	HrvHumidifyCommand_XXX	Off	On

Modbus Point List : Ventilation

Text-5											
Text-4		Auto		Ø				Auto			
Text-3	Normal	Super High	Heat	ror Code	Heat		Normal	Super High	Heat	Heat	
Text-2	Auto	High	Energy Saving	ginal Er	Auto		Auto	High	Energy Saving	Auto	
Text-1	Heat Exchange	Low	Quick Operation	nce LG ori	Cool		Heat Exchange	Low	Quick Operation	Cool	
Text-0				Refere		ပ္					ပ္
Object Name (XXX : Ventilation address)	ModeStatus_XXX	FanSpeedStatus_XXX	UserModeStatus_XXX	MalfunctionCode_XXX	HrvModeStatus_XXX	HrvSetTempstatus_XXX	ModeCommand_XXX	FanSpeed Command_XXX	User Mode Status_XXX	HrvModeStatus_XXX	HrvSetTempstatus_XXX
Name	OPERATION MODE	FAN SPEED	USER MODE	ERROR CODE	HRV_AC_MODE	HRV_SETTEMP	OPERATION MODE	FAN SPEED	USER MODE	HRV_AC_MODE	HRV_SETTEMP
Function			Holding Registers					Write Single	Registers		
Register	-	7	З	4	5	9	-	0	с	5	9

Function Code : 0x03 and 0x06

Register	Function	Name	Object Name (XXX : AHU address)	Inactive	Active
1		ON/OFF	StartStopStatus_XXX	Stop	Run
2		LOCK	LockStatus_XXX	Permit	Prohibit
S		FILTER SIGN	FilterSign_XXX	Off	On
4		SMOKE	FireAlarmStatus_XXX	Stop	Run
5		HUMIDITY	HumidifyStatus_XXX	Stop	Run
9	Coil Read	AUTO VENT	AutoVentStatus_XXX	Stop	Run
7		HUMIDIFIER	HumidifiyUnitStatus-XXX	Stop	Run
8		HEATER	HeaterUnitStatus_XXX	Stop	Run
6		VENT FAN	VentFANStatus_XXX	Stop	Run
10		SUPPLY FAN	SupplyFANStatus_XXX	Stop	Run
11		ALARM	Alarm_XXX	Normal	Abnormal
-		ON/OFF	StartStopCommand_XXX	Stop	Run
2		LOCK	LockCommand_XXX	Permit	Prohibit
4	Write Single Coil	SMOKE	FireAlarmCommand_XXX	Stop	Run
5		HUMIDITY	HumidifyCommand_XXX	Stop	Run
9		AUTO VENT	AutoVentCommand_XXX	Stop	Run

Modbus Point List : AHU

Text-5	Heat																				
Text-4	POWSAV											or Code									
Text-3	Fan											original Err									
Text-2	Dry											nce LG c									
Text-1	Cool											Refere									
Text-0		ပိ	-127~127	-127~127	-127~127	-127~127	40~60	30~90	30~90	30~90	0~255		06~0	06~0	06~0	06~0	06~0	06~0	06~0	06~0	06~0
Object Name (XXX : AHU address)	ModeStatus_XXX	SetTempStatus_XXX	SupplyTempStatus_XXX	OutdoorTempStatus_XXX	VentTempStatus_XXX	MixingTempStatus_XXX	SetHumidityStatus_XXX	SupplyHumidityStatus_XXX	OutdoorHumidityStatus_XXX	VentHumidityStatus_XXX	CO ₂ ValueStatus_XXX	MalfunctionCode_XXX	CurOADamperStatus_XXX	CurEADamperStatus_XXX	CurMixDamperStatus_XXX	OADamperCoolStatus_XXX	EADamperCoolStatus_XXX	MixDamperCoolStatus_XXX	OADamperHeatStatus_XXX	EADamperHeatStatus_XXX	MixDamperHeatStatus_XXX
Name	MODE	SET TEMP	SUPPLY TEMP	OUTDOOR TEMP	VENT TEMP	MIXING TEMP	SET HUMIDITY	SUPPLY HUMIDITY	OUTDOOR HUMIDITY	VENT HUMIDITY	CO2 VALUE	ERROR CODE	CURR_OA_DAMPER	CURR_EA_DAMPER	CURR_MIX_DAMPER	COOL_OA_DAMPER	COOL_EA_DAMPER	COOL_MIX_DAMPER	HEAT_OA_DAMPER	HEAT_EA_DAMPER	HEAT_MIX_DAMPER
Function										Read	Holding	Registers									
Register	~	2	က	4	വ	9	7	80	0	10	11	12	17	18	19	20	21	22	23	24	25

Function Code : 0x03

ENGLISH

Register	Function	Name	Object Name (XXX : AHU address)	Text-0	Text-1	Text-2	Text-3	Text-4	Text-5
26	Read	FAN_OA_DAMPER	OADamperFANStatus_XXX	06~0					
27	Holding	FAN_EA_DAMPER	EADamperFANStatus_XXX	06~0					
28	Registers	FAN_MIX_DAMPER	MixDamperFANStatus_XXX	06~0					
~		MODE	ModeCommand_XXX		Cool	Dry	Fan	POWSAV	Heat
2		SET TEMP	SetTempCommand_XXX	ç					
7		SET HUMIDITY	SetHumidityCommand_XXX	40~60					
20		COOL_OA_DAMPER	CoolOADamperCommand_XXX	06~0					
21		COOL_EA_DAMPER	CoolEADamperCommand_XXX	06~0					
22	Write	COOL_MIX_DAMPER	CoolMixDamperCommand_XXX	06~0					
23	Registers	HEAT_OA_DAMPER	HeatOADamperCommand_XXX	06~0					
24		HEAT_EA_DAMPER	HeatEADamperCommand_XXX	06~0					
25		HEAT_MIX_DAMPER	HeatMixDamperCommand_XXX	06~0					
26		FAN_OA_DAMPER	FANOADamperCommand_XXX	06~0					
27		FAN_EA_DAMPER	FANEADamperCommand_XXX	06~0					
28		FAN_MIX_DAMPER	FANMixDamperCommand_XXX	06~0					

Function Code : 0x03 / 0x06

Local Definition of Object ID - The instance number is a pair, this consists of the indoor unit No. and item.

Example of Point Table

The point table below is passed to BMS, and BMS registers the object.



* Object Type (Coil: 0, Register: 4)

* Product Type (Indoor : 0, Vent : 4, AHU : 8) ** Device : Group of Product units (16EA)

С	a	s	е	I	n	d	0	0	r

Function Code	Device No.	Product No.	Point	Instance No.	Name
1	0	0	0	0x00000	ON/OFF status
5	0	0	0	0x00000	ON/OFF Setting
1	0	1	0	0x00010	ON/OFF status
5	0	1	0	0x00010	ON/OFF Setting
1	1	0	0	0x00100	ON/OFF status
5	1	0	0	0x00100	ON/OFF Setting
3	0	0	0	0x40000	Mode status
6	0	0	0	0x40000	Mode Setting
3	0	1	0	0x40010	Mode status
6	0	1	0	0x40010	Mode Setting
3	1	0	0	0x40100	Mode status
6	1	0	0	0x40100	Mode Setting

Function Code	Device No.	Product No.	Point	Instance No.	Name
1	0	0	0	0x04000	ON/OFF status
5	0	0	0	0x04000	ON/OFF Setting
1	0	1	0	0x04010	ON/OFF status
5	0	1	0	0x04010	ON/OFF Setting
1	1	0	0	0x04100	ON/OFF status
5	1	0	0	0x04100	ON/OFF Setting
3	0	0	0	0x44000	Mode status
6	0	0	0	0x44000	Mode Setting
3	0	1	0	0x44010	Mode status
6	0	1	0	0x44010	Mode Setting
3	1	0	0	0x44100	Mode status
6	1	0	0	0x44100	Mode Setting

Case Vent

Case AHU

Function Code	Device No.	Product No.	Point	Instance No.	Name
1	0	0	0	0x08000	ON/OFF status
5	0	0	0	0x08000	ON/OFF Setting
1	0	1	0	0x08010	ON/OFF status
5	0	1	0	0x08010	ON/OFF Setting
1	1	0	0	0x08100	ON/OFF status
5	1	0	0	0x08100	ON/OFF Setting
3	0	0	0	0x48000	Mode status
6	0	0	0	0x48000	Mode Setting
3	0	1	0	0x48010	Mode status
6	0	1	0	0x48010	Mode Setting
3	1	0	0	0x48100	Mode status
6	1	0	0	0x48100	Mode Setting

Detailed Explanation of Object

Common to All Objects

Objects related to the air conditioner in communication are treated on the BACnet as described below.

- · Air Conditioner in Normal Communication
 - Other BACnet devices can access each object related to the air conditioner.
- Air Conditioner Unconnected
 - It seems to other BACnet devices that no objects related to the air conditioner exist.
 - Therefore, when the ReadProperty/WriteProperty service is received, the following ErrorPDU will be returned.
 - Error class: OBJECT; Error type: UNKNOWN_PROPERTY
- Air Conditioner Communication Error
 - Other BACnet device can access the objects related to the air conditioners, but the Present_ Value Property will be read in a value immediately before the communication error.

Run/Stop (Setting)

- Point number: 1
- Object name: StartStopCommand_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Output
- Meaning: This object is used to give Run/Stop commands to the air conditioner.
- Present_Value property:
- · ACTIVE: Run command
- · INACTIVE: Stop command
- · Remarks:
 - 1. The command executed is transmitted to the A/C regardless of the status of the A/C.
 - 2. Present_Value property will not be used if a property has never been set in the past.

Run/Stop (Status)

- Point number: 2
- Object name: StartStopStatus_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Input
- Meaning: This object is used to monitor the Run/Stop status of the air conditioner.
- Present_Value property:
- ACTIVE: Run
- INACTIVE: Stop
- Remarks: If there is an operation error, the Present_Value property will be set to ACTIVE
 regardless of whether the A/C is in operation or not.

Lock (Setting)

- Point number: 3
- Object name: LockCommand_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Output
- Meaning: This object is used to set the Lock of the A/C's control authority.
- Present_Value property:
- ACTIVE: Lock (Restricted)
- INACTIVE: Unlock (Not restricted)

Lock (Status)

- Point number: 4
- Object name: LockStatus_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Input
- · Meaning: This object is used to monitor the Lock of the A/C's control authority.
- Present_Value property:
- ACTIVE: Lock (Restricted)
- INACTIVE: Unlock (Not restricted)

Filter Sign

- Point number: 5
- Object name: FilterSign_XXX (XXX: Vent/AHU address)
- · Object type: Binary Input
- Meaning: This object is used to monitor the status of the filters for vent.
- Present_Value property:
- ACTIVE: Filter sign information is turned ON.
- INACTIVE: Filter sign information is OFF.
- Remarks: This object supports the Intrinsic Reporting function. When the Present_Value
 property changes, the corresponding Event will be transmitted if the Event has
 been registered.

Filter Sign Reset

- Point number: 6
- Object name: FilterSignReset_XXX (XXX: Vent/AHU address)
- · Object type: Binary Value
- · Meaning: This object is used to reset the vent's limit indication.
- Present_Value property:
- INACTIVE: Filter indication information is reset.
- · Remarks:
 - 1. During a read operation of the Present_Value property, the Fliter Limit Sign Reset will be always the same value as the Filter Limit Sign object.
 - 2. Only if INACTIVE is written to the Present_Value property during a write operation, the filter sign information resets ON signs and nothing will be executed even if ACTIVE is written.
 - 3. This object supports the Intrinsic Reporting function. When the Present_Value property changes, the corresponding Event will be transmitted if the Event has been registered.

Operation Mode (Setting)

- Point number: 7
- Object name: ModeCommand_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Multistate Output
- · Meaning: This object is used to set the operation modes of the air conditioner.
- Present_Value property:

Indoor	Vent
1 : Cool	HEX
2 : Dry	Auto
3 : Fan	Normal
4 : Auto	-

5 : Heat

· Remarks:

- 1. The Present_Value property will be set to "1: Cool" as the default value if property has never been set in the past.
- The air conditioner will ignore the command to an object that does not have right to select operation mode. Therefore, the controlled/monitored system must not use this object for the air conditioner without the right to select operation mode.

Operation Mode (Status)

- Point number: 8
- Object name: ModeStatus_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Multistate Input
- · Meaning: This object is used to monitor the operation modes of the air conditioner.
- Present_Value property:

Indoor	Vent
1 : Cool	HEX
2 : Dry	Auto
3 : Fan	Normal
4 : Auto	-
5 : Heat	-

Swing (Setting)

- Point number: 9
- Object name: SwingCommand_XXX (XXX: Indoor address)
- · Object type: Binary Output
- · Meaning: This object is to set the air direction of the indoor unit.
- Present_Value property:
- · ACTIVE: Run
- · INACTIVE: Stop

Swing (Status)

- Point number: 10
- Object name: SwingStatus_XXX (XXX: A/C unit address)
- · Object type: Binary Input
- Meaning: This object is to monitor the air direction of the A/C.
- Present_Value property:
- · ACTIVE: Swing_On
- INACTIVE: Swing_Off

Fan Speed (Setting)

- · Point number: 11
- Object name: FanSpeedCommand_XXX (XXX: A/C unit address)
- · Object type: Multistate Output
- · Meaning: This object is to set the airflow of the A/C.
- Present_Value property:

Indoor	Vent
1 : Low	Low
2 : Middle	High
3 : High	Super High
4 : Auto	Auto

• Remarks: The A/C will disregard the command which the object which can't select the operation mode. Therefore, controlled/monitored system shouldn't use the object which can't select the operation mode.

Fan Speed (Status)

- · Point number: 12
- Object name: FanSpeedStatus_XXX (XXX: Indoor/Vent addresss)
- · Object type: Multistate Input
- Meaning: This object is to monitor the airflow of the A/C.
- Present_Value property:

Indoor	Vent
1 : Low	Low
2 : Middle	High
3 : High	Super High
4 : Auto	Auto

• Remarks: Present_value property will be set to "1:Low" as the default result if the property has not been set in the past.

Set Room Temperature

- Point number: 13
- Object name: SetRoomTemp_XXX (XXX: Indoor/AHU address)
- · Object type: Analog Value
- · Meaning: This object is used to set the room temperature for the air conditioner.
- Present_Value property:
- Temperature(°C)
- · Remarks:
 - 1. This unit is for indoor units only, and the approximate set temperature range is 18 ~ 35°C.
 - When COV registration is made, the COV will be reported the moment a temperature change of at least 1°C is detected.

Room Temperature

- · Point number: 14
- Object name: RoomTemp_XXX (XXX: Indoor/AHU address)
- · Object type: Analog Input
- · Meaning: This object is used to monitor room temperature which the indoor unit is placed.
- Present_Value property:
- Temperature(°C)
- Remarks: This object is for indoor units only, and reports the room temperature data measured by the indoor units.

Alarm

- Point number: 15
- · Object name: Alarm_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Binary Input
- · Meaning: This object is used to monitor the Alarm.
- Present_Value property:
- ACTIVE: Alarm_On
- INACTIVE: Alarm_Off

Error Code

- · Point number: 16
- Object name: MalfunctionCode_XXX (XXX: Indoor/Vent/AHU address)
- · Object type: Analog Input
- · Meaning: This object is used to monitor the details of the error status when the air conditioner
- · has an error.
- Present_Value property:
- Error code(Range is 1 to 255)
- Remarks: This object's error code descriptions should be referred to the corresponding table
 at the "Reference LG original Error Code".

User Mode (Setting)

- Point number: 17
- Object name: UserModeCommand_XXX (XXX: Vent address)
- · Object type: Multi-state Output
- · Meaning: This object is used to set the basic operation mode in vent and also additional
- operation mode (quick fresh, energy efficiency, and heating).
- Present_Value property:
 - 1: Quick
 - 2: Saving
 - 3: Heater
- Remarks: This object is for vent only, and will not apply if the property has not been set in the past.

User Mode (Status)

- · Point number: 18
- Object name: UserModeStatus_XXX (XXX: Vent address)
- · Object type: Multi-state Input
- · Meaning : This object is used to monitor the basic operation mode in vent
- Property_Value property:
 - 1: Quick
 - 2: Saving
 - 3: Heater
- Reamark : This object is for vent only, and will not apply if the property has not been in the past.

Set Temperature (Status)

- Point number: 19
- Object name: SetTempStatus_XXX (XXX: AHU address)
- · Object type: Analog Input
- Meaning: This object is used to monitor the set temperature of the A/C's control authority.
- Present_Value property:
- Temperature(°C)
- Remarks : This object is for indoor units only, and reports the room temperature data measured by the indoor units.

Accumulator Power Distribution (Status)

- Point number: 20
- Object name: AccumPowerStatus_XXX (XXX: A/C unit address)
- · Object type: Analog Input
- Meaning: This object is used to monitor the accumulator power distribution of the A/C's control
- authority.
- Present_Value property:
- Power Distribution(count * 100Watt)

AC Operation Mode (Setting)

- · Point number: 21
- Object name: HrvModeCommand_XXX (XXX: DXHRV unit address)
- · Object type: Multistate Output
- · Meaning: This object is used to set the A/C operation mode of the DXHRV.
- Present_Value property:
 - 1 : Cool
 - 2 : Auto
 - 3 : Heat

AC Operation Mode (Status)

- Point number: 22
- Object name: HrvModeStatus_XXX (XXX: DXHRV unit address)
- · Object type: Multistate Input
- · Meaning: This object is used to monitor the A/C operation mode of the DXHRV.
- Present_Value property:
 - 1 : Cool
 - 2 : Auto
 - 3 : Heat

AC Run/Stop (Setting)

- Point number: 23
- Object name: HrvStartStopCommand_XXX (XXX: DXHRV unit address)
- · Object type: Binary Output
- · Meaning: This object is used to set the A/C Run/Stop status of the DXHRV.
- Present_Value property:
- · ACTIVE: Run command
- INACTIVE: Stop command

AC Run/Stop (Setting)

- Point number: 24
- Object name: HrvStartStopStatus_XXX (XXX: DXHRV unit address)
- · Object type: Binary Input
- Meaning: This object is used to monitor the A/C Run/Stop status of the DXHRV.
- Present_Value property:
- ACTIVE: Run
- INACTIVE: Stop

AC Humidify (Setting)

- Point number: 25
- Object name: HrvHumidifyCommand_XXX (XXX: DXHRV unit address)
- · Object type: Binary Output
- Meaning: This object is used to set the A/C humidify status of the DXHRV.
- Present_Value property:
- · ACTIVE: ON command
- · INACTIVE: OFF command

AC Humidify (Status)

- Point number: 26
- Object name: HrvStartStopStatus_XXX (XXX: DXHRV unit address)
- · Object type: Binary Input
- · Meaning: This object is used to monitor the A/C humidify status of the DXHRV.
- Present_Value property:
- · ACTIVE: ON
- INACTIVE: OFF

Set Upper Temperature (Setting)

- Point number: 27
- Object name: SetUpperTempCommand_XXX (XXX: A/C unit address)
- · Object type: Analog Value
- · Meaning: This object is used to set the upper temperature for the air conditioner.
- Present_Value property:
- Temperature(°C)
- · Remarks: .
 - 1. This unit is for indoor units only, and the approximate set upper temperature range is 18 \sim 30°C.
 - 2. 1°C is detected.

Set Upper Temperature (Status)

- Point number: 28
- Object name: SetUpperTempStatus_XXX (XXX: A/C unit address)
- · Object type: Analog Input
- Meaning: This object is used to monitor set upper temperature which the indoor unit is placed.
- Present_Value property:
- Temperature(°C)
- Remarks: This object is for indoor units only, and reports the set upper temperature data
 measured by the indoor units.

Set Lower Temperature (Setting)

- Point number: 29
- Object name: SetLowerTempCommand_XXX (XXX: A/C unit address)
- · Object type: Analog Value
- Meaning: This object is used to set the lower temperature for the air conditioner.
- Present_Value property:
- Temperature(°C)
- · Remarks:
 - This unit is for indoor units only, and the approximate set lower temperature range is 18 ~ 30°C.
 - 2. 1°C is detected.

Set Lower Temperature (Status)

- · Point number: 30
- Object name: SetLowerTempStatus_XXX (XXX: A/C unit address)
- Object type: Analog Input
- Meaning: This object is used to monitor set lower temperature which the indoor unit is placed.
- · Present_Value property:
- Temperature(°C)
- · Remarks: This object is for indoor units only, and reports the set lower temperature data measured by the indoor units.

Mode Lock (Setting)

- Point number: 31
- Object name: ModeLockCommand_XXX (XXX: A/C unit address)
- Object type: Binary Output
- · Meaning: This object is used to set the mode lock of the A/C's control authority.
- · Present_Value property:
- ACTIVE: Lock (Restricted)
- INACTIVE: Unlock (Not restricted)

Mode Lock (Status)

- Point number: 32
- Object name: ModeLockStatus_XXX (XXX: A/C unit address)
- · Object type: Binary Input
- · Meaning: This object is used to monitor the mode lock of the A/C's control authority.
- · Present_Value property:
- ACTIVE: Lock (Restricted)
- INACTIVE: Unlock (Not restricted)

ENGLISH

Initialization at the Start Up

The system is designed to automatically recognize the connected air conditioners. Therefore, a period of approximately one minute will be required to recognize all the air conditioners after the system is turn on. During this period, the following error PDU may be returned when an object corresponding to an air conditioner is accessed.

ErrorClass = Object; ErrorCode = Unknown_Object

If an attempt is made to read the Object List property of the Device object from an air conditioner during the above period of recognition, the following error PDU will be returned, unless the air conditioner has been recognize:

ErrorClass = Device; ErrorCode = Configuration_In_Progress

Communication error response of ACP BACnet, please refer to **ACP-BACnet Error Response Table on page 205**.

Clock Setting

The Timesynchronization service allows clock settings by the local time.

Furthermore, the UTCTimesycchronization allows clock settings by UTC

Report Function

Event Notification

1) Registration of Event Notification Destination

It is possible to use the AddListElement service to register notification destination information on the Recipient List property of the Notification Class object.

2) Deletion of Event Notification Destination

The RemoveListElement service can be used to delete notification destination information from the Notification Class object.

3) Event Notification Destination in Memory

The registered event notification destination is stored in the memory. When the system is turned on, the event notification destination will be initialized with the stored information. The Event notification destination will be stored five seconds after the registration or deletion.

COV(Change of Value) Notification

A request for COV registration is accepted through the SubscribeCOV service.

1) Setting of Confirmed or Unconfirmed COV

This item is supported according to the BACnet Specifications.

2) Setting of the desired lifetime of the subscription

This item is supported according to the BACnet Specifications.

When COV notification is made at the time of status change, the difference between the registered time and present time will be calculated. If the difference is greater than the registered lifetime of the subscription, the subscription will be judged expired and deleted. Therefore, if a clock time change is made, the lifetime of the subscription may differ from the value that has been set.

3) Memory after Interruption of Power Supply to System

This item is not supported. Registration information is not stored in the memory, and will be lost when the power is turned off. According to the BACnet Specifications, It is not required to guarantee preservation of subscriptions across power failure.

* Supported COV service is shown in the follow table

Service	Object	Product
On/Off (status)	Binary Input object property	Indoor / vent
Lock On/Off (status)	Binary Input object property	Indoor / vent
Mode Lock (status)	Binary Input object property	Indoor
Wind Flow Lock (status)	Binary Input object property	Indoor
Set Upper Temperature (status)	Analog Input object property	Indoor
Set Lower Temperature (status)	Analog Input object property	Indoor
Operation mode (status)	Multistate Input object property	Indoor / vent
Swing (status)	Binary Input object property	Indoor
Filter Sign	Binary Input object property	vent
Fan Speed (status)	Multistate Input object property	Indoor / vent
Set Room Temperature	Analog Value object property	Indoor
Room Temperature	Analog Input object property	Indoor
Alarm	Binary Input object property	Indoor / vent
Error Code	Analog Input object property	Indoor / vent
User mode	Multistate Input object property	vent

NOTES

Troubleshooting

During the use of the ACP BACnet, if unexpected problem occurs, please find the solution by studying the following list. If there is no solution, please access www.lgservice.co.kr to report the problem.

When Tx or Rx LED of CH1~4 port is not blinking during the product installation

When Tx or Rx LED of CH1~4 port is not blinking during the product installation, run it after setting the indoor and outdoor unit groups.

When GUI cannot be operated in Web GUI, which is the operation program of the ACP BACnet

- 1. When GUI cannot be operated in Web GUI, which is the operation program of the ACP BACnet, close Explorer window, and run new Explorer to access again.
- 2. Close all iexplorer.exe process in Task Manager, and access to the ACP BACnet again.
 - After running Task Manager, you can select 'Task Manager' in the popup menu window displayed by clicking the right button of the mouse on the menu bar of the window.

Applications Processes	Performance Netv	vorking	Users	
Image Name	User Name	CPU	Mem Usage	-
sychost.exe	LOCAL SERVICE	00	4,220 K	
sychost.exe	SYSTEM	00	4,164 K	
sychost.exe	NETWORK SERVICE	00	4,060 K	
alg.exe	LOCAL SERVICE	00	3,464 K	
svchost.exe	NETWORK SERVICE	00	3,340 K	
IEXPLORE.EXE	Administrator	00	2,952 K	100
wpabain.exe	Administrator	00	2,876 K	
wscntfy.exe	Administrator	00	1,912 K	
csrss.exe	SYSTEM	00	1,672 K	
jqs.exe	SYSTEM	00	1,420 K	
lsass.exe	SYSTEM	00	1,296 K	
winlogon.exe	SYSTEM	00	624 K	
smss.exe	SYSTEM	00	388 K	
teinet.exe	Administrator	00	328 K	
System	SYSTEM	00	236 K	
cmd.exe	Administrator	00	144 K	
cmd.exe	Administrator	00	144 K	
System Idle Process	SYSTEM	99	28 K	×
Show processes fr	om all users		End Proces	5

When the ventilation equipment is displayed as a network error state (code 242) in LG Web GUI of the ACP BACnet

When the ventilation equipment is displayed as a network error state (code 242) as followed, in Web GUI, which is the web server program of the ACP BACnet, please check the following categories.

- Check if the BUS-A and BUS-B of RS-485 cable are incorrectly connected.
- · Check if there is a communication defect between the remote controller and the indoor unit.
- Check if the PI485 DIP switch is incorrectly set.
- · Check if the indoor unit address for the central control is not set.

The CH242 (network error) keeps occurring and disappearing in the ACP BACnet controller.

Case of incorrect connection of RS-485 communication line

If each communication line is connected altogether as in the following figure, the communication line must be separated.



ACP BACnet

Duplicate setting of the indoor unit address

It is the case of two or more indoor units are set with the same address. It may be the case of several indoor units having the default address 00 by not setting the central control address from the beginning for some indoor units.

In such case, assign unique address to each indoor unit not to have indoor unit with a duplicate address.

It is installed by interfacing 16 room central controller and the ACP BACnet, but some indoor units are not recognized, or not properly performing the central control commands

 It is the case of incorrect setting of the simple central controller (16 room central controller) DIP switch.

Set all simple central controllers to Slave mode, and reset the power.

 If the indoor unit to control with simple central controller is in another physical line as in the following figure, the simple central controller cannot recognize the corresponding indoor unit. Therefore, the connections need to be modified to have the simple central controller to be in the same RS-485 communication line with the indoor unit to control.



When the outdoor unit is Multi V Super Π , and central control is not well performed with 16 room central controller or ACP BACnet, and the indoor units malfunction such as some indoor units automatically becoming locked state or automatically converting to cooling during heating operation

1. PI485 and outdoor unit may not be doubly connected. Please refer to the following picture to check the connection status of the communication line.



Normal communication line connection

When the image of Web GUI is broken and you cannot see the screen such as the temperature well

1. Close Web GUI, and rerun.



Guide to Open Source Software

The following GPL/LGPL execution file and libraries used for this product follows GPL/LGPL license contract.

GPL execution file

Linux kernel 2.4	fdisk	lrzsz
Sysvinit	Inetutils	e2fsprogs
Bash	net-tools	boa http server
busybox	stupid-ftpd	
tinylogin	traceroute	

LGPL library

glibc	linuxthreads	ncurses	zlib

If you request source code to LG Electronics through the following e-mail, we will send them in CD-ROM with the payment necessary for medium and transportation.

da-opensource@lge.com

This suggestion is valid for 3 years after you received this product from LG Electronics. You can receive the original GPL/LGPL license from http://www.systemaircon.com.

Part of the software used for this product follows the following copyright. Copyright ©1998-2002 Daniel Veillard. All Rights Reserved

BIBBs

ACP BACnet Interoperability Building Blocks Supported(BIBBs)

Data Sharing BIBBS

	BIBB Type	Supported	ACP BACnet Service	Initiate	Execute
DS-RP-A	Data Sharing-ReadProperty-A		ReadProperty	×	
DS-RP-B	Data Sharing-ReadProperty-B		ReadProperty		×
DS- RPM-A	Data Sharing- ReadPropertyMultiple-A		ReadPropertyMultiple	×	
DS- RPM-B	Data Sharing- ReadPropertyMultiple-B		ReadPropertyMultiple		×
DS- RPC-A	Data Sharing- ReadPropertyConditiona-A		ReadPropertyConditional	×	
DS- RPC-B	Data Sharing- ReadPropertyConditiona-B		ReadPropertyConditional		×
DS- WP-A	Data Sharing-WriteProperty-A		WriteProperty	×	
DS- WP-B	Data Sharing-WriteProperty-B	•	WriteProperty		×
DS- WPM-A	Sharing- WritePropertyMultiple-A		WritePropertyMultiple	×	
DS- WPM-B	Data Sharing- WritePropertyMultiple-B		WritePropertyMultiple		×
			SubscribeCOV	×	
DS- COV-A	Data Sharing-COV-A		Confirmed COVNotification		×
			Unconfirmed COVNotification		×
			SubscribeCOV		×
DS- COV-B	Data Sharing-COV-B	-	Confirmed COVNotification	×	
			Unconfirmed COVNotification	×	
			SubscribeCOV	×	
DS- COVP-A	Data Sharing-COVP-A		Confirmed COVNotification		×
			Unconfirmed COVNotification		×

	ВІВВ Туре	Supported	ACP BACnet Service	Initiate	Execute
			SubscribeCOV		×
DS- COVP-B	Data Sharing-COVP-B		Confirmed COVNotification	×	
СОУР-В			Unconfirmed COVNotification	×	
DS- COVU-A	Data Sharing-COV- Unsolicited-A		Unconfirmed COVNotification		×
DS- COVU-B	Data Sharing-COV- Unsolicited-B		Unconfirmed COVNotification	×	

Alarm and Event Management BIBBS

	ВІВВ Туре	Supported	ACP BACnet Service	Initiate	Execute
	Alorm and Event Natification A		Confirmed EventNotification		×
AE-N-A	Alarm and Event-Notification-A		Unconfirmed EventNotification		×
	Alarm and Event-Notification	_	Confirmed EventNotification	×	
AE-IN-I-D	Internal-B	•	Unconfirmed EventNotification	×	
AE-N-	Alarm and Event-Notification	_	Confirmed EventNotification	×	
E-B	External-B		Unconfirmed EventNotification	×	
AE- ACK-A	Alarm and Event-ACK-A		AcknowledgeAlarm	×	
AE- ACK-B	Alarm and Event-ACK-B		AcknowledgeAlarm		×
AE- ASUM-A	Alarm and Event-Summary-A		GetAlarmSummary	×	
AE- ASUM-B	Alarm and Event-Summary-B		GetAlarmSummary		×
AE- ESUM-A	Event-Summary-A		GetEnrollment Summary	×	
AE- ESUM-B	Event-Summary-B		GetEnrollment Summary		×
AE- INFO-A	Alarm and Event-Information-A		GetEventInformation	×	
AE- INFO-B	Alarm and Event-Information-B		GetEventInformation		×
AE-LS-A	Alarm and Event-LifeSafety-A		LifeSafetyOperation	×	
AE-LS-B	Alarm and Event-LifeSafety-B		LifeSafetyOperation		×

Scheduling BIBBS

(□:Not supported,∎: Support)

	ВІВВ Туре	Supported	ACP BACnet Service	Initiate	Execute
SCHED-A	Scheduling-A (must support DS-RP-A and DS-WP-A)				
SCHED- I-B	Scheduling-Internal-B (shall support DS-RP-B and DS-WP-B) (shall also support ether DM- TS-B or DS-UTC-B)				
SCHED- E-B	Scheduling-External-B (shall support SCHED-I-B and DS-WP-A)				

Trending BIBBS

	ВІВВ Туре	Supported	ACP BACnet Service	Initiate	Execute	
T-VMT-A	Trending - Viewing and Modifying Trends-A		ReadRange	×		
T-VMT- I-B	Trending-Viewing and Modifying Trends Internal-B		ReadRange		×	
T-VMT- E-B	Trending-Viewing and Modifying Trends External-B		ReadRange		×	
T-ATR-A	Trending - Automated Trend	Trending - Automated Trend		ConfirmedEvent Notification		×
	Retrieval-A		edEventNoti	×		
T-ATR-B	ATR-B Trending - Automated Trend Retrieval-B		ConfirmedEvent Notification	×		
			edEventNoti		×	

Device Management BIBBS

	ВІВВ Туре	Supported	ACP BACnet Service	Initiate	Execute
DM-	Device Management -	_	Who-Is	×	
DDB-A	Dynamic Device, Binding-A	-	I-Am		×
DM-	Device Management -	_	Who-Is		×
DDB-B	Dynamic Device, Binding-B	-	I-Am	×	
DM-	Device Management -		Who-Has	×	
DOB-A	Dynamic Object, Binding-A		I-Have		×
DM-	Device Management -	_	Who-Has		×
DOB-B	Dynamic Object, Binding-B	-	I-Have	×	
DM- DCC-A	Device Management - DeviceCommunication Control-A		DeviceCommunication Control	×	
DM- DCC-B	Device Management - DeviceCommunication Control-B		DeviceCommunication Control		×
	A-PT-A Device Management -		ConfirmedPrivate Transfer	×	
DIVI-PT-A	PrivateTransfer-A		UnconfirmedPrivate Transfer	×	
	Device Management -		ConfirmedPrivate Transfer		×
DIVI-P1-B	PrivateTransfer-B		UnconfirmedPrivate Transfer		×
DM-	Device Management - Text	_	ConfirmedPrivate Transfer	×	
TM-A	Message-A		UnconfirmedPrivate Transfer	×	
DM-	Device Management - Text		ConfirmedPrivate Transfer		×
TM-B	Message-B		UnconfirmedPrivate Transfer		×
DM-TS-A	Device Management - TimeSynchronization-A		TimeSynchronization	×	
DM-TS-B	Device Management - TimeSynchronization-B		TimeSynchronization		×
DM- UTC-A	Device Management - UTCTimeSynchronization-A		UTCTime Synchronization	×	

	ВІВВ Туре	Supported	ACP BACnet Service	Initiate	Execute
DM- UTC-B	Device Management - UTCTimeSynchronization-B		UTCTime Synchronization		×
DM- RD-A	Device Management - ReinitializeDevice-A		ReinitializeDevice	×	
DM- RD-B	Device Management - ReinitializeDevice-B		ReinitializeDevice		×

Device Management BIBBS

ВІВВ Туре		Supported	ACP BACnet Service	Initiate	Execute
DM- BR-A	Device Management - Backup and Restore-A		AtomicReadFile	×	
			AtomicWriteFile	×	
			CreateObject	×	
			ReinitializeDevice	×	
	Device Management - Backup and Restore-B		AtomicReadFile		×
DM- BR-B			DMAtomicWriteFile		×
			ReinitializeDevice		×
DM-R-A	Device Management - Restart-A		Unconfimed COVNotification		×
DM-R-B	Device Management - Restart-B		Unconfimed COVNotification	×	
DM- LM-A	Device Management - List Manipulation-A		AddListElement	×	
			RemoveListElement	×	
DM-	Device Management - List Manipulation-B		AddListElement		×
LM-B			RemoveListElement		×
DM-	Device Management - Object Creation and Deletion-A		CreateObject	×	
OCD-A			DeleteObject	×	
DM- OCD-B	Device Management - Object Creation and Deletion-B		CreateObject		×
			DeleteObject		×
DM-VT-A	Device Management - Virtual Terminal-A		VT-Open	×	
			VT-Close	×	×
			VT-Data	×	×
DM-VT-B	Device Management - Virtual Terminal-B		VT-Open		×
			VT-Close	×	×
			VT-Data	×	×

Network Management BIBBS

BIBB Type		Supported	ACP BACnet Service	Initiate	Execute
NM- CE-A	Network Management - Connection Establishment-A		Establish-Connection- To-Network	×	
			Disconnect-Connection- To-Network	×	
NM- CE-B	Network Management - Connection Establishment-B		Establish-Connection- To-Network		×
			Disconnect-Connection- To-Network		×
DM- BR-A	Network Management - Router Configuration-A		Who-Is-Router-To- Network	×	
			I-Am-Router-To- Network		×
			I-Could-Be-Router-To- Network		×
			Initialize-Routing-Table	×	
			Initialize-Routing-Table- Ack		×
NM- RC-B	Network Management - Router Configuration-B		Who-Is-Router-To- Network	×	×
			I-Am-Router-To- Network	×	×
			Initialize-Routing-Table		×
			Initialize-Routing-Table- Ack	×	

Property Identifier	Property Datatype	ACP BACnet	BNU-BAC	
Object_Identifier	BACnetObjectIdentifier	R	R	
Object_Name	CharacterString	R	R	
Object_Type	BACnetObjectType	R	R	
Present_Value	Unsigned	R1	R	
Description	CharacterString	0	R	
Device_Type	CharacterString	0	-	
Status_Flags	BACnetStatusFlags	R	R	
Event_State	BACnetEventState	R	R	
Reliability	BACnetReliability	O2	-	
Out_Of_Service	Boolean	R	R	
Number_Of_States	Unsigned	R	R	
State_Text	BACnetARRAY[N] of CharacterString	0	-	
Time_Delay	Unsigned	O3	-	
Notification_Class	Unsigned	O3	-	
Alarm_Values	List of Unsigned	O3	-	
Fault_Values	List of Unsigned	O3	-	
Event_Enable	BACnetEventTransitionBits	O3	-	
Acked_Transitions	BACnetEventTransitionBits	O3	-	
Notify_Type	BACnetNotifyType	O3	-	
Event_Time_Stamps	BACnetARRAY[3] of BACnetTimeStamp	O3	-	

Multi - state Input Object Type

Multi - state Output Object Type

Property Identifier	Property Datatype	ACP BACnet	BNU-BAC	
Object_Identifier	BACnetObjectIdentifier	R	R	
Object_Name	CharacterString	R	R	
Object_Type	BACnetObjectType	R	R	
Present_Value	Unsigned	W	W	
Description	CharacterString	0	R	
Device_Type	CharacterString	0	-	

Property Identifier	Property Datatype	ACP BACnet	BNU-BAC	
Status_Flags	BACnetStatusFlags	R	R	
Event_State	BACnetEventState	R	R	
Reliability	BACnetReliability	0	-	
Out_Of_Service	Boolean	R	R	
Number_Of_States	Unsigned	R	R	
State_Text	BACnetARRAY[N] of CharacterString	0	-	
Priority_Array	BACnetPriorityArray	R	-	
Relinquish_Default	Unsigned	R	-	
Time_Delay	Unsigned	01	-	
Notification_Class	Unsigned	01	-	
Feedback_Value	Unsigned	01	-	
Event_Enable	BACnetEventTransitionBits	01	-	
Acked_Transitions	BACnetEventTransitionBits	01	-	
Notify_Type	BACnetNotifyType	01	-	
Event_Time_Stamps	BACnetARRAY[3] of BACnetTimeStamp	O1	-	
Profile_Name	CharacterString	0	-	
ACP-BACnet Error Response Table

Error PDU

Error PDU	Error Class	Error Code
Reading of the object list during the initialization of the LG-NET	Device(0)	Configuration_In_Progress(2)
Request to access to an object not installed.	Object(1)	Unknown_Object(31)
Request to access to a property not installed.	Property(2)	Unknown_Property(32)
Request to write to a prohibited area.	Property(2)	Write_Access_Denied(40)
Request to write in a format different from the property.	Property(2)	Invalid_Datatype(9)
Request to access to a specified index outside the array index range.	Property(2)	Invalid_Array_Index(42)
Request to write a value outside the permissible range.	Property(2)	Value_Out_Of_Range(37)
A COV registration request of more than 10 registration items.	Resource(3)	Other(0)
An Event registration request of more than 10 registration items.	Resource(3)	No_Space_To_Add_List_ Element(19)
Request for the deletion of an element not existing in the list.	Service(5)	Other(0)
Request for the execution of the AddListElement/ RemoveListElement for a property that is not of List type.	Service(5)	Property_Is_Not_List(22)

Reject PDU

Reject PDU	Reject Reason
A propertyID or value overflow or underflow occurred during WritePropertyMultiple operation.	Inconsistent_Parameter(2)
The type of parameter for the execution of the service is different in type.	Invalid_Parameter_Data_Type(3)
An error was detected during tag decoding.	Invalid_Tag(4)
A parameter shortage occurred during the execution of the service.	Missing_Required_Parameter(5)
Too many arguments for the execution of the service.	Too_Many_Arguments(7)
An attempt to execute an unsupported service with confirmation.	Unrecognized_Service(9)

Abort PDU

Reject PDU	Reject Reason
Unable to process due to too many requests beyond the capacity.	Buffer_Overflow(1)
The processing of segments was aborted because an expected APDU was received.	Invalid_APDU_In_This_State(2)
The response side does not support the segment.	Segmentation_Not_Supported(4)

Class A device

expense.

Caution

Notes

pursuant to part 15 of the FCC Rules.

the equipment is operated in a commercial environment.



Disposal of your old appliance

compliance could void the user's authority to operate the equipment.

Changes or modifications not expressly approved by the manufacturer responsible for

This equipment has been tested and found to comply with the limits for a Class A digital device,

These limits are designed to provide reasonable protection against harmful interference when

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own

- When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
- All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
- 4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

