Internal Use Only http://biz.lgservice.com



Outdoor Unit R410A SERVICE MANUAL

MODEL : ARUN Series

CAUTION

Before Servicing the unit, read the safety precautions in General SVC manual. Only for authorized service personnel.

TABLE OF CONTENTS

Safety Precautions	3
Part 1 General Information	10
Model Names	11
External Appearance	13
Combination of Outdoor Units	15
Nomenclature	16
Part 2 Outdoor Units Part 3 PCB Setting and Test Run	17
Part 4 Trouble shooting guide	55

Safety Precautions

To prevent injury to the user or other people and property damage, the following instructions must be followed.

Incorrect operation due to ignoring instruction will cause harm or damage. The seriousness is classified by the following indications.

AWARNING This symbol indicates the possibility of death or serious injury.

ACAUTION This symbol indicates the possibility of injury or damage to properties only.

Meanings of symbols used in this manual are as shown below.



Be sure not to do.

Be sure to follow the instruction.

WARNING

Installation

Have all electric work done by a licensed electrician according to "Electric Facility Engineering Standard" and "Interior Wire Regulations" and the instructions given in this manual and always use a special circuit.

 If the power source capacity is inadequate or electric work is performed improperly, electric shock or fire may result.



• Improper installation by the user may result in water leakage, electric shock, or fire.



Always ground the product.

There is risk of fire or electric shock.





Always intstall a dedicated circuit and breaker.

 Improper wiring or installation may cause fire or electric shock.



Copyright ©2011 LG Electronics. Inc. All right reserved. Only for training and service purposes

For re-installation of the installed product, always contact a dealer or an Authorized Service Center.

• There is risk of fire, electric shock, explosion, or injury.



Do not store or use flammable gas or combustibles near the air conditioner.

• There is risk of fire or failure of product.



Prepare for strong wind or earthquake and install the unit at the specified place.

• Improper installation may cause the unit to topple and result in injury.



When installing and moving the air conditioner to another site, do not charge it with a different refrigerant from the refrigerant specified on the unit.

• If a different refrigerant or air is mixed with the original refrigerant, the refrigerant cycle may malfunction and the unit may be damaged.



Do not install, remove, or re-install the unit by yourself (customer).

• There is risk of fire, electric shock, explosion, or injury.



Use the correctly rated breaker or fuse.

• There is risk of fire or electric shock.



Do not install the product on a defective installation stand.

 It may cause injury, accident, or damage to the product.



Do not reconstruct to change the settings of the protection devices.

• If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by LGE are used, fire or explosion may result.



Ventilate before operating air conditioner when gas leaked out.

• It may cause explosion, fire, and burn.



Securely install the cover of control box and the panel.

• If the cover and panel are not installed securely, dust or water may enter the outdoor unit and fire or electric shock may result.



If the air conditioner is installed in a small room, measures must be taken to prevent the refrigerant concentration from exceeding the safety limit when the refrigerant leaks.

• Consult the dealer regarding the appropriate measures to prevent the safety limit from being exceeded. Should the refrigerant leak and cause the safety limit to be exceeded, harzards due to lack of oxygen in the room could result.



Operation -

Do not damage or use an unspecified power cord.

• There is risk of fire, electric shock, explosion, or injury.



Be cautious that water could not enter the product.

• There is risk of fire, electric shock, or product damage.



Use a dedicated outlet for this appliance.

• There is risk of fire or electrical shock.



Do not touch the power switch with wet hands.

• There is risk of fire, electric shock, explosion, or injury.



When the product is soaked (flooded or submerged), contact an Authorized Service Center.

• There is risk of fire or electric shock.



Take care to ensure that nobody could step on or fall onto the outdoor unit.

• This could result in personal injury and product damage.



Be cautious not to touch the sharp edges when installing.

· It may cause injury.



Do not open the inlet grille of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)

There is risk of physical injury, electric shock, or product failure.



ACAUTION

Installation –

Always check for gas (refrigerant) leakage after installation or repair of product.

Low refrigerant levels may cause failure of product.



Keep level even when installing the product.

• To avoid vibration or water leakage.



Do not install the product where the noise or hot air from the outdoor unit could damage the neighborhoods.

• It may cause a problem for your neighbors.



Do not install the unit where combustible gas may leak.

 If the gas leaks and accumulates around the unit, an explosion may result.



Use power cables of sufficient current carrying capacity and rating.

• Cables that are too small may leak, generate heat, and cause a fire.



Keep the unit away from children. The heat exchanger is very sharp.

• It can cause the injury, such as cutting the finger. Also the damaged fin may result in degradation of capacity. Do not use the product for special purposes, such as preserving foods, works of art, etc. It is a consumer air conditioner, not a precision refrigeration system.

There is risk of damage or loss of property.



When installting the unit in a hospital, communication station, or similar place, provide sufficient protection against noise.

• The inverter equipment, private power generator, high-frequency medical equipment, or radio communication equipment may cause the air conditioner to operate erroneously, or fail to operate. On the other hand, the air conditioner may affect such equipment by creating noise that disturbs medical treatment or image broadcasting.



Do not install the product where it is exposed to sea wind (salt spray) directly.

• It may cause corrosion on the product. Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient operation.





Operation

Do not use the air conditioner in special environments.

• Oil, steam, sulfuric smoke, etc. can significantly reduce the performance of the air conditioner or damage its parts.



Make the connections securely so that the outside force of the cable may not be applied to the terminals.

• Inadequate connection and fastening may generate heat and cause a fire.



Do not block the inlet or outlet.

• It may cause failure of appliance or accident.



Be sure the installation area does not deteriorate with age.

• If the base collapses, the air conditioner could fall with it, causing property damage, product failure, or personal injury.



Install and insulate the drain hose to ensure that water is drained away properly based on the installation manual.

• A bad connection may cause water leakage.



Be very careful about product transportation.

- Only one person should not carry the product if it weighs more than 20 kg.
- Some products use PP bands for packaging. Do not use any PP bands for a means of transportation. It is dangerous.
- Do not touch the heat exchanger fins. Doing so may cut your fingers.
- When transporting the outdoor unit, suspending it at the specified positions on the unit base. Also support the outdoor unit at four points so that it cannot slip sideways.



Safely dispose of the packing materials.

- · Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries.
- Tear apart and throw away plastic packaging bags so that children may not play with them. If children play with a plastic bag which was not torn apart. they face the risk of suffocation.



Do not touch any of the refrigerant piping during and after operation.

It can cause a burn or frostbite.



Do not directly turn off the main power switch after stopping operation.

• Wait at least 5 minutes before turning off the main power switch. Otherwise it may result in water leakage or other problems.



Use a firm stool or ladder when cleaning or maintaining the air conditioner.

Be careful and avoid personal injury.



Turn on the power at least 6 hours before starting operation.

 Starting operation immediately after turning on the main power switch can result in severe damage to internal parts. Keep the power switch turned on during the operational season.



Do not operate the air conditioner with the panels or guards removed.

 Rotating, hot, or high-voltage parts can cause injuries.



Auto-addressing should be done in condition of connecting the power of all indoor and outdoour units. Auto-addressing should also be done in case of changing the indoor unit PCB.



Do not insert hands or other objects through the air inlet or outlet while the air conditioner is plugged in.

 There are sharp and moving parts that could cause personal injury.



Part 1 General Information

1. Model Names	11
1.1 Indoor Unit	11
1.2 Outdoor Unit	11
2. External Appearance	13
2.1 Indoor Unit	13
2.2 Outdoor Unit	14
3. Combination of Outdoor Units	15
4. Nomenclature	16
4.1 Indoor Unit	16
4.2 Outdoor Unit	16

1. Model Names

1.1 Indoor Unit

		Chassis							Capac	ity(Bt	u/h(kW	/))					
Cate	egory	Name	5.5	7.5	9.6	12.3	15.4	19.1	24.2	28.0	30.0	36.2	42.0	48.1	54.0	76.4	95.5
			(1.6)	(2.2)	(2.8)	(3.6)	(4.5)	(5.6)	(7.1)	(8.2)	(8.8)	(10.6)	(12.3)	(14.1)	(15.8)	(22.4)	(28.0)
Wall N	lounted	SE		3SE*2	3SE*2	3SE*2	3SE*2										
(Ge	neral)	S5						ARNU18 3S5*2	ARNU24 3S5*2								
ART	Мікком	SE		ARNU07 3SE*2	ARNU09 3SE*2	ARNU12 3SE*2	ARNU15 3SE*2										
COOL	WIFFOF	S8						ARNU18 3S8*2	ARNU24 3S8*2								
	1 Way	TJ		ARNU07 3TJ*2	ARNU09 3TJ*2	ARNU12 3TJ*2											
	2 Way	TL						ARNU18 3TL*2	ARNU24 3TL*2								
		TR	ARNU05 3TR*2	ARNU07 3TR*2	ARNU09 3TR*2	ARNU12 3TR*2											
Ceiling Cassette		TQ					ARNU15 3TQ*2	ARNU18 3TQ*2									
	4 Way	TP							ARNU24 3TP*2	ARNU28 3TP*2							
		TN			ARNU093 TN*2	ARNU123 TN*2	ARNU15 3TN*2					ARNU36 3TN*2					
		ТМ						ARNU18 3TM*2	ARNU24 3TM*2				ARNU42 3TM*2	ARNU48 3TM*2			
		BH		ARNU07 3BHA2	ARNU09 3BHA2	ARNU12 3BHA2	ARNU15 3BHA2	ARNU18 3BHA2	ARNU24 3BHA2								
	Ligh Statio	BG					ARNU15 3BGA2	ARNU18 3BGA2	ARNU24 3BGA2	ARNU28 3BGA2		ARNU36 3BGA2	ARNU42 3BGA2				
	nigii Static	BR												ARNU483 BRA2			
Ceiling		B8														URNU76 3B8A2	URNU96 3B8A2
Duct	Low Static	B1		ARNU07 3B1G2	ARNU09 3B1G2	ARNU12 3B1G2	ARNU15 3B1G2										
	LOW Static	B2						ARNU18 3B2G2	ARNU24 3B2G2								
	Built In	B3		ARNU07 3B3G2	ARNU09 3B3G2	ARNU12 3B3G2	ARNU15 3B3G2										
	Dantin	B4						ARNU18 3B4G2	ARNU24 3B4G2								
Ceiling	g & Floor	VE			ARNU09 3VEA2	ARNU12 3VEA2											
Ceiling S	Suspended	VJ						3VJA2	URNU24 3VJA2								
	With Case	CE		ARNU07 3CEA2	ARNU09 3CEA2	ARNU12 3CEA2	ARNU15 3CEA2										
Floor		CF						ARNU18 3CFA2	ARNU24 3CFA2								
Standing	Without	CE		ARNU07 3CEU2	ARNU09 3CEU2	ARNU12 3CEU2	ARNU15 3CEU2										
	Case	CF						ARNU18 3CFU2	ARNU24 3CFU2								
Vertic	al AHU	NJ						ARNU18 3NJA2	ARNU24 3NJA2		ARNU30 3NJA2	ARNU36 3NJA2			4		
vertical AHU		NK											ARNU42 3NKA2	ARNU48 3NKA2	ARNU54 3NKA2		

★ *ART COOL- SE/S8(* R:Mirror, V:Silver, B : Blue) *Wall Mounted- A: Basic, L:Plasma

*Ceiling Cassette- A: Basic, C:Plasma

1.2 Outdoor Unit

Heat Pump	A	RUN					
Power Supply	8HP (6Ton)	10HP (8Ton)	12HP (10Ton)	14HP (12Ton)	18HP (14Ton)	20HP (16Ton)	
3Ø, 460V, 60Hz	072DT3	096DT3	121DT3	144DT3	168DT3	192DT3	
Power Supply	22HP (18Ton)	24HP (20Ton)	26HP (22Ton)	28HP (24Ton)	32HP (26Ton)	34HP (28Ton)	
3Ø, 460V, 60Hz	216DT3	240DT3	264DT3	288DT3	312DT3	336DT3	

Power Supply	36HP	38HP	40HP	42HP
	(30Ton)	(32Ton)	(34Ton)	(36Ton)
3Ø, 460V, 60Hz	360DT3	384DT3	408DT3	432DT3

2. External Appearance

2.1 Indoor Unit

Ceiling Cassette- 1Way	Ceiling Concealed Duct - High Static
ARNU073TJ*2 ARNU093TJ*2 ARNU123TJ*2 * A:Basic, C:Plasma	ARNU073BHA2 ARNU363BGA2 ARNU093BHA2 ARNU423BGA2 ARNU123BHA2 ARNU423BGA2 ARNU153BHA2 URNU763B8A2 ARNU183BHA2 URNU963B8A2 ARNU243BHA2 ARNU153BGA2 ARNU243BGA2 ARNU183BGA2 ARNU243BGA2 ARNU183BGA2
Ceiling Cassette- 4Way	Wall Mounted
ARNU053TR*2 ARNU363TN*2 ARNU073TR*2 ARNU423TM*2 ARNU093TR*2 ARNU483TM*2 ARNU123TR*2 ARNU483TM*2 ARNU153TQ*2 ARNU193TN*2 ARNU183TQ*2 ARNU153TN*2	ARNU073SE*2 ARNU153SE*2 ARNU093SE*2 ARNU183S5*2 ARNU123SE*2 ARNU243S5*2 * A:Basic, L:Plasma
ARNU243TP*2 ARNU183TM*2 ARNU283TP*2 ARNU243TM*2 * A:Basic, C:Plasma	
Ceiling Concealed Duct - Low Static	ART COOL Mirror
ARNU073B1G2 ARNU093B1G2 ARNU123B1G2 ARNU243B2G2	ARNU073SE*2 * R:Mirror ARNU093SE*2 V:Silver ARNU123SE*2 B : Blue ARNU153SE*2 ARNU183S8*2 ARNU243S8*2 ARNU243S8*2
Ceiling Concealed Duct – Built-in	Floor Standing
ARNU073B3G2 ARNU153B3G2 ARNU093B3G2 ARNU183B4G2 ARNU123B3G2 ARNU243B4G2	With case ARNU073CEA2 ARNU093CEA2 ARNU123CEA2 ARNU153CEA2 ARNU183CFA2
Ceiling & Floor	AKNU243CFA2
ARNU093VEA2 ARNU123VEA2 Ceiling Suspended URNU183VJA2 URNU243VJA2	WITHOUT CASE ARNU073CEU2 ARNU093CEU2 ARNU123CEU2 ARNU153CEU2 ARNU183CFU2 ARNU243CFU2
Ceiling Cassette -2Way ARNU183TL*2 ARNU243TL*2 * A:Basic, C:Plasma	Vertical AHU ARNU183NJA2 ARNU243NJA2 ARNU303NJA2 ARNU363NJA2 ARNU423NKA2 ARNU423NKA2 ARNU483NKA2 ARNU483NKA2

* These are model names of the basic function.

2.2 Outdoor Unit

2.2.1 460V

CHASSIS	Model Name	Model
UX2	ARUN072DT3	
UX3	ARUN096DT3 ARUN121DT3 ARUN144DT3	
UX3 UX2	ARUN168DT3 ARUN192DT3 ARUN216DT3	
UX3 UX3	ARUN240DT3 ARUN264DT3 ARUN288DT3	
UX3 UX3 UX2	ARUN312DT3 ARUN336DT3 ARUN360DT3	
UX3 UX3 UX3	ARUN384DT3 ARUN408DT3 ARUN432DT3	

3. Combination of Outdoor Units

3.1 460V

Model Name	Capacity	Number	Module(HP)			
woder name	(HP(Ton))	of Units	8	10	12	14
ARUN072DT3	8(6)	1	1			
ARUN096DT3	10(8)	1		1		
ARUN121DT3	12(10)	1			1	
ARUN144DT3	14(12)	1				1
ARUN168DT3	18(14)	2	1	1		
ARUN192DT3	20(16)	2	1		1	
ARUN216DT3	22(18)	2	1			1
ARUN240DT3	24(20)	2		1		1
ARUN264DT3	26(22)	2			1	1
ARUN288DT3	28(24)	2				2
ARUN312DT3	32(26)	3	1	1		1
ARUN336DT3	34(28)	3	1		1	1
ARUN360DT3	36(30)	3	1			2
ARUN384DT3	38(32)	3		1		2
ARUN408DT3	40(34)	3			1	2
ARUN432DT3	42(36)	3				3

A maximum of 42HP can be obtained by combining 8, 10, 12 and 14HP

The biggest module should be master module and others are slaves.

Setting method of master/slave and position of master in the system is explained in the installation chapter.

4. Nomenclature

4.1 Indoor Unit



* Heat recovery ventilator refer to the DX-Coil manual



Part 2 Outdoor Units

ARUN Series

on19

Function

1. Basic control 1.1 Normal operation	22
1.1 Normal operation	
	22
1.2 Compressor control	22
1.3 Master and slave unit's EEV control	23
2. Special control	24
2.1 Oil return control	24
2.2 Defrost control	26
2.3 Stop operation	27
2.4 Oil equalizing control	27
3 Protection control	28
3.1 Pressure protection control	28
3 2 Discharge temperature control	29
3.3 Inverter protection control	29
3.4 Phase detection	
3.5 Pressure switch	30
4. Other control	
4.1 Initial setup	01
4.2 Emergency operation	
4.2 Emergency operation	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Befrigerant Auto Charging 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Befrigerant Checking Function 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU FEV Abnormal Checking Function 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Buning Function 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Runing Function_Cooling Mode 4.8 Integrated Test Runing Function 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Runing Function_Cooling Mode 4.8 Integrated Test Runing Function_Heating Mode 4.8 Auto Back Up Function_Inverter compressor 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Runing Function_Cooling Mode 4.8 Integrated Test Runing Function_Heating Mode 4.8 Auto Back Up Function_Inverter compressor 4.9 Pump Down 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Runing Function_Cooling Mode 4.8 Integrated Test Runing Function_Heating Mode 4.8 Auto Back Up Function_Inverter compressor 4.9 Pump Down 4.10 Pump Out 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Runing Function_Cooling Mode 4.8 Integrated Test Runing Function_Heating Mode 4.8 Auto Back Up Function_Inverter compressor 4.9 Pump Down 4.10 Pump Out 4.11 Auto Back Up Function_Inverter compressor 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Runing Function_Cooling Mode 4.8 Integrated Test Runing Function_Heating Mode 4.8 Auto Back Up Function_Inverter compressor 4.9 Pump Down 4.10 Pump Out 4.11 Auto Back Up Function_Inverter compressor 4.12 Auto Back Up Function_Inverter compressor 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Runing Function_Cooling Mode 4.8 Integrated Test Runing Function_Heating Mode 4.8 Auto Back Up Function_Inverter compressor 4.9 Pump Down 4.10 Pump Out 4.11 Auto Back Up Function_Inverter compressor 4.12 Auto Back Up Function_Constant speed compressor 4.13 Night Low Noise Function 	
 4.2 Emergency operation	
 4.1 Initial output 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Runing Function_Cooling Mode 4.8 Integrated Test Runing Function_Heating Mode 4.8 Auto Back Up Function_Inverter compressor 4.9 Pump Down 4.10 Pump Out 4.11 Auto Back Up Function_Inverter compressor 4.12 Auto Back Up Function_Constant speed compressor 4.13 Night Low Noise Function 4.15 Static pressure compensation mode 	
 4.2 Emergency operation 4.3 Sensor checking function 4.4 Refrigerant Auto Charging 4.5 Refrigerant Checking Function 4.6 IDU EEV Abnormal Checking Function 4.7 Integrated Test Runing Function_Cooling Mode 4.8 Integrated Test Runing Function_Heating Mode 4.8 Auto Back Up Function_Inverter compressor 4.9 Pump Down 4.10 Pump Out 4.11 Auto Back Up Function_Inverter compressor 4.12 Auto Back Up Function_Constant speed compressor 4.13 Night Low Noise Function 4.15 Static pressure compensation mode 	

1. Basic control

1.1 Normal operation

Actuator	Cooling operation	Heating operation	Stop state
Compressor	Fuzzy control	Fuzzy control Fuzzy control	
Fan	Fuzzy control	Fuzzy control	stop
Main EEV	Full open	Fuzzy control	Min. pulse
Subcooling EEV	Fuzzy control	 Normal : minimum pulse Avoiding control of high discharge temperature 	Min. pulse
Indoor Unit EEV	Superheat fuzzy control	Subcooling fuzzy control	Min. pulse

Note : Heating operation is not functional at an outdoor air temperature of 24°C or more. Cooling operation is not functional at an outdoor air temperature of 2°C or less with indoor unit combination of 10% or less

1.2 Compressor control

Fuzzy control : Maintain evaporating temperature(Te) to be constant on cooling mode and condensing temperature(Tc) on heating mode by Fuzzy control to ensure the stable system performance. (Tc:47 ~51°C, Te:2 ~ 5°C)

(1) Cooling mode

Te can be set by initial dip switch setting. (Normal mode, capacity up mode, and energy save mode)

(2) Heating mode

Tc can be set by initial dip switch setting. (Normal mode, capacity up mode, and energy save mode)

Note: By setting dip switch, Te and Tc are decided simultaneously.



1.3 Master and slave Unit's EEV control

- (1) Main EEV control Main EEV operates with fuzzy control rules to keep the degree of super Heat(Superheat) (about 3°C)at the evaporator outlet stable during heating mode The degree of Superheat = Tsuction - Tevaporation Tsuction : temperature at suction pipe sensor(°C) Tevaporation : evaporation temperature equivalent to low pressure(°C)
- (2) Subcooling EEV control(about 15°C)

Subcooling EEV works with fuzzy rules to keep the degree of Subcool at the outlet of subcooler during cooling mode

The degree of Subcool = Tcondensation - Tliquid

Tliquid : temperature at outlet of subcooler(°C)

Tcondensation : condensation temperature equivalent to high pressure(°C)

(3) Avoiding excessive high discharge temperature : when main EEV opens some given opening (R22 : 1000pls, R410A : 800 pls) and discharge temperature is above 90°C in heating operation, subcooling EEV may control the "subcooling out temperature-evaporating temperature" to be some given difference.

2. Special control

2.1 Oil return control

2.1.1 Oil return control on cooling mode

Oil return operation recovers oil amount in compressor by collecting oil accumulated in pipe. Each cycle component operates as shown on the below table during oil return operation.

Outdoor Unit

Component	Starting	Running	Ending
Inv Compressor	30Hz	Setting Value	30Hz
Constant Speed Compressor	OFF	ON	OFF
FAN	Normal control	Normal control	Normal control
Main EEV	Max. pulse	Max. pulse	Max. pulse
Subcooling EEV	Normal control	Min. pluse	85 pulse
4way valve	OFF	OFF	OFF
Hot gas bypass valve	Normal control	Normal control	Normal control

Indoor Unit

Component	Starting	Running	Ending
Fan	Normal control	OFF	Normal control
Thermo on unit EEV	Normal control	Normal control	Normal control
Thermo off unit EEV	40 pulse	400 pulse	40 pulse
Oil return signal	OFF	ON	OFF

■ Oil return operation time : 3 min for running step

Starting condition:every 8 hours operate

Oil return process ends if compressor protection control starts

2.1.2 Oil return control on heating mode

Outdoor Unit

Component	Starting	Running	Ending
Inv Compressor	50Hz	Setting Value	50Hz
Constant Speed Compressor	OFF	ON	OFF
FAN	Normal control	Normal control	Normal control
Main EEV	Max. pulse	Max. pulse	Max. pulse
Subcooling EEV	Normal control	Min. pulse	100 pulse
4way valve	ON	OFF	ON
Hot gas bypass valve	Normal control	Normal control	Normal control

Indoor Unit

Component	Starting	Running	Ending
Fan	Normal control	OFF	Normal control
Thermo on unit EEV	Normal control	400~800 pulse	Normal control
Thermo off unit EEV	80~130 pulse	400~800 pulse	80~130 pulse

■ Oil return operation time : 3 min for running step

Starting condition:same as cooling mode

■ Oil return process ends if compressor protection control starts

2.2 Defrost

Defrost operation eliminates ice accumulated on heat exchanger, recovering performance of heat exchanger. Each cycle component operates as following table during defrost operation.

Outdoor Unit

Component	Starting	Running	Ending
Inv Compressor	30Hz	Setting Value	30Hz
Constant Speed Compressor	OFF	ON	OFF
FAN	Stop	High pressure control	Normal control
Main EEV	Normal control	Max. pulse	Normal control
Subcooling EEV	Normal control	Min. pulse	Normal control
4way valve	On ' OFF	OFF	ON
Hot gas bypass valve	Normal control	Normal control	Normal control

Indoor Unit

Component	Starting	Running	Ending
Fan	OFF	OFF	OFF
Thermo on unit EEV	Normal control	400~800 pulse	Normal control

Ending condition

1) All heat exchanger pipe temperature are above setting temperature for 30 sec.

2) The running time of defrost operation is over 30% of the total heating time

3) If compressor protection control starts by high discharge temperature of compressor etc.

2.3 Stopping operation

2.3.1 Stopping operation on cooling mode

Component	Operation	Note
Inv Compressor	OFF	-
Constant Speed Compressor	OFF	-
FAN	Stop	-
Main EEV	50 pulse	Stop(Min. pulse)
Subcooling EEV	35 pulse	Stop(Min. pulse)
4way valve	OFF	-
Hot gas bypass valve	OFF	OFF after 15 min.

2.3.2 Stopping operation on heating mode

Component	Operation	Note
Inv Compressor	OFF	-
Constant Speed Compressor	OFF	-
FAN	Stop	-
Main EEV	50 pulse	-
Subcooling EEV	35 pulse	Stop(Min. pulse)
4way valve	ON	OFF over 30C air temperature
Hot gas bypass valve	OFF	OFF After 15 min.

2.4 Oil equalizing control

This function prevent oil unbalance between inverter. compressor. and constant speed compressor.

Compressor discharge temperature - Compressor oil temperature \ge Standard oil temperature Compressor oil temperature : Compressor oil balance temperature where the end of capi.

3. Protection control

3.1 Pressure protection control

3.1.1 Pressure control on cooling mode

High pressure control

Pressure Range	Compressor	Fan
P _d ≥ 4003 kPa	Stop	Stop
Pd > 3807 kPa	-5Hz/ 4sec.	+100RPM/4sec.
Pd ≥ 3644 kPa	Frequency holding	Normal control
Pd < 3644 kPa	Normal control	

■ Low pressure control

Pressure Range	Compressor	Fan
$Ps \le 150kPa$, 1 minute later operation	Stop	Stop
Ps ≤ 346kPa, 1 minute before operation	-5Hz/4s	-100RPM/ 4sec.
Ps ≤ 399kPa	Normal control	Frequency holding

* Frequency holding : frequency (or RPM) is not increasing (can decrease)

3.1.2 Pressure control on heating mode

High pressure control

Pressure Range	Compressor	Fan
Pd ≥ 4003 kPa	Stop	Stop
Pd > 3415 kPa	-5Hz/4sec.	-50RPM/ 4sec.
Pd ≥ 3317 kPa	Normal control	Frequency holding
Pd < 3317 kPa	Normal control	Pd < 3284 N/control

Pressure Range	Compressor	Fan
$Ps \le 150 kPa$, 1minute after operation	Stop	Stop
Ps < 150kPa, 1minute before operation	Inv. Minimum freq. + STD Comp. Off	+100RPM/10sec
Ps < 165kPa, befre 1 minute	Inv15Hz / 10sec	
Ps > 190kPa	Inv. freq. change limite, less than 5Hz	
Ps > 203kPa	Normal Control	

3.2 Discharge temperature control

Outdoor unit control

Temperature range	Compressor	Sub cooling EEV	IDU EEV
Tdis >115C	Off	SC,SH decrease control	SH decrease control
Tdis >108C	-5Hz/10sec.	SC,SH decrease control	SH decrease control
Tdis >100C	Normal control	SC,SH decrease control	SH decrease control

SC : Sub Cooling, SH : Super Heating

3.3 Inverter protection control

	Normal Operation	Frequency Down	System Stop
AC Input Current	33A or less	33A or more	35A or more
Compressor Current	34A or less	34A or more	40A or more

* AC input current is input current of inverter compressor except constant current (current pass through noise filter)

3.4 Phase detection

■ When the product is reversed or missed wiring installation(Power line : R, S, T), it isn't defect or operate for protection of product function and constant speed compressor.

		Single	М		
Reversed Phase R,		Sirigle	541		
		Series	М	S1	S1
			541	542	542
	R,S,T		M+S1(at the same time)	M+S2(at the same time)	
			542	543	543
			M+S1+S2(at the same time)		
			543		
F Missed Phase		Single	М		
			501		
		Series	М	S1	S2
	R,T		501	502	503
			M+S1(at the same time)	M+S2(at the same time)	
			502	503	503
			M+S1+S2(at the same time)		
			503		
		Single	М		
	S		231		
		Series	М	S1	S2
			231	232	233
			M+S1(at the same time)	M+S2(at the same time)	
			232	233	233
			M+S1+S2(at the same time)		
			233		

3.5 Pressure switch

- Main has pressure sensing switch in series between compressor and power relay.
- The state of pressure sensing switch is normally on. It has small electric current from 220V AC. Never touch the connecting terminal with hand nor short two wires directly.

4. Other control

4.1 Initial setup

There are 4 initial setup steps before running. All DIP switch setting must be completed before initial setup.

1) Step 1 : factory setting value display

Factory setting value is displayed in 7 segment on PCB for 24sec. All dip switches must be set properly before step 1.

Power is on

Master model code is displayed (3sec)

Slave1 model code is displayed (3sec)

Slave2 model code is displayed (3sec)

Total capacity including sub units is displayed (2sec)

Heat pump : Display 2 is default value Cooling only : no display

Factory setting(25 is normal)

Model type













- 2) Step 2 : Communication check
 - If all model code is displayed in 7 segment including all Slave unit,
 - communication between outdoor units is normal.
 - If 104* is displayed in 7-segment, check communication wires between outdoor units and Dip switch setting.
- 3) Step 3 : PCB error check
 - After 40 sec, error check begins.
- Master/ Slave unit
 - All errors of units including Slave units are displayed in 7 segment.
 - If communication between main PCB and inverter PCB isn't normal, 52* is displayed in 7-segment If communication between main PCB and fan PCB isn't normal, 105* is displayed in 7-segment. If error is displayed, check corresponding wires.
- 4) Step 4 : Auto addressing of indoor units
 - Auto addressing begins when address(red) button in Main PCB is pressed for 6 sec.
 - During auto addressing, 7 segment on main PCB displays "88"
 - After auto addressing, the number of indoor units is displayed in 7 segment for 30 sec. The address of each indoor unit is displayed on each wired remote controller.

Push address(red) button for 6 sec.





Auto address starts

Auto address is in progress (max. 15 min.)

The number of indoor units is displayed for 30 sec.

Auto address process is finished. Every indoor unit displays its address on wired remote controller and the 7 segment of main PCB is off.







(35 indoor units found)



4.2 Emergency operation

- If a compressor is out of order, the system can be run except the defective compressor by backup function.
- Automatic emergency operation(automatic back up function)

If outdoor unit detect comp defect during operation,, automatic back up mode is set.

- 1) Inverter compressor automatic emergency operation.
- 2) Constant compressor automatic emergency operation.

Manual emergency operation(Manual back up function)

- 1) Check which compressor is broken.(refer to °∞Trouble Shooting Guide°±)
- 2) Turn off the power.
- 3) Set the dip S/W of defective outdoor unit.
 - Inverter compressor defect : dip S/W No.3
 - Unit defect : dip S/W No.4
- 4) Turn on the power.



Emergency operation with inverter compressor failure should not last 48 hours. \rightarrow It causes other compressor failure.

During the emergency operation, cooling/heating capacity may be lower.

4.3 Sensor checking function Note 1)

• If you set the Dip switch when power is on, the changed setting will not be applied immediately. The changed setting will be enabled only when Power is reset or by pressing Reset button.





Note

1. Sensor checking function is used with refrigerant checking and refrigerant auto charging.

	UX2 (1 Comp)	UX3 (2 Comp)
No. or sensor	6	7

- 2. Check abnormal sensor.
- 3. It is displayed at the LED on the main PCB at each step.
- 4. Reference the sensor error in next page.

- 1. Confirm auto addressing has been performed (Check installed number of IDU).
- 2. The error can be displayed even if the sensor is normal according to installation and temperature condition. If error occurs, check the sensor and judge abnormality.

4.4 Refrigerant Auto Charging (Set 1)

This function charges appropriate amount of refrigerant automatically through cycle operation. It can be used when refrigerant amount Isn't certain because of SVC and leakage.

* Refrigerant charging time is depending on charging amount. (Charging time : About 3min/Kg)



- 1. After installing the refrigerant charging device, **558** as shown in figure, open the valve
- 2. In case air temperature is out of guaranteed temperature, it may end without performing Auto charging
- 3. Refrigerant charging Time may change according to the charging amount. (Abt. 1.5min/lb)

Note



Procedure

- 1. Arrange manifold, capillary assembly, refrigerant vessel and scale
- 2. Connect manifold to the gas pipe service valve of ODU as shown in the figure.
- Connect manifold and Capillary tube.
 Use designated capillary assembly only.
 If designated capillary assembly isn't used, the system may get damaged.
- 4. Connect capillary and refrigerant vessel.
- 5. Purge hose and manifold.
- 6. After **EFR** Is displayed, open the valve and charge the refrigerant

■ Error contents about auto refrigerant charging function

- 1. **329** : Temperature Range Error (In case that IDU or ODU is out of range)
- 2. 2. 2. Low Pressure Descent Error (In case the system runs at low pressure limit for over 10 minutes)
- 3. **349** : Judging rapid refrigerant inflow (In case the liquid refrigerant flows in because of not using designated Capillary Assembly)
- 4. 359 : Instability Error(In case the high/low pressure target doesn't get satisfied for some time after the starting operation)

- 1. Guaranteed temperature range (Error will occur if temperature is out of range) IDU : 20~32°C ODU : 0~43°C
- (this temperature range is specifically for accurate refrigerant charging)
- 2. For refrigerant charging, use designated device only. (Capillary Assembly Set)
- 3. Set the IDU wired remote controller temperature sensing mode as IDU
- 4. Be careful that IDU should not be thermo off.

4.5 Refrigerant Checking Function (Set 2)

This function judges refrigerant leakage and overcharging It can be used with refrigerant auto charging function.



Note

- 1. In case air temperature is out of guaranteed temperature, refrigerant checking function may end without performing refrigerant checking. Use guaranteed temperature range only.
- 2. During the process of judging refrigerant amount, if the cycle isn't stable, refrigerant checking function may end without performing refrigerant checking.

- 1. Guaranteed Temperature range(Error occurs out of guaranteed temperature range) IDU : 20~35°C ODU : 0~43°C
- 2. Set IDU wired remote controller temperature sensor setting as 'IDU'.
- 3. Make certain that IDU doesn't run with thermo off mode during operation.

[Error contents about auto refrigerant charging function]

- 1. **329** : Temperature Range Error (In case that IDU or ODU is out of range)
- 2. 519 : System Unstable Error (In case, After 45 min operating the system, it does not be stable)

How to Cope with Result of Refrigerant checking

- 1. If the temperature is not in guaranteed Temperature range, the system will not execute Refrigerant checking and the system will be OFF.
- 2. Excess of Refrigerant(619) After remove the 20% of calculated total refrigerant, recharge the refrigerant by using Refrigerant Auto Charging Function.
- **3. Scarcity of Refrigerant(629)** Charge the refrigerant by using Refrigerant Auto Charging Function.
- **4. Impossible to Judge(639)** IF the system is not in order, check the other problem except refrigerant.

4.6 Integrated Test Runing Function_Cooling Mode (Set 3)

This function is checking process for normal operation of parts and system on operating system.

- All processes carry out included refrigerant amount judge logic and check normal condition of parts on cooling mode.
- $\boldsymbol{\cdot}$ This function check only normal condition of parts on heating mode.
- Saved data can check using LGMV.



Note

1. Judge the normal condition refer to report of Test Running.

4.7 Integrated Test Runing Function_Heating Mode (Set 4)

The function is checking process for normal operation of parts and system on operationg system.

- All processes carry out included drefrigerant amount judge logic and check normal condition of parts on heating mode.
- This function check only normal condition of parts on heating mode.
- Saved data can check using LGMV.





Note

1. Judge the normal condition refer to report of Test Running.

- 1. Guaranteed Temperature range(Error occurs out of guaranteed temperature range) IDU : 20 ~ 35 °C ODU : 0 ~ 43 °C
- 2. Set IDU wired remote controller temperature sensor setting as 'IDU'.
- 3. Make certain that IDU doesn't run with thermo off mode during operation.

[Error contents about auto refrigerant charging function]

- 1. 329 : Temperature Range Error (In case that IDU or ODU is out of range)
- 2. **509** : System Unstable Error (In case, After 45 min operating the system, it does not be stable)

How to Cope with Result of Refrigerant checking

- 1. If the temperature is not in guaranteed Temperature range, the system will not execute Refrigerant checking and the system will be OFF.
- 2. Excess of Refrigerant(619) After remove the 20% of calculated total refrigerant, recharge the refrigerant by using Refrigerant Auto Charging Function.
- **3. Scarcity of Refrigerant(629)** Charge the refrigerant by using Refrigerant Auto Charging Function.
- **4. Impossible to Judge(639)** IF the system is not in order, check the other problem except refrigerant.

4.8 Pump Down

This function gathers the refrigerant present in the system to ODU

Use this function to store refrigerant of system in ODU for leakage or IDU replacement.



[Note]

If **I** is displayed, close gas SVC V/V of all ODU immediately.

If low pressure descends below 229 kPa, the system turns off automatically. Close the gas SVC V/V immediately.

Caution

- 1.Use pump down function within guaranteed temperature range IDU : 20~32C ODU : 5~40C
- 2. Make certain that IDU doesn't run with thermo off mode during operation
- 3. Maximum operation time of pump down function is 30 min. (in case low pressure doesn't go down)
- 4. Press black+red button during operation to end pump down.(IDU,ODU off)

4.9 Pump Out

This function gathers the refrigerant to other ODU and IDU.

Use this function in case of compressor failure, ODU parts defect, leakage.



If **F (P**) is displayed, close gas SVC V/V of all ODU immediately.

If low pressure descends below 229 kPa, the system turns off automatically. Close gas SVC V/V immediately. This function is operating only Heat Pump model.

Caution

- 1.Use pump out function within guaranteed temperature range
- IDU : 10~30°C
- ODU : 5~40°C
- 2. Make certain that IDU doesn't run with thermo off mode during operation
- 3. Pump out function takes 2~5 min. after compressor start. Make certain that IDU doesn't run with thermo off mode during operation (in case low pressure doesn't go down)
- 4. Press black+red button during operation to end pump out.(IDU,ODU off) $4/7 \rightarrow 5/7$

Example. Slave2 ODU Inv Comp failure



- 1. Close liquid pipe and common pipe of the unit for pump out operation.
- 2. Operate pump out
- 3. Close gas pipe of unit after completion
- 4. End pump out
- 5. Close common pipe of no.1,2.
- 6. Eliminate refrigerant in common pipe after opening the common pipe of corresponding ODU. Replace compressor and perform vacuum.
- 7. Add the refrigerant with auto charging function

4.10 Auto Back Up Function_Inverter compressor

This function allows the system to operate in case of inverter compressor failure by backing up compressor automatically.

SVC can be asked by displaying error to the customer every 6 hours.



4. Error displays continuously at the corresponding ODU.

4.11 Auto Back Up Function_constant speed compressor

This function allows the system to operate in case of constant speed compressor failure by backing up compressor automatically.



Example) Slave1 Unit constant speed Comp failure(No.173)





4.12 Night Low Noise Function

In cooling mode, this function makes the ODU fan operate at low RPM to reduce the fan noise of ODU at night which has low cooling load.

Max. RPM setting method



Note 1)

Setting Method for Fan Max. RPM

Step	Black Button	Red Button
1	1 time	1 time
2	2 time	1 time
3	3 time	1 time
4	4 time	1 time
5	5 time	1 time
6	6 time	1 time
7	7 time	1 time
8	8 time	1 time
9	9 time	1 time

RPM / Time Settings

		Cap	acitv	ludamont	Operation		
Canac	ity(Hn)	8	10~14	Time	Time		
Oapac	ity(i ip)		10/-14	(br)	(br)		
St	ер	Fan Maxir	num RPM	(11)	(11)		
1				8	9		
2	1	790 90	900	6.5	10.5		
3				5	12		
4		680		8	9		
5	2		800	6.5	10.5		
6				5	12		
7						8	9
8	3	620	780	6.5	10.5		
9				5	12		

Noise

	Capacity					
Capacity(Hp)	8 10~14					
Step	Max RPM Noise(dB)					
Standard	58	62				
1	55	59				
2	52	56				
3	49	53				

DIP Switch Settings -



Warning : Please reset Main PCB before starting this function

- 1. Request installer to set the function during installation.
- 2. In case the function is not used, set the dip S/W OFF and reset the power.
- 3. If ODU RPM changes, cooling capacity may go down.

4.13 Vacuum Mode

This function is used for creating vacuum in the system after compressor replacement, ODU parts replacement or IDU addition/replacement.



ODU operation stops during vacuum mode.

4.14 Static pressure compensation mode

This function is used for creating vacuum in the system after compressor replacement, ODU parts replacement or IDU addition/replacement.

High static pressure mode : Set DIP S/W



4.15 Black Box Function

This function saves data immediately before the error occurs in ODU main PCB, and thus making error analysis cause possible.



Saving process : Making Data Save EEP data data saving place select if file save



Part 3 PCB Setting and Test Run

Test Run

1. Checks Before Test Run

1	Check to see whether there is any refrigerant leakage, and slack of power or communication cable.
2	Confirm that 500 V megger shows 2.0 M Ω or more between power supply terminal block and ground. Do not operate in the case of 2.0 M Ω or less. NOTE: Never carry out megaohm check over terminal control board. Otherwise the control board
	would be broken. Immediately after mounting the unit or after leaving it turned off for an extended length of time, the resistance of the insulation between the power supply terminal board and the ground may decrease to approx. 2 M Ω as a result of refrigerant accumulating in the internal compressor. If the insulation resistance is less than 2 M Ω , turning on the main power supply and energizing the crankcase heater for more than 6 hours will cause the refrigerant to evaporate, increasing the insulation resistance.
3	Check if high/low pressure common pipe, liquid pipe and gas pipe valves are fully opened. NOTE: Be sure to tighten caps.
4	Check if there are any problems in automatic addressing Check and confirm that there are no error messages in the display of indoor units or remote controls and LED in outdoor units.
٨	

when cutting main power of the Multi V

- Always apply main power of the outdoor unit during use of product (cooling season/heating season).
- Always apply power before 4 hours to heat the crank case heater where performing test run after installation of product. It may result in burning out of the compressor if not preheating the crank case with the electrical heater for more than 4 hours.(In case of the outdoor temperature below 10°C)

Preheat of compressor

- Start preheat operation for 4 hours after supplying main power.
- In case that the outdoor temperature is low, be sure to supply power 4 hours before operation so that the heater is heated(insufficient heating may cause damage of the compressor.)

2. How to cope with Test Run abnormality

The phenomena from main component failure

Component	Phenomenon	Cause	Check method and Trouble shooting
	Not operating	Motor insulation broken	Check resistance between terminals and chassis
		Strainer clogged	Change strainer
Compressor		Oil leakage	Check oil amount after opening oil port
Stop during runni		Motor insulation failure	Check resistance between terminals and chassis
	Abnormal noise during running	R-S-T misconnection	Check compressor R-S-T connection
Outdoor fan	High pressure error at cooling	Motor failure, bad ventilation around outdoor heat exchanger	Check the outdoor fan operation after being turned the outdoor units off for some time. Remove obstacles around the outdoor units
	Heating failure, fre- quent defrosting	Bad connector contact	Check connector
	No operating sound at applying power	Coil failure	Check resistance between terminals
EEV	Heating failure, frozen outdoor heat exchanger part	EEV clogged	Service necessary
	Low pressure error or discharge temper- ature error	EEV clogged	Service necessary

When system fault occurs, the error code is displayed at indoor unit display or remote control display, the trouble shooting guide is in the service manual

• When CH05/53/11 ERROR occurs, check if auto-addressing has done and communication wiring is ok.

• For detailed information, please refer Multi V Troubleshooting Guide Book.

3. DIP Switch Setting

■ Location of setting Switch

Heat Pump (Main PCB)



DIP switch setting

Checking according to dip switch setting

You can check the setting values of the master outdoor unit from the 7 segment LED. Power reset is required every time the DIP switch setting is changed

Checking the setting of the Master unit

The number is sequentially appeared at the 7 segment in 5 seconds after applying the power. This number represents the setting condition. (For example, represents R410A 30HP) Master model code \rightarrow Slave1 model code \rightarrow Slave2 model code \rightarrow total capacity \rightarrow 2 \rightarrow 25 \rightarrow 140

1 ~255 : Master model code

1~255 : Slave1 model code

1 ~255 : Slave2 model code Refer to table code

1 ~255 : Slave3 model code

8~42HP : HP number(sum of master capacity and slave capacity)

No display : cooling only 2 : heat pump

25 : normal

160 : Model Type (ARUN***DT3)

Example) 28Hp, R410A

 $15 \rightarrow 15 \rightarrow 28 \rightarrow 2 \rightarrow 25 \rightarrow 160$



Product may not properly operate if the relevant DIP switch is not properly setup.

Model Code

Model Code	Unit (HP)	Unit	Ref.
12	8		
13	10	Master &	D410A
14	12	Slave	R410A
15	14		

Setting the DIP switch Heat pump

• If you set the Dip switch when power is on, the changed setting will not be applied immediately.

The changed setting will be enabled only when Power is reset or by pressing Reset button.



	Index	1	2	3	4	5	6	7	8	9	10	11	12	13	14
Heating capacity up		•													
	IDU Fan RPM Control		•												
	Auto charging	•	•					•						×	×
	Refrigerant Checking Function	•	•					٠						×	•
	Integrated test operation function (Cooling)	•	•					×							×
	Integrated test operation function (Heating)	•						×							•
	Inverter backup			•											
	Unit backup				•										
	Non-operation indoor unit EEV adjustment	×	×			•	х	×							
	Indoor unit target subcooling/overheating adjustment	×	×			×	•	×							
	Operation indoor unit EEV adjustment	×	•			•	×	×							
ç	Dry contact					•	•	×							
ctio	Snow removal fuction								•	×					
nuc	Forced defrost								×	•					
ш	Snow removal+Forced defrost								•	•					
	Forced overall defrost							•							•
	Static pressure mode	×	×										×		×
	Nigh low noise operation (Cooling only)												٠	×	٠
	Night low noise operation (Cooling/Heating)												•		•
	Pump down										•				×
	Pump out														•
	Forced oil return operation	×	×					•							х
	Vacuum mode												×	×	•
	Only overall defrost											٠			
	Selector Fan/ All OFF	×	×									•	٠		×
	ODU Address setting												٠	×	×
_ p	Master unit					×	×	×							
D Titin	Slave 1 unit					•	×	٠							
Ses	Slave 2 unit					×	•								

- 1. 'X' mark within the table means that the dip switch must be pulled down. If not, the function may not work properly.
- 2. If the applicable dip switch is not set properly, the product may not work properly.
- 3. When executing the test operation, check the operating condition of the indoor unit and only execute the operation when all indoor units are stopped.
- 4. Auto test operation function does not work for the product where only one indoor unit is connected.
- 5. Cooling Only model is not working on functions of Heat Pump model.

Part 4 Trouble shooting guide

Trouble shooting guide

1. The phenomena from main component failure	57
2. Checking Method for Key Components	58
2.1 Compressor	58
2.2 Fan Motor	59
2.3 Electronic Expansion Valve	60
2.4 Phase Bridge Diode Checking Method	63
2.5 Inverter IPM Checking Method	64
2.6 Fan IPM Checking Method(UX3 chassis)	65
2.7 Fan IPM Checking Method(UX2 chassis)	66
2.8 Pressure Sensor(High/Low Pressure Sensor)	67
2.9 Outdoor Fan	67
2.10 Solenoid Valve	68
2.11 4way Valve	69
2.12 Temperature Sensor	69
2.13 Others	70
3. Self-diagnosis function	71

1. The phenomena from main component failure

The phenomena from main component failure

Component	Phenomenon	Cause	Check method and Trouble shooting
	Not operating	Motor insulation broken	Check resistance between terminals and chassis
		Strainer clogged	Change strainer
Compressor		Oil leakage	Check oil amount after opening oil port
	Stop during running	Motor insulation failure	Check resistance between terminals and chassis
	Abnormal noise during running	U-V-W misconnection	Check compressor U-V-W connection
Outdoor fan	High pressure error in cooling mode operation	Motor failure, bad ventilation around outdoor heat exchanger	Check the fan operation to confirm proper motor functioning. Switch OFF the outdoor unit and remove obstacles, if any, around the HEX. Check connector
	Heating failure, fre- quent defrosting	Bad connector contact	Check resistance between terminals
Outdoor EEV	No operation sound after switching ON the power supply	Coil failure	Service necessary
	Heating failure, frozen outdoor heat exchanger part	EEV clogged	Service necessary
	Low pressure error or discharge temper- ature error	EEV clogged	

When system fault occurs, the error code is displayed on the indoor unit display or remote control display. The trouble shooting guide is available in the service manual.

• When CH05/53/11 ERROR occurs, check if auto-addressing has done and communication wiring is ok.

2. Checking Method for Key Components

2.1 Compressor

Check and ensure in following order when error related with the compressor or error related with power occurs during operation:

No.	Checking Item	Symptom	Countermeasure
1	Is how long power on during	1) Power on for 12 hours or more	* Go to No.2.
		2) Power on for 12 hours or less	* Go to No.2 after applying power for designated time (12 hours).
2	Does failure appears again when starting operation?	1) The compressor stops and same error appears again.	* Check IPM may fail.
	Method to measure insulation resistance $\begin{array}{c} \hline \\ \hline $	2) If output voltage of the inverter is stably output. *1	 * Check coil resistor and insulation resistor. If normal, restart the unit. If same symptom occurs, replace the compressor. * Insulation resistor: 2MW or more Coil resistor: Inveter Constant Checking Temperature U-V 0.438% ±7% 2.19% ±7% 25°C U-W 0.433% ±7% 2.13% ±7% 25°C W-U 0.435% ±7% 2.26% ±7% 25°C
	Figure 2.	3) If output voltage of the inverter is unstable or it is 0V. (When incapable of using a digi- tal tester)	 * Check the IPM. If the IPM is normal, replace the inverter board. * Check coil resistor and insula- tion resistor.

[Cautions when measuring voltage and current of inverter power circuit]

Measuring values may differ depending on measuring tools and measuring circuits since voltage, current in the power supply or output side of the inverter has no since waveform.

Especially, output voltage changes when output voltage of the inverter has a pattern of pulse wave. In addition, measuring values appear largely differently depending on measuring tools.

- If using a movable tester when checking that output voltage of the inverter is constant (when comparing relative voltage between lines), always use an analog tester. Especially exercise particular caution if the output frequency of the inverter is low, when using a movable tester, where change of measured voltage values is large between other lines, when virtually same values appear actually or where there is danger to determine that failure of the inverter occurred.
- 2) You can use rectification voltmeter (→+) if using commercial frequency tester when measuring output values of the inverter (when measuring absolute values). Accurate measuring values cannot be obtained with a general movable tester (For analog and digital mode).

2.2 Fan Motor

Checking Item	Symptom	Countermeasure
(1) The fan motor does not operate. Does failure appears	1) When power supply is abnormal	* Modify connection status in front of or at the rear of the breaker, or if the power terminal console is at frosting condition.
again when starting operation?		* Modify the power supply voltage is beyond speci- fied scope.
	2) For wrong wiring	* For following wiring.
(2) Vibration of the fan		1. Check connection status.
motor is large.		2. Check contact of the connector.
		 Check that parts are firmly secured by tightening screws.
		4. Check connection of polarity.
		5. Check short circuit and grounding.
	3) For failure of motor	* Measure winding resistance of the motor coils. - Panasonic Motor : 9.5 $\Omega \pm 5\%$ (@25°C) - LG Motor : 8.6 $\Omega \pm 7\%$ (@25°C)
	4) For defective fuse5) For failure of circuit board	 * Replace the fuse if there is defect (Fuse 800V 30A). Replace the circuit board in following procedures if problems occur again when powering on and if there are no matters equivalent to items as specified in above 1) through 4). (Carefully check both connector and grounding wires when replacing the circuit board.) 1. Replace only fan control boards. If starting is done, it means that the fan control board has defect. 2. Replace both fan control board and the main board. If starting is done, it means that the fan control has defect. 3. If problems continue to occur even after counter-
		measure of No.1 and No.2, it means that both boards has defect.

2.3 Electronic Expansion Valve



Pulse signal output value and valve operation

	Output state							
	1	2	3	4				
ø1	ON	ON	OFF	OFF				
ø2	ON	ON	ON	ON				
ø3	OFF	OFF	OFF	ON				
ø4	OFF	OFF	OFF	OFF				

Output pulse sequence

- In valve close state: $4 \rightarrow 3 \rightarrow 2 \rightarrow 1 \rightarrow 4$
- In valve open state: $1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 1$
- * 1. If EEV open angle does not change, all of output phase will be OFF
- 2. If output phase is different or continuously in the ON state, motor will not operate smoothly and start vibrating.

EEV valve operation



- At power ON, open angle signal of 1400 pulses output and valve position is set to (a)
 If valve operates smoothly, no noise and vibration occurs and if valve is closed. noise occurs.
- Noise from EEV can be confirmed by touching the EEV surface with a screw driver and listening the EEV noise.
- If liquid refrigerant is in EEV, the noise is lower.

• EEV Coil and body(Outdoor unit)



Remove and assemble the coil



• EEV failure check method

Failure mode	Diagnosis	Repair process	Unit
Microcomputer Driving circuit failure	 1.Disconnect the EEV connector form control board and connect testing LED <l< td=""><td>Check and replace Indoor unit control board</td><td>Indoor unit</td></l<>	Check and replace Indoor unit control board	Indoor unit
EEV locking	1.If EEV is locked, in no load state, the driving motor rotate, and clicking sound always occurs	Replace EEV	Indoor / Outdoor unit
EEV Motor coil short or misconnection	 Check the resistance between coil terminal (red-white, red-yellow, red-orange, red-blue) If the estimated resistance value is in 52 ± 3Ω then the EEV is normal 	Replace EEV	Outdoor unit
	 Check the resistance between coil terminal (brown-white, brown-yellow, brown-orange, brown-blue) If the estimated resistance value is in 150 ± 10Ω then the EEV is normal 	Replace EEV	Indoor unit
Full closing (valve leakage)	 Operate indoor unit with FAN mode and operate another indoor unit with COOLING mode Check indoor unit(FAN mode) liquid pipe temperature (from operation monitor of outdoor unit control board) When fan rotate and EEV is fully closed, if there is any leakage, then the temperature is down If estimated temperature is very low in comparison with suction temperature which is displayed at remote controller then the valve is not fully closed 	If the amount of leakage is much, Replace EEV	Indoor unit

2.4 Phase Bridge Diode Checking Method

Internal circuit diagram

Appearance





- 1. Wait until inverter PCB DC voltage gets discharged, after the main power switch off.
- 2. Pull out all the connectors connected with 3 phase bridge diode.
- 3. Set multi tester in diode mode.
- 4. Measured value should be 0.4~0.7V measuring as below table.
- 5. In case the measured value is different from the table, set multi tester to resistance mode and measure. If the value is small (0 Ω) or high (hundreds M Ω), PCB needs to be replaced.
- 6. In case that bridge diode is damaged, check if inverter PCB assembly(IPM) is needed to be replaced.

Diode terminal Tester terminal	+ terminal: black(-)	- terminal: red(+)
R(~) : red(+)	0.4 V ~ 0.7 V	-
S(~) : red(+)	0.4 V ~ 0.7 V	-
T(~) : red(+)	0.4 V ~ 0.7 V	-
R(~) : black(-)	-	0.4 V ~ 0.7 V
S(~) : black(-)	-	0.4 V ~ 0.7 V
T(~) : black(-)	-	0.4 V ~ 0.7 V

* Red(+) and black(-) are the measuring terminals of multi tester.

- Check the electric parts of c/box, 10 minutes after switching off the main supply and checking DC voltage is discharged. Otherwise, there is chance of getting electric shock.
- There is chance of electric shock by charged voltage.

2.5 Inverter IPM Checking Method



- 1. Wait until inverter PCB DC voltage is discharged after main power off.
- 2. Pull out CN-P1, CN-N1 connectors and U,V,W COMP connector connected with the inverter PCB.
- 3. Set multi tester to resistance mode.
- 4. If the value between P and N terminal of IPM is short(0 Ω) or open(hundreds M Ω), PCB needs to be replaced.(IPM damaged)
- 5. In the measured value with resistance mode should be within 28K Ω ±10%.
- 6. In case measured value is different from the table, PCB needs to be replaced.(PCB damaged).

	P terminal : black (-)	N terminal : red (-)
U terminal : red(+)	28K Ω ± 10%	Open
V terminal : red(+)	28K Ω ± 10%	Open
W terminal : red(+)	28K Ω ± 10%	Open
	P terminal : red(+)	N terminal : red (+)
U terminal : black(-)	Open	28K Ω ± 10%
V terminal : black(-)	Open	28K Ω ± 10%
W terminal : black(-)	Open	28K Ω ± 10%

* Red(+) and black(-) are the measuring terminals of multi tester.

2.6 Fan IPM Checking Method

- 1. Wait until inverter PCB DC voltage gets discharged after the main power switch off.
- 2. Pull out DC connector and U,V,W fan motor connector connected with fan PCB
- 3. Set multi tester in resistance mode .
- 4. If the value between P and N terminal of IPM is small (0Ω) or tens KΩ, PCB needs to be replaced (IPM damaged).
- 5. In case the measured value is open(hundreds K Ω), measure resistance mode, and the value should be within 35 K Ω ±10% as shown below table.
- 6. If the measured value is different from the value given in the table, PCB is needs to be replaced.

	P terminal : black (-)	N terminal : red (-)	
U terminal : red(+)	35K Ω ± 10%	Open	
V terminal : red(+)	35K Ω ± 10%	Open	
W terminal : red(+)	35K Ω ± 10%	Open	
	P terminal : red(+)	N terminal : red (+)	
U terminal : black(-)	Open	35K Ω ± 10%	
V terminal : black(-)	Open	35K Ω ± 10%	
W terminal : black(-)	Open	35K Ω ± 10%	

* Red(+) and black(-) are the measuring terminals of multi tester.



U terminal V terminal W terminal U terminal V terminal W terminal

2.7 Fan IPM Checking Method

- 1. Wait until inverter PCB DC voltage gets discharged after the main power switch off.
- 2. Pull out DC connector and U,V,W fan motor connector connected with fan PCB
- 3. Set multi tester in resistance mode .
- 4. If the value between P and N terminal of IPM is small (0Ω) or tens KΩ, PCB needs to be replaced (IPM damaged).
- 5. In case the measured value is open(hundreds K Ω), measure resistance mode, and the value should be within 35 K Ω ±10% as shown below table.
- 6. If the measured value is different from the value given in the table, PCB is needs to be replaced.

	P terminal : black (-)	N terminal : red (-)
U terminal : red(+)	35K Ω ± 10%	Open
V terminal : red(+)	35K Ω ± 10%	Open
W terminal : red(+)	35K Ω ± 10%	Open
	P terminal : red(+)	N terminal : red (+)
U terminal : black(-)	Open	35K Ω ± 10%
V terminal : black(-)	Open	35K Ω ± 10%
W terminal : black(-)	Open	35K Ω ± 10%

* Red(+) and black(-) are the measuring terminals of multi tester.



2.8 Pressure Sensor(High/Low Pressure Sensor)

Connect manifold gauge to the service valve of outdoor unit, and compare the output of high pressure sensor to the output of low pressure sensor to detect the defect.

below) Compare the output of pressure sensor to the output of manifold gauge pressure using the table below. Read the pressure clearly between black and white as the composition of pressure sensor.



- 1) If the pressure of manifold gauge is 0~1kg/cm², it indicates the pressure got lower due to the leakage of refrigerant. Find the place of leakage and fix it.
- 2) If the difference of the outputs of high and low pressure is in the range of 1kg/cm², the pressure sensor is normal.
- 3) If the difference of the outputs of high and low pressure is over 1kg/cm², the pressure sensor is out of order, it need to be replaced.
- 4) The composition of pressure sensor



The pressure sensor is composed like the circuit picture shown above. If DC 5V voltage flows on red and black wire, voltage would be made between the white and black wire. The pressure which is equivalent to the pressure output is shown in the table above.

2.9 Outdoor Fan

- 1) The outdoor fan is controlled by the inverter motor which can control the number of rotations.
- 2) The outdoor fan is controlled by the high/low pressure of the outdoor unit after the operation of compressor.
- 3) There is possibility that the outdoor fan does not operate due to low capacity operation or low outdoor temperature even if the compressor is operating. This does not mean breakdown of the unit, the fan will start operating if it reaches the set point.

2.10 Solenoid Valve

Check the conformity of the operation of solenoid valve to the output sigh of control board.

1) Hot gas bypass valve

- 1. When the compressor starts operating, hot gas valve will be on for 1 minute. Check if there is operation noise or piping vibration on the solenoid valve.
- 2. To get rid of the difference of high and low pressure of system after stop operating the compressor, turn the valve on after 5 seconds.
- 3. Turn the hot gas valve on if the temperature of compressor suction pipe is lower than ranged temperature.
- 4. Hot gas valve can be kept on by the condition of cycle operation, this does not indicate the breakdown of the unit.
- 5. The change of the operation condition by the operation of solenoid valve can be checked by the before and behind temperature of bypass piping and the sound of refrigerant.
- 6. Insulation resistance in the state of connecting the valve to coil should be over $100m\Omega$ when measure it with DC mega tester(DC 500V).

2) Oil solenoid valve

- 1. It is located in the bottom of accumulator, and it starts operating after some period of time of the compressor operation to provide oil stored in the bottom of the accumulator to the compressor.
- 2. When the compressor starts operating, oil solenoid valve will be on for 2 minutes. Check if there is operation noise or piping vibration on the solenoid valve.
- 3. It turns on right after the compressor stop operating.
- 4. Solenoid valve can turn on and off repeatedly by the condition of cycle operation; this does not indicate the breakdown of the unit.
- 5. Insulation resistance in the state of connecting the valve to coil should be over $100m\Omega$ when measure it with DC mega tester(DC 500V).

2.11 4way Valve

- 1. Keep it off before the outdoor unit is powered on and the indoor unit is turned on.
- 2. Cooling, defrosting, oil recovery : OFF, heating : ON
- 3. When alternating cooling to heating, transform 4 way valve during re-starting for 3 minutes.
- 4. To check the mode of cooling/heating operation of 4 way valve, touch the piping surface of low pressure service valve.
- 5. Refrigerant flowchart of 4 way valve



 Insulation resistance in the state of connecting the valve to coil should be over 100mΩ when measure it with DC mega tester(DC 500V).

2.12 Temperature Sensor

- 1) outdoor temperature sensor : TH1
- 2) Suction pipe(S-pipe) temperature sensor : TH2
- 3) Discharge pipe(D-pipe) temperature sensor : TH3
- 4) Outdoor heat exchanger (center of condenser) temperature sensor :TH2
 - 1. Check the condition of installation and the contact of temperature sensor.
 - 2. Check whether the connector contact of temperature sensor is normal.
 - 3. Measure the resistance of temperature sensor.

	TH1	TH2	TH3
Posistanco	10KΩ±1%(@25°C)	5KΩ±1%(@25°C)	200KΩ±1%(@25°C)
nesisiance	1.07KΩ±3.3%(@85°C)	535Ω±3.3%(@85°C)	28KΩ±7.7%(@85°C)

2.13 Others

Electrolytic capacitor and resistor for voltage distribution

- 1) Disconnect an terminal of voltage distribution resistor from each DC link electrolytic capacitor
- Set the multi meter to resistance mode, connect the probe to +,- terminal of the capacitor. If the estimated resistance value is increase continuously without short(value is 0), then the resistor is normal
- 3) Set the multi meter to resistance mode, confirm that the resistance value of the resistor is around 270 kOhm

Check and replace inferior components

3. Self-diagnosis function

Self-Diagnosis Function

Error Indicator

- This function indicates types of failure in self-diagnosis and occurrence of failure for air condition.
- Error mark is displayed on display window of indoor units and wired remote controller, and 7-segment LED of outdoor unit control board as shown in the table.
- If more than two troubles occur simultaneously, lower number of error code is first displayed.
- After error occurrence, if error is released, error LED is also released simultaneously.

Error Display

1st,2nd LED of 7-segment indicates error number, 3rd LED indicates unit number.

Ex) 211 : No.21 error of master unit 213 : No.21 error of slave2 $011 \rightarrow 051$: No.105 error of master unit

* Refer to the DX-Venitilation manual for DX-Venitilation error code

Display			Title	Cause of Error		
	0	1	-	Air temperature sensor of indoor unit	Air temperature sensor of indoor unit is open or short	
Ind	0	2	-	Inlet pipe temperature sensor of indoor unit	Inlet pipe temperature sensor of indoor unit is open or short	
	0	3	-	Communication error : wired remote con- troller ↔ indoor unit	Failing to receive wired remote controller signal in indoor unit PCB	
oor u	0	4	-	Drain pump	Malfunction of drain pump	
nit rela	0	5	-	Communication error : outdoor unit ↔ indoor unit	Failing to receive outdoor unit signal in indoor unit PCB	
ated e	0	6	-	Outlet pipe temperature sensor of indoor unit	Outlet pipe temperature sensor of indoor unit is open or short	
rror	0 9		-	Indoor EEPROM Error	In case when the serial number marked on EEPROM of Indoor unit is 0 or FFFFFF	
	1	0	-	Poor fan motor operation	Disconnecting the fan motor connector/Failure of indoor fan motor lock	
	1	7	-	Inlet Air temperature sensor of FAU	Air temperature sensor of indoor unit is open or short	
Outdo	2	1	1	Master Outdoor Unit Inverter Compressor IPM Fault	Master Outdoor Unit Inverter Compressor Drive IPM Fault	
			2 1	2	Slave1 Outdoor Unit Inverter Compressor IPM Fault	Slave1 Outdoor Unit Inverter Compressor Drive IPM Fault
or unit					3	Slave2 Outdoor Unit Inverter Compressor IPM Fault
relate	2			1	Inverter Board Input Over Current(RMS) of Master Outdoor Unit	Master Outdoor Unit Inverter Board Input Current excess (RMS)
d erro		2	2	Inverter Board Input Over Current(RMS) of Slave1 Outdoor Unit	Slave1 Outdoor Unit Inverter Board Input Current excess (RMS)	
			3	Inverter Board Input Over Current(RMS) of Slave2 Outdoor Unit	Slave2 Outdoor Unit Inverter Board Input Current excess (RMS)	

Display			Title	Cause of Error						
Outdoor unit related error	2	3	1	Master Outdoor Unit Inverter Compressor DC link Low Voltage1	DC charging is not performed at Master Outdoor Unit after starting relay turn on.					
			2	Slave1 Outdoor Unit Inverter Compressor DC link Low Voltage	DC charging is not performed at Slave1 Outdoor Unit after starting relay turn on.					
						3	Slave2 Outdoor Unit Inverter Compressor DC link Low Voltage	DC charging is not performed at Slave2 Outdoor Unit after starting relay turn on.		
			1	Master Outdoor Unit High Pressure Switch	System is turned off by Master Outdoor Unit high pressure switch.					
	2	4	2	Slave1 Outdoor Unit High Pressure Switch	System is turned off by slave1 Outdoor Unit high pressure switch.					
			3	Slave2 Outdoor Unit High Pressure Switch	System is turned off by slave2 Outdoor Unit high pressure switch.					
			1	Master Outdoor Unit Input Voltage High/ Low Voltage	Master Outdoor Unit input voltage is over 506V or below 300V					
	2	5	2	Slave1 Outdoor Unit Input Voltage High/ Low Voltage	Slave1 Outdoor Unit input voltage is over 506V or below 300V					
			3	Slave2 Outdoor Unit Input Voltage High/ Low Voltage	Slave2 Outdoor Unit input voltage is over 506V or below 300V					
		6	1	Master Outdoor Unit Inverter Compressor Start Failure	The First Start Failure by Master Outdoor Unit Inverter Compressor Abnormality					
	2		2	Slave1 Outdoor Unit Inverter Compressor Start Failure	The First Start Failure by Slave1 Outdoor Unit Inverter Compressor Abnormality					
			3	Slave2 Outdoor Unit Inverter Compressor Start Failure	The First Start Failure by Slave2 Outdoor Unit Inverter Compressor Abnormality					
		8	1	Master Outdoor Unit Inverter DC link High Voltage	System is turned off by Master Outdoor Unit DC Voltage Over Charging					
	2		2	Slave1 Outdoor Unit Inverter DC link High Voltage	System is turned off by Slave1 Outdoor Unit DC Voltage Over Charging					
			3	Slave2 Outdoor Unit Inverter DC link High Voltage	System is turned off by Slave2 Outdoor Unit DC Voltage Over Charging					
	2	9						1	Master Outdoor Unit Inverter Compressor Over Current	Master Outdoor Unit Inverter Compressor Fault OR Drive Fault
			2	Slave1 Outdoor Unit Inverter Compressor Over Current	Slave1 Outdoor Unit Inverter Compressor Fault OR Drive Fault					
			3	Slave2 Outdoor Unit Inverter Compressor Over Current	Slave2 Outdoor Unit Inverter Compressor Fault OR Drive Fault					
	Display			Title	Cause of Error					
----------------------	---------	---	---	--	---					
			1	Master Outdoor Unit Constant Speed Compressor2 High Discharge Temperature	System is turned off by Master Outdoor Uunit Constant Speed Compressor2 High Discharge Temperature					
	3	0	2	Slave1 Outdoor Unit Constant Speed Compressor2 High Discharge Temperature	System is turned off by Slave1 Outdoor Unit Constant Speed Compressor2 High Discharge Temperature					
Outdoor unit related			3	Slave2 Outdoor Unit Constant Speed Compressor2 High Discharge Temperature	System is turned off by Slave2 Outdoor Unit Constant Speed Compressor2 High Discharge Temperature					
			1	Master Outdoor Unit Inverter Compressor High Discharge Temperature	System is turned off by Master Outdoor Unit Inverter Compressor High Discharge Temperature					
	3	2	2	Slave1 Outdoor Unit Inverter Compressor High Discharge Temperature	System is turned off by Slave1 Outdoor Unit Inverter Compressor High Discharge Temperature					
			3	Slave2 Outdoor Unit Inverter Compressor Discharge High Temperature	System is turned off by Slave2 Outdoor Unit Inverter Compressor High Discharge Temperature					
			1	Master Outdoor Unit Constant Speed Compressor1 High Discharge Temperature	System is turned off by Master Outdoor Uunit Constant Speed Compressor1 High Discharge Temperature					
	3	3	2	Slave1 Outdoor Unit Constant Speed Compressor1 High Discharge Temperature	System is turned off by Slave1 Outdoor Unit Constant Speed Compressor1 High Discharge Temperature					
			3	Slave2 Outdoor Unit Constant Speed Compressor1 High Discharge Temperature	System is turned off by Slave2 Outdoor Unit Constant Speed Compressor1 High Discharge Temperature					
		4	1	High Pressure of Master Outdoor Unit	System is turned off by excessive increase of high pressure of Master Outdoor Unit					
error	3		2	High Pressure of Slave1 Outdoor Unit	System is turned off by excessive increase of high pressure of Slave1 Outdoor Unit					
			3	High Pressure of Slave2 Outdoor Unit	System is turned off by excessive increase of high pressure of Slave2 Outdoor Unit					
-		5	1	Low Pressure of Master Outdoor Unit	System is turned off by excessive decrease of low pressure of Master Outdoor Unit					
	3		2	Low Pressure of Slave1 Outdoor Unit	System is turned off by excessive decrease of low pressure of Slave1 Outdoor Unit					
			3	Low Pressure of Slave2 Outdoor Unit	System is turned off by excessive decrease of low pressure of Slave2 Outdoor Unit					
			1	Master Outdoor Unit Low Condensing Ratio Limited	Master Outdoor Unit stayed under low condensing limit for 3 minutes					
	3	6	2	Slave1 Outdoor Unit Low Condensing Ratio Limited	Slave1 Outdoor Unit stayed under low condensing limit for 3 minutes					
			3	Slave2 Outdoor Unit Low Condensing Ratio Limited	Slave2 Outdoor Unit stayed under low condensing limit for 3 minutes					

Display			Title	Cause of Error		
			1	Master Outdoor Unit Inverter Compressor CT Sensor Fault	Master Outdoor Unit Inverter Compressor CT Sensor open or short	
	4	0	2	Slave1 Outdoor Unit Inverter Compressor CT Sensor Fault	Slave1 Outdoor Unit Inverter Compressor CT Sensor open or short	
			3	Slave2 Outdoor Unit Inverter Compressor CT Sensor Fault	Slave2 Outdoor Unit Inverter Compressor CT Sensor open or short	
Outdoor unit rela	4	1	1	Master Outdoor Unit Inverter Compressor Discharge Temperature Sensor Fault	Master Outdoor Unit Inverter Compressor Discharge Temperature Sensor open or short	
			2	Slave1 Outdoor Unit Inverter Compressor Discharge Temperature Sensor Fault	Slave1 Outdoor Unit Inverter Compressor Discharge Temperature Sensor open or short	
			3	Slave2 Outdoor Unit Inverter Compressor Discharge Temperature Sensor Fault	Slave2 Outdoor Unit Inverter Compressor Discharge Temperature Sensor open or short	
	4	2	1	Master Outdoor Unit Low Pressure Sensor Fault	Master Outdoor Unit Low Pressure Sensor open or short	
			2	Slave1 Outdoor Unit Low Pressure Sensor Fault	Slave1 Outdoor Unit Low Pressure Sensor open or short	
ited erro			3	Slave2 Outdoor Unit Low Pressure Sensor Fault	Slave2 Outdoor Unit Low Pressure Sensor open or short	
Ē				1	Master Outdoor Unit High Pressure Sensor Fault	Master Outdoor Unit High Pressure Sensor open or short
	4	3	2	Slave1 Outdoor Unit High Pressure Sensor Fault	Slave1 Outdoor Unit High Pressure Sensor open or short	
-			3	Slave2 Outdoor Unit High Pressure Sensor Fault	Slave2 Outdoor Unit High Pressure Sensor open or short	
			1	Master Outdoor Unit Air Temperature Sensor Fault	Master Outdoor Unit Air Temperature Sensor open or short	
	4	4	2	Slave1 Outdoor Unit Air Temperature Sensor Fault	Slave1 Outdoor Unit Air Temperature Sensor open or short	
			3	Slave2 Outdoor Unit Air Temperature Sensor Fault	Slave2 Outdoor Unit Air Temperature Sensor open or short	

Display			Title	Cause of Error		
			1	Master Outdoor Unit Heat Exchanger Temperature Sensor (Front side) Fault	Master Outdoor Unit Heat Exchanger Temperature Sensor(Front side) open or short	
	4	5	2	Slave1 Outdoor Unit Heat Exchanger Temperature Sensor (Front side) Fault	Slave1 Outdoor Unit Heat Exchanger Temperature Sensor (Front side) open or short	
			3	Slave2 Outdoor Unit Heat Exchanger Temperature Sensor (Front side) Fault	Slave2 Outdoor Unit Heat Exchanger Temperature Sensor(Front side) open or short	
			1	Master Outdoor Unit Suction Temperature Sensor Fault	Master Outdoor Unit Suction Temperature Sensor open or short	
	4	6	2	Slave1 Outdoor Unit Suction Temperature Sensor Fault	Slave1 Outdoor Unit Suction Temperature Sensor open or short	
Outdoor unit related err			3	Slave2 Outdoor Unit Suction Temperature Sensor Fault	Slave2 Outdoor Unit Suction Temperature Sensor open or short	
	4	7	1	Master Outdoor Unit Constant Speed Compressor1 Discharge Temperature Sensor Fault	Master Outdoor Unit Constant Speed Compressor1 Discharge Temperature Sensor open or short	
			2	Slave1 Outdoor Unit Constant Speed Compressor1 Discharge Temperature Sensor Fault	Slave1 Outdoor Unit Constant Speed Compressor1 Discharge Temperature Sensor open or short	
			3	Slave2 Outdoor Unit Constant Speed Compressor1 Discharge Temperature Sensor Fault	Slave2 Outdoor Unit Constant Speed Compressor1 Discharge Temperature Sensor open or short	
Ť		8		1	Master Outdoor Unit Constant Speed Compressor2 Discharge Temperature Sensor Fault	Master Outdoor Unit Constant Speed Compressor 2 Discharge Temperature Sensor open or short
	4		2	Slave1 Outdoor Unit Constant Speed Compressor2 Discharge Temperature Sensor Fault	Slave1 Outdoor Unit Constant Speed Compressor 2 Discharge Temperature Sensor open or short	
-				3	Slave2 Outdoor Unit Constant Speed Compressor2 Discharge Temperature Sensor Fault	Slave2 Outdoor Unit Constant Speed Compressor 2 Discharge Temperature Sensor open or short
			1	Master Outdoor Unit Faulty IPM Temperature Sensor	Master Outdoor Unit IPM Temperature Sensor short/open	
	4	9	2	Slave1 Outdoor Unit Faulty IPM Temperature Sensor	Slave1 Outdoor Unit IPM Temperature Sensor short/open	
			3	Slave2 Outdoor Unit Faulty IPM Temperature Sensor	Slave2 Outdoor Unit IPM Temperature Sensor short/open	

Display			Title	Cause of Error				
			1	Omitting connection of R, S, T power of Master Outdoor Unit	Omitting connection of Master outdoor unit			
	5	0	2	Omitting connection of R, S, T power of Slave1 Outdoor Unit	Omitting connection of Slave1 Outdoor Unit			
			3	Omitting connection of R, S, T power of Slave2 Outdoor Unit	Omitting connection of Slave2 Outdoor Unit			
	5	1	1	Excessive capacity of indoor units	Excessive connection of indoor units compared to capacity of Outdoor Unit			
			1	Communication error : inverter PCB → Main PCB	Failing to receive inverter signal at main PCB of Master Outdoor Unit			
Outdoor unit rela	5	2	2	Communication error : inverter PCB → Main PCB	Failing to receive inverter signal at main PCB of Slave1 Outdoor Unit			
			3	Communication error : inverter PCB → Main PCB	Failing to receive inverter signal at main PCB of Slave2 Outdoor Unit			
	5	531Communication error : indoor unit \rightarrow main PCB of Outdoor Unit		Communication error : indoor unit → main PCB of Outdoor Unit	Failing to receive indoor unit signal at main PCB of Outdoor Unit .			
ted error		4	1	Reverse connection of R, S, T power of Master Outdoor Unit	Reverse connection or omitting connection of R, S, T power of Master Outdoor Unit			
	5		2	Reverse connection of R, S, T power of Slave1 Outdoor Unit	Reverse connection or omitting connection of R, S, T power of Slave1 Outdoor Unit			
							3	Reverse connection of R, S, T power of Slave2 Outdoor Unit
		7			1	Master Outdoor Unit Communication Error with Inverter Controller	Master Outdoor Unit Controller part cannot receive inverter control signals (usually happens after on-boarding)	
	5		2	Slave1 Outdoor Unit Communication Error with Inverter Controller	Slave1 Outdoor Unit Controller part cannot receive inverter control signals (usually happens after on-boarding)			
			3	Slave2 Outdoor Unit Communication Error with Inverter Controller	Slave2 Outdoor Unit Controller part cannot receive inverter control signals (usually happens after on-boarding)			
	5 9 1 Error of series installation		Error of series installation	In the case of installing smaller outdoor unit as master unit				

Display			Title	Cause of Error							
			1	Inverter PCB EEPROM Error of Master Outdoor Unit	Access Error of Inverter PCB of Master Outdoor Unit						
	6	0	2	Inverter PCB EEPROM Error of Slave1 Unit	Access Error of Inverter PCB of Slave1 Outdoor Unit						
			3	Inverter PCB EEPROM Error of Slave2 Unit	Access Error of Inverter PCB of Slave2 Outdoor Unit						
			1	Master Outdoor Unit Fan Lock	Restriction of Master Outdoor Unit						
	6	7	2	Slave1 Outdoor Unit Fan Lock	Restriction of Slave1 Outdoor Unit						
			3	Slave2 Outdoor Unit Fan Lock	Restriction of Slave2 Outdoor Unit						
Outdoor unit related	6		1	Constant1 CT Sensor Error of Master Outdoor Unit	Constant1 CT Sensor open or short of Master Outdoor Unit						
		9	2	Constant1 CT Sensor Error of Slave1 Outdoor Unit	Constant1 CT Sensor open or short of Slave1 Outdoor Unit						
			3	Constant1 CT Sensor Error of Slave2 Outdoor Unit	Constant1 CT Sensor open or short of Slave2 Outdoor Unit						
		0	0	1	Constant2 CT Sensor Error of Master Outdoor Unit	Constant2 CT Sensor open or short of Master Outdoor Unit					
error	7			0	0	0	0	0	2	Constant2 CT Sensor Error of Slave1 Outdoor Unit	Constant2 CT Sensor open or short of Slave1 Outdoor Unit
		3	3	3	1	Instant Over Current(Peak) of Master Outdoor Unit PFC	Instant Over Current(Peak) of Master Outdoor Unit PFC				
	7				3	3	2	Instant Over Current(Peak) of Slave1 Outdoor Unit PFC	Instant Over Current(Peak) of Slave1 Outdoor Unit PFC		
			3	Instant Over Current(Peak) of Slave2 Outdoor Unit PFC	Instant Over Current(Peak) of Slave2 Outdoor Unit PFC						
			1	Master Outdoor Unit Fan CT Sensor Error	Master Outdoor Unit Fan CT Sensor open or short						
	7	5	2	Slave1 Outdoor Unit Fan CT Sensor Error	Slave1 Outdoor Unit Fan CT Sensor open or short						
			3	Slave2 Outdoor Unit Fan CT Sensor Error	Slave2 Outdoor Unit Fan CT Sensor open or short						

Display			Title	Cause of Error											
			1	Master Outdoor Unit Fan DC Link High Voltage Error	Master Outdoor Unit Fan DC Link High Voltage Error										
	7	6	2	Slave1 Outdoor Unit Fan DC Link High Voltage Error	Slave1 Outdoor Unit Fan DC Link High Voltage Error										
Outdoo			3	Slave2 Outdoor Unit Fan DC Link High Voltage Error	Slave2 Outdoor Unit Fan DC Link High Voltage Error										
			1	Master Outdoor Unit Fan Over Current Error	Master Outdoor Unit Fan Current is over 5A										
	7	7	2	Slave1 Outdoor Unit Fan Over Current Error	Slave1 Outdoor Unit Fan is over 5A										
			3	Slave2 Outdoor Unit Fan Over Current Error	Slave2 Outdoor Unit Fan is over 5A										
	7	9	1	Master Outdoor Unit Fan Start Failure Error	Master Outdoor Unit Fan First Position Sensing Failure										
unit rela			2	Slave1 Outdoor Unit Fan Start Failure Error	Slave1 Outdoor Unit Fan First Position Sensing Failure										
ted error			3	Slave2 Outdoor Unit Fan Start Failure Error	Slave2 Outdoor Unit Fan First Position Sensing Failure										
			1	Master Outdoor Unit Main PCB EEPROM Error	Communication Fail Between Master Outdoor Unit Main MICOM and EEPROM or omitting EEPROM										
	8	6	2	Slave1 Outdoor Unit Main PCB EEPROM Error	Communication Fail Between Slave1 Outdoor Unit Main MICOM and EEPROM or omitting EEPROM										
													3	Slave2 Outdoor Unit Main PCB EEPROM Error	Communication Fail Between Slave2 Outdoor Unit Main MICOM and EEPROM or omitting EEPROM
			1	Master Outdoor Unit Fan PCB EEPROM Error	Communication Fail Between Master Outdoor Unit Fan MICOM and EEPROM or omitting EEPROM										
	8	7	2	Slave1 Outdoor Unit Fan PCB EEPROM Error	Communication Fail Between Slave1 Outdoor Unit Fan MICOM and EEPROM or omitting EEPROM										
			3	Slave2 Outdoor Unit Fan PCB EEPROM Error	Communication Fail Between Slave2 Outdoor Unit Fan MICOM and EEPROM or omitting EEPROM										

	Display			Title	Cause of Error														
				1	Communication Error Between Master Outdoor Unit and Other Outdoor Unit	Failing to receive Slave Unit signal at main PCB of Master Outdoor Unit													
	1	0	4	2	Communication Error Between Slave1 Outdoor Unit and Other Outdoor Unit	Failing to receive master and other Slave Unit signal at main PCB of Slave1 Outdoor Unit													
				3	Communication Error Between Slave2 Outdoor Unit and Other Outdoor Unit	Failing to receive master and other Slave Unit signal at main PCB of Slave2 Outdoor Unit													
				1	Master Outdoor Unit Fan PCB Communication Error	Failing to receive fan signal at main PCB of master unit.													
	1	0	5	2	Slave1 Outdoor Unit Fan PCB Communication Error	Failing to receive fan signal at main PCB of Slave1 unit.													
Outdoor unit related				3	Slave2 Outdoor Unit Fan PCB Communication Error	Failing to receive fan signal at main PCB of Slave2 unit.													
		0		1	Master Outdoor Unit FAN IPM Fault Error	Instant Over Current at Master Outdoor Unit Fan IPM													
	1		6	2	Slave1 Outdoor Unit FAN IPM Fault Error	Instant Over Current at Slave1 Outdoor Unit Fan IPM													
				3	Slave2 Outdoor Unit FAN IPM Fault Error	Instant Over Current at Slave2 Outdoor Unit Fan IPM													
			7		1	Master Outdoor Unit Fan DC Link Low Voltage Error	Master Outdoor Unit Fan DC Link Input Voltage is under 380V												
error	1	0		2	Slave1 Outdoor Unit Fan DC Link Low Voltage Error	Slave1 Outdoor Unit Fan DC Link Input Voltage is under 380V													
																			3
											1	Master Outdoor Unit Liquid pipe Temperature Sensor Error	Liquid pipe temperature sensor of Master Outdoor Unit is open or short						
	1	1	3	2	Slave1 Outdoor Unit Liquid pipe Temperature Sensor Error	Liquid pipe temperature sensor of slave1 Outdoor Unit is open or short													
				3	Slave2 Outdoor Unit Liquid pipe Temperature Sensor Error	Liquid pipe temperature sensor of slave2 Outdoor Unit is open or short													
				1	Master Outdoor Unit Subcooling Outlet Temperature Sensor Error	Master Outdoor Unit Subcooling Outlet Temperature Sensor open or short													
	1	1	5	2	Slave1 Outdoor Unit Subcooling Outlet Temperature Sensor Error	Slave1 Outdoor Unit Subcooling Outlet Temperature Sensor open or short													
				3	Slave2 Outdoor Unit Subcooling Outlet Temperature Sensor Error	Slave2 Outdoor Unit Subcooling Outlet Temperature Sensor open or short													

Display			iy		Title	Cause of Error																
				1	Failure of operation mode conversion at Master Outdoor Unit	Pressure unbalance between Outdoor Units																
	1	5	1	2	Failure of operation mode conversion at Slave1 Outdoor Unit	Pressure unbalance between Outdoor Units																
				3	Failure of operation mode conversion at Slave2 Outdoor Unit	Pressure unbalance between Outdoor Units																
-				1	Master Outdoor Unit Constant Speed Compressor Fault	Comp locking, Check Valve leakage, comp dielectric break down at Master Outdoor Unit																
	1	7	3	2	Slave1 Outdoor Unit Constant Speed Compressor Fault	Comp locking, Check Valve leakage, comp dielectric at Slave1 Outdoor Unit																
Outdoor unit related				3	Slave2 Outdoor Unit Constant Speed Compressor Fault	Comp locking, Check Valve leakage, comp dielectric at Slave2 Outdoor Unit																
		7	1	1	1			1	Master outdoor unit rated speed 2 con- denser over-current	Master Outdoor Unit rated speed 2 condenser burned / locked or fault by over-current												
	1		4	2	Slave1 outdoor unit rated speed 2 con- denser over-current	Slave1 Outdoor Unit rated speed 2 condenser burned / locked or fault by over-current																
						3	Slave2 outdoor unit rated speed 2 con- denser over-current	Slave2 Outdoor Unit rated speed 2 condenser burned / locked or fault by over-current														
		8	2	2	2	2	2	2	2	2	2	1	Master outdoor unit Main Board Main-Sub Micom communication error	Master Outdoor Unit Main Board Main-Sub Micom communi- cation failed								
error	1											2	2	2	2	2	2	2	2	2	Slave1 outdoor unit Main Board Main-Sub Micom communication error	Slave1 Outdoor Unit Main Board Main-Sub Micom communi- cation failed
																				-	3	Slave2 outdoor unit Main Board Main-Sub Micom communication error
-					1	Excessive increase of Master Outdoor Unit Fan PCB Heat Sink Temperature	Master Outdoor Unit Fan Inverter PCB Temperature is Over 95°C															
	1	9	3	2	Excessive increase of Slave1 Outdoor Unit Fan PCB Heat Sink Temperature	Slave1 Outdoor Unit Fan Inverter PCB Temperature is Over 95°C																
			-	3	Excessive increase of Slave2 Outdoor Unit Fan PCB Heat Sink Temperature	Slave2 Outdoor Unit Fan Inverter PCB Temperature is Over 95°C																
				1	Master Outdoor Unit Fan PCB Heat Sink Temperature Sensor Error	Master Outdoor Unit Fan PCB Heat Sink Temperature Sensor open or short																
	1	9	4	2	Slave1 Outdoor Unit Fan PCB Heat Sink Temperature Sensor Error	Slave1 Outdoor Unit Fan PCB Heat Sink Temperature Sensor open or short																
				3	Slave2 Outdoor Unit Fan PCB Heat Sink Temperature Sensor Error	Slave2 Outdoor Unit Fan PCB Heat Sink Temperature Sensor open or short																

Error No.	Error Type	Error Point	Main Reasons
01	Indoor unit air sensor error		1 Indeer unit DCD wrong connection
02	Indoor unit pipe inlet sensor error	Indoor unit	 2. Indoor unit PCB failure 3. Sensor problem (main reason)
06	Indoor unit pipe outlet sensor error	open/short	
17	Inlet Air temperature sensor error of FAU		



** In case the value is more than $100k\Omega$ (open) or less than 100Ω (short), Error occurs

Refer: Resistance value maybe change according to temperature of temp sensor, It shows according to criteria of current temperature(±5% margin) → Normal Air temp sensor: $10^{\circ}C = 20.7k\Omega$: $25^{\circ}C = 10k\Omega$: $50^{\circ}C = 3.4k\Omega$ Pipe temp sensor: $10^{\circ}C = 10k\Omega$: $25^{\circ}C = 5k\Omega$: $50^{\circ}C = 1.8k\Omega$



Error No.	Error Type	Error Point	Main Reasons
03	No communication between cabled remote controller & indoor unit	The remote controller did not receive the sig- nal from indoor unit during specific time	 Remote controller fault Indoor unit PCB fault Connector fault, Wrong connection Communication cable problem



* If there is no remote controller to replace : Use another unit's remote controller doing well

- ** Check cable : Contact failure of connected portion or extension of cable are main cause Check any surrounded noise (check the distance with main power cable)
 → make safe distance from the devices generate electromagnetic wave
- *** After replacing indoor unit PCB, do Auto Addressing & input unit's address if connected to central controller. (All the indoor units connected should be turned on before Auto Addressing



Copyright ©2010 LG Electronics. Inc. All right reserved. Only for training and service purposes

Error No.	Error Type	Error Point	Main Reasons
04	Drain pump error	Float switch is open due to rising of condensate water level because of drain pump fault or drain pipe clogging	 Drain pump/float switch fault Improper drain pipe location, clog- ging of drain pipe Indoor unit PCB fault





A:Point to check rotating



*** Indoor PCB drain pump connector (Check input of 220V)(Marked as **CN-DPUMP)**



[***] Standard of drain pipe head height / slope



Error No.	Error Type	Error Point	Main Reasons
05	Indoor & Outdoor unit communication error	No signal communication between indoor & outdoor units.	 Auto addressing is not done Communication cable is not connected Short circuit of communication cable Indoor unit communication circuit fault Outdoor unit communication circuit fault Not enough distance between power and communication cable?





 * (Note1) communication from IDU is normal if voltage fluctuation(-9V ~ +9V) exists when checking DC voltage of communication terminal between IDU and ODU



 If the DC voltage between communication terminal A, B of indoor unit is fluctuate within (-9V~+9V) then communication from outdoor unit is normal



Copyright ©2010 LG Electronics. Inc. All right reserved. Only for training and service purposes

Error No.	Error Type	Error Point	Main Reasons
09	Indoor unit EEPROM error		 Error developed in communication between the micro- processor and the EEPROM on the sur- face of the PCB. ERROR due to the EEPROM damage

- Replace the indoor unit PCB, and then make sure to perform Auto addressing and input the address of central control

Error No.	Error Type	Error Point	Main Reasons
10	Indoor unit BLDC fan motor failure	Indoor BLDC fan motor feedback signal is absent (for 50 sec.)	 Motor connector connection fault Indoor PCB fault Motor fault



* It is normal when check hall sensor of indoor fan motor as shown below



Each termainl with the tester

Tester		Normal resistance(10%)	
+	-	TH chassis	TD chassis
1	4	œ	∞
5	4	hundreds kΩ	hundreds kΩ
6	4	∞	∞
\bigcirc	4	hundreds kΩ	hundreds kΩ

<Checking connection state of fan motor connector>



** Replace the indoor unit PCB, and then make sure to do Auto addressing and input the address of central control

(Notice: The connection of motor connector to PCB should be done under no power supplying to PCB)

Error No.	Error Type	Error Point	Main Reasons
21* Master 211 Slave1 212 Slave2 213	Inverter PCB Assy IPM Fault occur	IPM self protection circuit activation (Overcurrent/IPM overheat- ing/Vcc low voltage)	 Over current detection at Inverter compressor (U,V,W) Compressor damaged (insulation damaged/Motor damaged) IPM overheating (Heat sink fan damaged/Heat sink fan connector disconnected/Heat sink disassembled) Inverter compressor terminal disconnected or loose Inverter PCB assembly damaged ODU input current low



* Measuring resistance between each terminal of compressor



* IPM joining point

* Compressor wire connector connection point





Check joining conditon

Error No.	Error Type	Error Point	Main Reasons
22* Master 221 Slave1 222 Slave2 223	AC Input Current Over Error	Inverter PCB Assembly input 3 phase power current is over limited value(22A)	 Overload operation (Pipe clogging/Covering/EEV defect/Ref. overcharge) Compressor damage(Insulation damage/Motor damage) Input voltage low Power Line Misconnection Inverter PCB Assembly damage (Input current sensing part)



* Measuring resistance between each terminal of compressor



* Compressor wire connector connection



* Measuring input voltage



* Inverter PCB & bridge diode wiring



Check joining condition





Error No.	Error Type	Error Point	Main Reasons
23* Master 231 Slave1 232 Slave2 233	Inverter Compressor DC Link Low Voltage	DC Voltage isn't charged after starting relay on	 DC Link terminal misconnection/terminal contact fault Starting relay damage Condenser damage Inverter PCB assembly damage (DC Link voltage sensing part) Input voltage low



* Inverter PCB & bridge diode wiring





* Measuring input voltage





Error No.	Error Type	Error Point	Main Reasons
24* Master 241 Slave1 242 Slave2 243	Excessive rise of discharge pressure in outdoor com- pressor	Compressor off due to the high pressure switch in outdoor unit	 Defective high pressure switch Defective fan of indoor unit or outdoor unit Check valve of compressor clogged Pipe distortion due to the pipe damage Refrigerant overcharge Defective LEV at the indoor or outdoor unit . Covering or clogging(Outdoor covering during the cooling mode /Indoor unit filter clogging during the heating mode) SVC valve clogging Defective outdoor PCB



Error No.	Error Type	Error Point	Main Reasons
25* Master 251 Slave1 252 Slave2 253	Input Voltage high/low	Input voltage is over limited value of the product (173V or less, 289V or more)	 Input voltage abnormal (T-N) Outdoor unit inverter PCB assembly damage (input voltage sensing part)



Error No.	Error Type	Error Point	Main Reasons
26* Master 261 Slave1 262 Slave2 263	Inverter compressor starting failure Error	Starting failure because of compressor abnormality	 Overload operation (Pipe clogging/Covering/EEV defect/Ref. overcharge) Compressor damage (Insulation damage/Motor damage) Compressor wiring fault ODU inverter PCB damage (CT)



* Measuring resistance between each terminal of compressor



* Compressor wire connection



Error No.	Error Type	Error Point	Main Reasons
28* Master 281 Slave1 282 Slave2 283	Inverter DC link high voltage error	Inv PCB DC link voltage supplied over 780V	 Input voltage abnormal (R,S,T) ODU inverter PCB damage (DC Link voltage sensing part)



Noise filter output(lower part)

Noise filter input (upper part)

Error No.	Error Type	Error Point	Main Reasons
29* Master 291 Slave1 292 Slave2 293	Inverter compressor over current	Inverter compressor input current is over 30A	 Overload operation (Pipe clogging/Covering/EEV defect/Ref. overcharge) Compressor damage(Insulation damage/Motor damage) Input voltage low ODU inverter PCB assembly damage



* Measuring resistance between each terminal of compressor



* Measuring input voltage



* Compressor wire connection



Error No.	Error Type	Error Point	Main Reasons
30* Master 301 Slave1 302 Slave2 303	Master Outdoor Unit Constant Speed Compressor 2 Discharge Temperature Sensor	System is turned off by Master Outdoor Unit Constant Speed Compressor 2 Discharge Temperature Sensor	 Constant Speed Compressor 2 Discharge Temperature Sensor Fault Refrigerant Short/Leakage EEV Fault
32* Master 321 Slave1 322 Slave2 323	Over-increase discharge temperature of inverter com- pressor at main outdoor unit	Compressor is off because of over-increase discharge temperature of inverter compressor	 Temperature sensor defect of inverter compressor discharge pipe Refrigerant shortage / leak EEV defect Liquid injection valve defect
33* Master 331 Slave1 332 Slave2 333	Over-increase discharge temperature of constant compressor 1 at main con- stant outdoor and sub con- stant outdoor unit	Compressor is off because of over-increase discharge temperature of constant compressor 1 at main and sub outdoor unit	 Temperature sensor defect of constant compressor 1 discharge pipe? Refrigerant shortage/leak EEV defect Liquid injection valve defect



Error No.	Error Type	Error Point	Main Reasons
34* Master 341 Slave1 342 Slave2 343	Over-increase of dis- charge pressure of compressor	Error happens because of 3 times successive compres- sor off due to over- increase of high pres- sure by high pressure sensor	 Defect of high pressure sensor Defect of indoor or outdoor unit fan Deformation because of damage of refrigerant pipe Over-charged refrigerant Defective indoor / outdoor unit EEV When blocked Outdoor unit is blocked during cooling Indoor unit filter is blocked during heating SVC valve is clogged PCB defect of outdoor unit



Copyright ©2010 LG Electronics. Inc. All right reserved. Only for training and service purposes

Error No.	Error Type	Error Point	Main Reasons
35* Master 351 Slave1 352 Slave2 353	Excessive drop of discharge pressure of compressor	Error happens because of 3 times successive compres- sor off due to exces- sive drop of low pres- sure by the low pres- sure sensor	 Defective low pressure sensor Defective outdoor/indoor unit fan Refrigerant shortage/leakage Deformation because of damage of refrigerant pipe Defective indoor / outdoor unit EEV Covering / clogging (outdoor unit covering during the cooling mode/ indoor unit filter clogging during heating mode) SVC valve clogging Defective outdoor unit PCB Defective indoor unit pipe sensor



- 103 -

Error No.	Error Type	Error Point	Main Reasons
40* Master 401 Slave1 402 Slave2 403	Inverter compressor CT sensor error	Micom input voltage isn't within 2.5V ±0.3V at initial state of power supply	 Input voltage abnormal (T-S) ODU inverter PCB damage (CT sensing part)



Error No.	Error Type	Error Point	Main Reasons
41* (Inverter) Slave1 472 Master 411 Slave2 473 Slave1 412 48* Slave2 413 (Constant 2) 47* Master 481 (Constant 1) Slave1 482 Master 471 Slave2 483	Compressor dis- charge pipe tem- perature sensor error	Sensor measurement valve is abnormal (Open/Short)	 Defective connection of the compressor discharge pipe tem- perature sensor Defective discharge pipe com- pressor sensor of the compres- sor (open/short) Defective outdoor PCB





* Error is generated if the resistance is more than 5M(open) and less than 2k (short)

Note: Standard values of resistance of sensors at different temperatures (5% variation) 10C = 362k : 25C = 200k : 50C = 82k : 100C = 18.5k



Error No.	Error Type	Error Point	Main Reasons
42* Master 421 Slave1 422 Slave2 423	Sensor error of low pressure	Abnormal value of sensor (Open/Short)	 Bad connection of low pressure connector Defect of low pressure connector (Open/Short) Defect of outdoor PCB
43* Master 431 Slave1 432 Slave2 433	Sensor error of high pressure	Abnormal value of sensor (Open/Short)	 Bad connection of high pressure connector Defect of high pressure connector (Open/Short) Defect of outdoor PCB



Low pressure sensor

High pressure sensor Pressure sensor connector

Pressure sensor connector



Error No.	Error Type	Error Point	Main Reasons
44* Master 441 Slave1 442 Slave2 443	Sensor error of outdoor air temper- ature	Abnormal value of sensor (Open/Short)	 Bad connection of air temperature connector Defect of air temperature connector(Open/Short) Defect of outdoor PCB
45* Master 451 Slave1 452 Slave2 453	Piping temperature sensor error of heat exchanger in master & slave out- door unit heat exchanger (A,B)	Abnormal value of sensor (Open/Short)	 Bad connection of air temperature connector Defect of air temperature connector(Open/Short) Defect of outdoor PCB
46* Master 461 Slave1 462 Slave2 463	Compressor suc- tion temperature sensor error	Abnormal value of sensor (Open/Short)	 Bad connection of air temperature connector Defect of air temperature connector(Open/Short) Defect of outdoor PCB
49* Master 491 Slave1 492 Slave2 493	Outdoor Unit IPM Temperature Sensor Fault	Outdoor Unit IPM Temperature Sensor Open or Short	 Bad connection of air temperature connector Defect of air temperature connector(Open/Short) Defect of outdoor PCB
153* Master 11-> 531 Slave1 12-> 532 Slave2 13-> 533	Outdoor Unit Upper Heat Exchanger Temperature Sensor Fault	Outdoor Unit Upper Heat Exchanger Temperature Sensor open or short	 Temperature Sensor Connecting Fault Temperature Sensor(Open/Short) Main PCB Fault
154* Master 11-> 541 Slave1 12-> 542 Slave2 13-> 543	Outdoor Unit Low Heat Exchanger Temperature Sensor Fault	Outdoor Unit Low Heat Exchanger Temperature Sensor open or short	 Temperature Sensor Connecting Fault Temperature Sensor(Open/Short) Main PCB Fault



Error No.	Error Type	Error Point	Main Reasons
50* Master 501 Slave1 502 Slave2 503	ODU 3phase power omis- sion error	Omitting one or more of R,S,T input power	 Input Voltage abnormal (R,S,T) Check power Line connection condition Main PCB damage Inverter PCB input current sensor fault





Copyright ©2010 LG Electronics. Inc. All right reserved. Only for training and service purposes
Error No.	Error Type	Error Point	Main Reasons
51	Over-Capacity (Sum of indoor unit capaci- ty is more than outdoor capacity)	Sum of indoor unit capaci- ty exceed outdoor unit capacity specification	 1. 130% more than outdoor unit rated capacity Wrong connection of communication cable/piping Control error of slave outdoor unit Dip switch Power supply defect of slave unit PCB Defect of outdoor unit PCB



Error No.	Error Type	Error Point	Main Reasons
52* Master 521 Slave1 522	Communication error between (Inverter PCB → Main PCB)	Main controller of Master unit of Master unit can't receive signal from inverter controller	 Power cable or communication cable is not connected Defect of outdoor Main fuse/Noise Filter Defect of outdoor Main / inverter PCB



* The method of checking MAIN PCB and inverter compressor PCB (If normal, communication LED blinks)



communication connector & LED in MAIN PCB



communication connector & LED in inverter compressor PCB



Main PCB Fuse

Error No.	Error Type	Error Point	Main Reasons
53	Communication error (Indoor unit → Main PCB)	In case Main PCB can't receive signal from indoor unit	 Communication cables are not connected Communication cables are short / open Defect of outdoor Main / indoor PCB ODU/IDU Main PCB Damage. communication Wire Connection Fault.



* 1 time/10 sec Turn on/off

In case of CH53, almost happened with CH05, the indoor units not operated actually are normal so check with same method of CH05. and additionally check as shown as below and above flow chart

- Although the quantity of indoor units installed is same as LGMV data there may be a few indoor units with which the number of communication is not increased with LGMV
- Although the quantity of indoor units installed is not same as LGMV data, and if communication of the indoor unit displayed at LGMV is done well then the indoor unit suspected to have some problem (and is not appear at LGMV) may have following problems
- ① wrong connection of communication cable or power cable
- 2 fault of power / PCB / communication cable
- 3 duplication of indoor unit number
- · If communication is not doing well wholly then the Auto Addressing is not done
- The case that CH53 appear at indoor unit also Auto Addressing is not done so indoor unit address may be duplicated
- * After replacement of indoor unit PCB, Auto Addressing should be done, if central controller is installed then the central control address also should be input.

In case that only communication PCB is replaced above process is not needed

Error No.	Error Type	Error Point	Main Reasons
54*	Wrong connection of 3Ø	Wrong connection of 3Ø	 Main PCB defect No power of R,S,T supplied Wring connection of R,S,T cables Main Pcb Fuse failure
Master 541	power supply cable	power supply cable	
Slave1 542	(Reverse direction / missing	(Reverse direction / miss-	
Slave2 543	a phase)	ing a phase)	





 Check power cable connection state, phase (R-S-T) order, power supply state in control box of product



** Check power cable connection state, phase order, power supply state in distribution panel



Error No.	Error Type	Error Point	Main Reasons
57* Master 571 Slave1 572 Slave2 573	Communication error : Main PCB > Inverter PCB	Failing to receive inverter signal at main PCB of Outdoor Unit	 Bad Connection Between Inv and Main Communication Wire Noise Effect ODU Main PCB Damage ODU Inv PCB Damage



Error No.	Error Type	Error Point	Main Reasons
59* Master 591 Slave1 592 Slave2 593	Series Installation Error	Series Installation of Slave Outdoor Unit Larger Than Master Capacity	1. Dip Switch Setting Error



Copyright ©2010 LG Electronics. Inc. All right reserved. Only for training and service purposes

Error No.	Error Type	Error Point	Main Reasons
60* Master 601 Slave1 602 Slave2 603	Inverter PCB EEP- ROM error	EEPROM Access error and Check SUM error	 EEPROM contact defect/wrong insertion Different EEPROM Version ODU inverter PCB assembly damage



* Inverter EEPROM inserting point





EEPROM enlarged picture

* Right inserting direction of inverter EEPROM



* Note : Replace after power off

Error No.	Error Type	Error Point	Main Reasons
67* Master 671 Slave1 672 Slave2 673	Fan Lock Error	Fan RPM is 10RPM or less for 5 sec. when ODU fan starts or 40 RPM or less after fan starting.	 Fan motor defect / assembly condition abnormal Wrong connection of fan motor connector (Hall sensor, U,V,W output) Reversing rotation after RPM target apply Fan PCB assembly defect Fan lock by Heavy Snowfall.



* Fan Motor resistance measuring * Hall Sensor connector between each phase





* Fan Motor Wire connection



Error No.	Error Type	Error Point	Main Reasons
69* Master 691 Slave1 692 Slave2 693	Constant 1 CT Sensor Error of Outdoor Unit	Constant 1 CT Sensor open or short of Outdoor Unit	Constant 1 CT Sensor Error
70* Master 701 Slave1 702 Slave2 703	Constant Speed Compressor 2 CT Sensor Error	Constant Speed Compressor 2 CT Sensor Open/short	1. Constant Speed Compressor 2 CT Sensor defect



Error No.	Error Type	Error Point	Main Reasons
73* Master 731 Slave1 732 Slave2 733	AC input instant over cur- rent error (Matter of soft- ware)	Inverter PCB input 3 phase power current is over 50A(peak) for 2ms	 Overload operation (Pipe clog- ging/Covering/EEV defect/Ref. overcharge) Compressor damage(Insulation damage/Motor damage) Input voltage abnormal(R,S,T) Power line assemble condition abnormal Inverter PCB assembly damage(input current sensing part)



Measuring input voltage



Compressor Wire Connection



Noise filter wiring



Noise filter input (upper part)



Noise filter output(lower part)

Inverter PCB assembly/Wiring power to inverter PCB on Noise filter



Inverter PCB assembly power connection



Noise filter power connection

Error No.	Error Type	Error Point	Main Reasons
75* Master 751 Slave1 752 Slave2 753	Fan CT sensor error	Offset of micom which senses the fan motor phase current is not 2.5V	 Input voltage is abnormal(not 15V) Fan PCB assembly defect Power wire open and connecting fault Inv PCB assembly defect



15V input power wiring conditions





Check short of power wire

Error No.	Error Type	Error Point	Main Reasons
76* Master 761 Slave1 762 Slave2 763	Fan DC Link High Voltage Error	Fan PCB DC link voltage supplied over 780V	 Input power abnormal Fan PCB assembly defect Power wire connecting fault



Error No.	Error Type	Error Point	Main Reasons
77* Master 771 Slave1 772 Slave2 773	Fan Over Current Error	Output current is over 5A for 40ms	 Overload operation Fan Motor defect Fan PCB assembly defect Fan Motor connector insert defect Condenser icing or blocking



Measuring fan motor phase resistance



Fan motor wire connection



Error No.	Error Type	Error Point	Main Reasons
79* Master 791 Slave1 792 Slave2 793	Fan Starting Failure Error	Fan Motor initial starting failure	 Fan motor defect/ assemble condition abnormal Fan motor connector misconnection(Hall sensor, U,V,W ouput) Fan PCB defect



Measuring fan motor phase resistance



Fan motor wire connection

Measuring insulation resistance between fan terminal & chassis





Error No.	Error Type	Error Point	Main Reasons
86* Master 861 Slave1 862 Slave2 863	Main PCB EEPROM Error	EEPROM Access Error	1. No EEPROM 2. EEPROM wrong insertion



EEPROM insertion direction



* Note : Replace after power off

Same direction both socket hole and EEPROM hole

Error No.	Error Type	Error Point	Main Reasons
87* Master 871 Slave1 872 Slave2 873	Fan PCB EEPROM Error	Error occurs when checking the EEPROM checksum as initializing after power is supplied	1.EEPROM bad contact/wrong insertion 2.EEPROM Version is different 3.ODU fan PCB assembly damage



Fan EEPROM insertion



Inverter EEPROM insertion direction



* Note : Replace after power off

Same direction both socket hole and EEPROM hole

Error No.	Error Type	Error Point	Main Reasons
104^* Master $11 \rightarrow 041$ Slave1 $12 \rightarrow 042$ Slave2 $13 \rightarrow 043$	Communication Error Between Outdoors	Master displays ODU number which is not communicated. Slave displays own error number	 Loose connection of power cable/ communi- cation cable (Open/Short) Defect of each outdoor unit PCB





* Slave Unit Dip SW



Error No.	Error Type	Error Point	Main Reasons
105^* Master 11 \rightarrow 051 Slave1 12 \rightarrow 052 Slave2 13 \rightarrow 053	Communication error (Fan PCB ↔ Inverter PCB)	Fan controller didn't receive signal from inverter controller	 Wrong connection between Inverter and Fan PCB Fan PCB power not supplied ODU Inv/Fan PCB defect



ℜ Note : Check fan PCB assembly Error LED blinking (Check 108⁻ Error)

Copyright ©2010 LG Electronics. Inc. All right reserved. Only for training and service purposes

Error No.	Error Type	Error Point	Main Reasons
106^{*} Master $11 \rightarrow 061$ Slave1 $12 \rightarrow 062$ Slave2 $13 \rightarrow 063$	ODU Fan PCB IPM Fault	IPM protection circuit activation (over current / overheating)	 Overload operation (Pipe clogging/Covering/EEV defect/Ref. overcharge ODU fan motor assemble condition abnormal (Coil disconnection/Short/Insulation damage) Fan PCB heatsink assemble condition abnormal Fan PCB assembly defect



Fan Motor Wire connection



Fan Heatsink assemble position



Check assemble condition

Fan IPM assemble position



Check assemble condition

Error No.	Error Type	Error Point	Main Reasons
$\begin{array}{c} 107^{*}\\ Master\\ 11 \rightarrow 071\\ Slave1\\ 12 \rightarrow 072\\ Slave2\\ 13 \rightarrow 073 \end{array}$	Fan DC Link Low Voltage Error	Fan PCB DC link voltage supplied below 380V	 Wrong wiring between inverter PCB and Fan PCB Fan PCB assembly defect Reactor terminal contact defect DC link terminal wiring/contact defect Bridge diode defect



DC Volt connected

Error No.	Error Type	Error Point	Main Reasons
113^* Master $11 \rightarrow 131$ Slave1 $12 \rightarrow 132$ Slave2 $13 \rightarrow 133$	Outdoor unit liquid pipe (condenser) temperature sensor error	Abnormal sensor resistance value (Open/Short)	 Defective temperature sensor con- nection Defective temperature sensor (Open / Short) Defective outdoor unit PCB

Error No.	Error Type	Error Point	Main Reasons
115^* Master 11 \rightarrow 151 Slave1 12 \rightarrow 152 Slave2 13 \rightarrow 153	Outdoor Unit Subcooling Outlet Temperature Sensor Error	Abnormal sensor resistance value (Open/Short)	 Defective temperature sensor con- necter connection Defective temperature sensor (Open/Short) Defective outdoor PCB



* Sensor resistance 100 k Ω over (open) or 100 Ω below (short) will generate error

Note: Temperate sensor resistance vary with temperature, So compare temperature sensor resistance value according to outdoor unit temperature by referring below table ($\pm 5\%$ tolerance) Air temperature sensor: $10^{\circ}C = 20.7k\Omega$: $25^{\circ}C = 10k\Omega$: $50^{\circ}C = 3.4k\Omega$ Pipe temperature sensor: $10^{\circ}C = 10k\Omega$: $25^{\circ}C = 5k\Omega$: $50^{\circ}C = 1.8k\Omega$

Error No.	Error Type	Error Point	Main Reasons
151* Master 11→511	Function error of outdoor 4way (reversing valve)	Function error of 4way (reversing valve) in Main or Slave outdoor units	 Wrong operation of 4way valve because of sludge etc. inflow No pressure difference because of compressor fault Wrong installation of In/outdoor common pipe Defect of 4way valve



* Measure the resistance of 4way valve



Location of 4way valve connector on Main PCB(marked as 4way,CN09)



** Confirm the 4way valve coil is inserted to the end



**** Check the output voltage of terminal socket during heating operation



- *** When power is supplied in order as follow
 - (Slave2 \rightarrow Slave1 \rightarrow Mater)
 - ODU information is displayed one after the other at main PCB 7-segment
 - 1. Model ID
 - \rightarrow 5HP:60 , 6HP:61 , 8HP:62 , 10HP:63, 12HP:64, 14HP:65
 - 2. Total Capacity
 - \rightarrow Displayed with HP
 - 3. ODU Type
 - \rightarrow HEAT PUMP : 2, Cooling : 0
 - 4. Normal mode : 25
 - 5. Refrigerant
 - → R410a : 41
- ***** Checking method for outdoor unit of 3unit system
 - (Master + Slave1 + Slave2)
 - ① Close all the SVC valves of high / low pressure common pipe
 - ② Operate system
 - ③ Check the difference of high and low pressure with LGMV for each unit (Master, Slave1, Slave2)
 - ④ If there is a unit in which the difference is not increased then the 4way valve of that unit is defective

Error No.	Error Type	Error Point	Main Reasons
173* Master 11→ 731 Slave1 12→ 732 Slave2 13→ 733	Outdoor Unit Constant Speed Compressor 1 Over Current	Outdoor Unit Constant Speed Compressor 1 Fault or Drive Fault	 Constant speed compressor 1 damage Constant speed compressor 1 input over current Discharge temperature sensor defect
174* Master 11→ 741 Slave1 12→ 742 Slave2 13→ 743	Outdoor Unit Constant Speed Compressor 2 Over Current	Outdoor Unit Constant Speed Compressor 2 Fault or Drive Fault	 Constant speed compressor 2 damage Constant speed compressor 2 input over current Discharge temperature sensor defect





* cables connection between constant compressor and magnetic switch

Error No.	Error Type	Error Point	Main Reasons
182* Master 11-> 821 Slave1 12-> 822 Slave2 13-> 823	Communication Error Between Main-Sub Micom of Master Outdoor unit Main PCB	Failure Receiving Signal Between Main-Sub Micom of Master Outdoor unit Main PCB	 Failure Receiving Signal Between Main-Sub Micom of Master Outdoor unit Main PCB



Error No.	Error Type	Error Point	Main Reasons
193* Master 11 → 931 Slave1 12 → 932 Slave2 13 → 933	Fan PCB heatsink temperature high	Heat sink temperature is over 95°C	 Heatsink temperature sensor defect Fan PCB assembly defect
194* Master 11 → 941 Slave1 12 → 942 Slave2 13 → 943	Fan PCB heatsink temperature sensor error	Heatsink temperature sensor abnormal	 Heatsink temperature sensor defect(Open/Short) Wrong connection of temperature sen- sor connector Fan PCB assembly defect



Error No.	Error Type	Error Point	Main Reasons
242	Network Error	Network error of central con- troller	 RS-485 communication wiring defect Communication defect between remote controller and indoor unit RS-485 dip switch setting error Indoor unit addressing ssetting error on central controller



<RS-485 communication wire miss connection>





P/NO : MFL54555527

AUGUST, 2011