



LG SIMs 2.0

SMART INVERTER MONITORING SYSTEM USER'S MANUAL



***Controls for
LG Air Conditioning Systems***

***Model PSWMOZ3
Single/Multi***

Proprietary Data Notice

This document, as well as all reports, illustrations, data, information, and other materials are the property of LG Electronics U.S.A., Inc., and are disclosed by LG Electronics U.S.A., Inc., only in confidence.

Do not throw away, destroy, or lose this manual.

Please read carefully and store in a safe place for future reference.

Content familiarity required for proper installation and operation.

Follow the instructions in this manual to prevent product malfunction, property damage, injury, and/or death. Incorrect operation due to ignoring any instructions may cause harm or damage. The level of seriousness is classified by the symbols described below.



WARNING

This symbol indicates that the action or lack thereof could possibly cause death, personal injury, or property damage



Note:

This symbol indicates that the action or lack thereof could possibly cause equipment malfunction or failure.



This symbol indicates that the following action should not be performed.

A summary of safety precautions is on page 4

For more technical materials such as submittals, engineering databooks, and catalogs, visit www.lghvac.com

UM_SIMS2.0_PSWMOZ3_5_15

For continual product development, LG Electronics U.S.A., Inc., reserves the right to change specifications without notice.

©LG Electronics U.S.A., Inc.

This document, as well as all reports, illustrations, data, information, and other materials are the property of LG Electronics U.S.A., Inc.

Table of Contents

Safety Precautions	4
LG SIMs 2.0 Terms and Conditions	5
LG Smart Inverter Monitoring System 2.0	6
LG SIMs 2.0 Operating Considerations	8
Safety	9
Installation Sequence	9
Install the SIMs WLAN Module	9
Install the SIMs App	11
Install the Android App	11
Install the iOS App	13
Wireless Connection	14
Android Connection	14
iOS Connection	16
Using SIMs	16
Initial Setup	17
LG SIMs Main Screen	18
Outdoor Info Tab	20
Component	20
Temperature	21
Indoor Info Tab	22
Graph Info Tab	23
IDU Temp	23
ODU Temp and Freq	24
ODU Electric	25
SIMs Troubleshooting Guide	26
Troubleshooting SIMs Operation	27
Data Guide	29
WLAN Module Specifications	29
NOTICE	30

Safety Precautions

LG Smart Inverter Monitoring System (SIMs) 2.0 is for use with LG duct-free split (DFS) systems only. Do not attempt to use SIMs 2.0 with any other type of system.

The information in this manual is intended for use by an industry-qualified, experienced, certified technician familiar with the U.S. National Electric Code (NEC) who is equipped with the proper tools and test instruments.

Failure to carefully read and follow all instructions in this manual may result in equipment malfunction, property damage, personal injury and/or death.

Input power to the outdoor unit remains connected and on during procedures in this manual. Do not touch any exposed outdoor unit wiring, terminals, or other electrical components with tools or exposed skin. Only qualified technicians should install, remove, or re-install this unit. Improper installation or use may result in fire, explosion, electric shock, physical injury and/or death.

All electrical work must be performed by a licensed electrician and conform to local building codes or, in the absence of local codes, with the National Electrical Code, and the instructions given in this manual.

If the power source capacity is inadequate or the electric work is not performed properly, it may result in fire, electric shock, physical injury and/or death.

Do not install the SIMs unit if it will be exposed to rain or other precipitation. Do not install the unit in a location exposed to open flame or extreme heat. Do not touch the unit with wet hands.

There is risk of fire, electric shock, explosion, physical injury and/or death.

Safely dispose of the packing materials.

Tear apart and throw away plastic packaging bags so that children may not play with them and risk suffocation and death.

Do not store or use flammable gas or combustibles near the unit. Do not install the unit in a location that generates oil, steam, salt, sulfuric acid, etc.

There is risk of product failure, fire, explosion, physical injury and/or death.

Replace all outdoor unit control box and panel covers.

If cover panels are not installed securely, dust, water or other foreign objects may enter the interior of a disassembled unit, causing fire, electric shock, physical injury and/or death.

Do not cut, lengthen or shorten the cable between the SIMs unit and the outdoor unit. Do not install the SIMs unit in a location where the cable cannot be safely and easily connected between the two units. Do not allow strain on this cable.

Do not spill water on the inside of the outdoor unit, especially on electrical components. Do not drop the SIMs unit into water. If the unit is immersed in water or other liquid, contact your local authorized LG distributor for support.

LG SIMs 2.0 Terms and Conditions

In using LG SIMs 2.0 hardware and smart phone application you agree to the LG SIMs 2.0 terms and conditions.

- LG SIMs 2.0 hardware and smart phone application are to be used only with LG Electronics, Inc. inverter air conditioner products.
- LG SIMs 2.0 hardware and smart phone application cannot be sold/transferred/rented to any other parties.
- All data generated by LG SIMs 2.0 hardware and smart phone application cannot be sold/transferred/rented to any other parties.
- A complete list of LG SIMs 2.0 terms and conditions is at <http://www.lg-dfs.com/sims.aspx>

LG Smart Inverter Monitoring system 2.0

This manual describes how to install and use the LG Smart Inverter Monitoring system (SIMs) 2.0, Model PSWMOZ3. SIMs consists of a hardware Wireless Local Area Network (WLAN) module, an interface cable, and a free application (app) for iOS and Android. The user must supply a smart phone, either an Apple iPhone or an Android phone. SIMs is not optimized for tablets.

Before using SIMs, you must download and install the latest version of the free SIMs app from either the App store (iOS) or the Play Store (Android). Be sure to download the WLAN version of the app. There is also a Bluetooth version (LG SIMs 1.0 [Bluetooth Only]) on the Play Store, but the Bluetooth version will not work with this WLAN SIMs module. Be sure to download LG SIMs 2.0.



Figure 1 shows the SIMs app and SIMs WLAN module in a typical DFS application. Table 1 lists SIMs smart phone requirements.

The SIMs WLAN module and the smartphone app together provide monitoring and troubleshooting capability for LG duct-free systems (DFS). SIMs functions only with LG DFS products.

Table 1: SIMs Smart Phone Requirements

	Smart Phone Supporting Specifications			Wireless Communications Effective Distance
OS	Minimum Specification	Recommended Specification	Resolution	- Effective distance: 32.8 ft (open area) - Effective distance may be reduced by the communication environment
iOS	iOS: 6.1	iOS: 6.1 / 7.0	960x640 1136x640	
Android	Android 2.3	Android 4.4	480x800 720x1280 768x1280 768x1024 1080x1920	

Due to our policy of continuous product innovation, some specifications may change without notification.




Figure 1: SIMs WLAN Module to Typical DFS System

SIMs can display and graph operational data for the air conditioner system including the indoor unit and the outdoor unit. SIMs also displays error codes and a troubleshooting guide.

To use SIMs you must be a trained HVAC service technician familiar with variable refrigerant flow (VRF) systems in general and with LG's DFS products. You should understand the inverter air conditioning operation cycle, the meaning of the data displayed by SIMs, and how to use the data to troubleshoot the system.

⚠ Note: *The DFS air conditioning system must run for at least 15–20 minutes before data collected by SIMs 2.0 is valid for troubleshooting.*

LG SIMs 2.0 Operating Considerations

- LG SIMs 2.0 processes data in real time. If other functions of the smart phone are used at the same time as SIMs, smart phone resources may be insufficient for SIMs to process data or the SIMs connection may be disconnected. Please use the product with this in mind. Always use a smart phone with at least the minimum recommended specifications.
- The SIMs application may unexpectedly end due to insufficient system resources.
- Transmission/reception data volume may increase according to the number of indoor and outdoor units. SIMs response speed may be slower for some smart phone specifications.
- Wireless transmission/reception distance may be reduced or communication may be disconnected due to the operational environment (weather, electromagnetic interference or physical obstacles).
- SIMs may not work correctly with rooted smart phones.
- As communication distance between the SIMs WLAN module and the smart phone increases, smart phone WLAN output may increase, causing greater drain on the smart phone battery. During use, keep the smart phone as close as safely possible to the SIMs WLAN module.

Safety

Safety of personnel is the primary concern during all procedures. Read and understand the safety summary at the front of this manual. Read and understand this installation procedure before beginning installation. Use the appropriate tools and accessories during installation. Plan your work and do not work alone, if possible. Know how to obtain emergency medical and firefighting assistance.

Installation Sequence

To use SIMs, you must install the app on your smart phone and you must connect the WLAN module to the outdoor unit. If you have not yet installed the app, it may be more convenient to do so before arriving at the job site. If desired, you can skip ahead to the app installation section and return to WLAN module installation when you are on-site.

Install the SIMs WLAN Module


The SIMs WLAN module must connect to the LGMV connector on the outdoor unit's circuit board. Most outdoor units have an extension cable connected to the LGMV connector. To access the extension cable you have to remove only the side handle cover. Some outdoor units may not have the extension cable. If not, you must remove the top cover of the outdoor unit and connect the SIMs cable directly to the LGMV connector on the circuit board.

WARNING

High voltages capable of causing death are used in this equipment. Outdoor unit power remains connected during this procedure. Take extreme caution not to touch electrical components or connections. Failure to observe this warning can result in death or severe injury.

Note: *Some ODUs have an LGMV extension cable accessed by removing the side handle cover. If the ODU does not have this extension cable, access the LGMV connector by removing the top cover of the ODU.*

1. Remove the outdoor unit handle cover.



2. Locate the cable labeled MVC Jig inside the outdoor unit. If this cable is not there, reinstall the handle cover and remove the top cover of the outdoor unit.



3. Locate the SIMs WLAN module and the SIMs interface cable.
4. Connect USB connector on the interface cable to USB connector on the SIMs WLAN module.
5. If the MVC Jig cable is present, connect the other end of the interface cable to the MVC Jig cable connector.
6. If the MVC Jig cable is not present, connect the other end of the interface cable to the LGMV connector on the outdoor unit circuit board.



7. Put the WLAN module in a safe location for operation. Be sure the direct path from the WLAN module to your smart phone is not blocked by any object.



8. If you have not yet installed the app, go to Install the SIMs App.
9. If you have already installed the SIMs app, go to Using SIMs.


Install the SIMs App

You must have the free SIMs app correctly installed on your smart phone before using SIMs. Follow the instructions for your smart phone, either Android or iPhone.

Install the Android App

Follow these steps to install the app on an Android smart phone.



1. Be sure your phone meets the specifications listed in “Table 1: SIMs Smart Phone Requirements” on page 6.
2. Tap the Play Store icon on the phone.




3. Type LG SIMs 2.0 in the search window and search for the app.

4. Tap the LG SIMs 2.0 icon in the search results list. Be sure to install LG SIMs 2.0. There is a Bluetooth app named

LG SIMs 1.0 that may also appear in the search results list. The Bluetooth app will not work with the SIMs WLAN module.




5. Tap the INSTALL button on the LG SIMs 2.0 screen.




6. Tap the ACCEPT button on the App permissions screen.

7. When the app is finished installing, an OPEN button is displayed on the screen.




- If you are ready to begin SIMs operation, tap OPEN and the app will start. If you will use SIMs later, you can return to the phone's Home screen.




Install the iOS App

Follow these steps to install the LG SIMs 2.0 iOS app.

- Be sure your iPhone meets the specifications listed in “Table 1: SIMs Smart Phone Requirements” on page 6.
- Tap the App Store icon on the screen.
- Type LG SIMs 2.0 in the search window and search for the app.



- Tap the LG SIMs 2.0 icon in the search results list. Be sure to select LG SIMs 2.0. There is a Bluetooth app named LG SIMs 1.0 that may also appear in the search results list. The Bluetooth app will not work with the SIMs WLAN module.
- Tap the FREE Button.
- If necessary, enter your Apple ID and password to continue.



7. Tap the **INSTALL APP** button on the LG SIMs 2.0 screen.
8. When installation is complete, an **OPEN** button is displayed on the screen.
9. If you are ready to begin SIMs operation, tap **OPEN** and the app will start. If you will use SIMs later, you can return to the phone's Home screen.



Wireless Connection


To use SIMs, the SIMs app must be installed on your smart phone and the SIMs WLAN module must be connected to the air conditioning system's outdoor unit. Follow the instructions for Android or for iPhone to connect your smart phone to the SIMs WLAN module.

WARNING


High voltages capable of causing death are used in this equipment. Outdoor unit power remains connected during this procedure. Take extreme caution not to touch electrical components or connections. Failure to observe this warning can result in death or severe injury.

Android Connection

1. Tap the LG SIMs 2.0 icon.
2. The LG SIMs 2.0 Start screen is displayed.






- 3. Tap the Start button and SIMs will begin to scan for active WiFi devices in the area. When scanning is complete, a list of devices displays. The SIMs WLAN module will have a name such as LGE_MV-XX-XX-XX, where the XX characters are alphanumeric. In some instances, the name may be all numbers.
- 4. Tap the SIMs WLAN name in the list to connect to the WLAN module. When the connection is complete, Connected displays below the name.
- 5. Press the OK button and the Main Info screen displays.



LG SIMs			
Operation Info	Installation		Mode
Operation : OFF	Save	Rem	
Capacity(IDU) : 9K	Rx	Thm	
Error Code : 00		Defrost	
Main Info	Outdoor Info	Indoor Info	Graph Info
ODU Mid Temp	23.2 °C	Freq.	0 Hz
ODU Air Temp	22.8 °C	IDU Air Temp	22.8 °C
ODU Dis. Temp	22.0 °C	IDU FAN	Low
ODU FAN	0 Rpm	Pipe Mid	22.8 °C
EEV	460 Pulse	Error	00 (count : 0)
Max Limit	[0] None	IDU 1	
File		Help	

iOS Connection

1. Tap the Settings icon on the iPhone screen.
2. The iPhone Settings screen displays. Tap the WiFi button and SIMs will begin to scan for active WiFi devices in the area. When scanning is complete, a list of devices is displayed. The SIMs WLAN module will have a name such as LGE_MV-XX-XX-XX, where the XX is alphanumeric. In some instances, the name may be all numbers.
3. Tap the SIMs WLAN name in the list to connect to the WLAN module.
4. When WiFi is connected, tap the LG SIMs 2.0 icon to start the app.
5. The LG SIMs 2.0 Start screen displays. Tap the Start button to start the app or the Setting button to perform an initial app setup.



Using SIMs

WARNING


High voltages capable of causing death are used in this equipment. Outdoor unit power remains connected during this procedure. Take extreme caution not to touch electrical components or connections. Failure to observe this warning can result in death or severe injury.

Using SIMs with an Android smart phone or an iPhone is similar. These examples use Android screens.


⚠ Note: The DFS air conditioning system must run for at least 15–20 minutes before data collected by SIMs 2.0 is valid for troubleshooting.

Initial Setup

1. Tap the Setting button on the Start Screen.



2. The Setting screen displays. You can make selections for Language (English or Korean), Temp Unit (Fahrenheit or Celsius), and Demo Mode (On or Off).




3. Set these options as desired. Demo Mode is for demonstration only and does not require a wireless connection to an ODU. Always set Demo Mode to OFF when monitoring an air conditioning system.
4. When finished making selections, tap OK.



5. The LG SIMs 2.0 main screen displays.

LG SIMs 2.0 Main Screen

The main screen is the first screen displayed after wireless connection is established. Tap the Main Info tab to display this information.



Operational Information

Item	Description
Operation	ODU operating mode: Cooling/Heating/Fan/Off
Capacity (IDU)	Capacity of the selected indoor unit
Error Code: XX	Current AC system error (if any)
Save	Not used
Rx	When lit, indicates an active wireless connection
Rem	Remote controller is on when lit
Thm	Thermo on when lit
Defrost	System in defrost mode when lit

AC Cycle Information – Main Info Tab

Item	Description
ODU Mid Temp	Outdoor heat exchanger middle pipe temperature
ODU Air Temp	Outdoor temperature
ODU Dis Temp	Outdoor unit compressor out temperature
ODU Fan	Outdoor unit fan speed in RPM
EEV	Electronic expansion valve
Max Limit	Inverter compressor frequency restriction
Freq	Outdoor unit compressor frequency
IDU Air Temp	Indoor temperature
IDU Fan	Indoor unit fan speed
Pipe Mid	Indoor heat exchanger middle pipe temperature
Error	Error code
IDU 1	IDU 1 through IDU 12. Tap to display a popup and then select the number of indoor units in the currently monitored system.


Help Menu

Item	Description
File	Not used (factory use only)
Help	Tap to display troubleshooting guide

Outdoor Info Tab

Component

Tap the Outdoor Info tab to display ODU information. The Outdoor Info tab has two sub displays, Component and Temperature. Tap the desired one to display its data.



Outdoor Info – Component

Item	Description
Frequency	Target and present inverter compressor frequency
FAN1 RPM	Target and present fan 1 speed
FAN2 RPM	Target and present fan 2 speed
DC Link	Target and present DC link voltage
Current	Input current
Voltage	Input voltage
EEV Mode	EEV operation mode
Restart Timer	Restart timer
Comp Mode	Compressor operation status
EEV	Electronic expansion valve pulse

Outdoor Info Tab

Temperature


LG SIMs		
Operation Info	Installation	Mode
Operation : OFF	Save ●	Rem ●
Capacity(IDU) : 9K	Rx ●	Thm ●
Error Code : 00		Defrost ●
Main Info	Outdoor Info	Indoor Info
Component		Graph Info
Temperature		
	Target	Present
Inv Td	32.0 °F	32.0 °F
Suction	-	
Discharge	72.0 °F	
Cond Mid	72.0 °F	
Cond Out	-	
Heatsink	73.0 °F	
Air Temp	71.0 °F	
File		Help

Outdoor Info – Temperature

Item	Description
Inv TD	Target and present out temperature
Suction	Compressor in temperature
Discharge	Compressor out temperature
Cond Mid	Heat exchanger pipe middle temperature
Cond Out	Heat exchanger pipe outlet temperature
Heatsink	Heat sink temperature
Air Temp	Outdoor temperature

Indoor Info Tab

Tap the Indoor Info tab to display IDU information.
Click the number row to the left to display any additional IDU numbers.



Indoor Info


Item	Description
Capacity	Indoor unit capacity
Operation	Indoor unit operating mode (cooling/heating)
THM Mode	Thermo on/off
REM Mode	Remote controller on/off
FAN	Fan speed in RPM
EEV	Electronic expansion valve
Air Temp	Indoor temperature
Pipe-in	Heat exchanger pipe inlet temperature
Pipe-mid	Heat exchanger pipe middle temperature
Pipe-out	Heat exchanger pipe outlet temperature

Graph Info Tab

IDU Temp

Tap the Graph Info tab and then tap the IDU tab to display IDU information in graph format. You can “pinch” the screen in and out to change the time scale to display data for a longer or shorter data collection period.

Allow SIMs to run for 30 to 60 minutes to acquire enough data to show system operating trends.



Graph Info – IDU Temperature

Item	Description
Room Temp	Indoor temperature
Pipe Mid Temp	Heat exchanger pipe middle temperature
Pipe In Temp	Heat exchanger pipe in temperature
Pipe Out Temp	Heat exchanger pipe out temperature


Graph Info Tab

ODU Temp and Freq

Tap the Graph Info tab and then tap the ODU tab to display ODU information in graph format. Tap the Temp → Elec / Elec → Temp tab to switch between ODU temperature and electric data.

You can “pinch” the screen in and out to change the time scale to display data for a longer or shorter data collection period.

Allow SIMs to run for 30 to 60 minutes to acquire enough data to show system operating trends.



Graph Info – ODU Temperature and Frequency

Item	Description
Discharge Temp	Compressor out temperature
Pipe Mid Temp	Pipe middle temperature
Out Air Temp	Outdoor air temperature
Suction Temp	Compressor in temperature
Pipe Out Temp	Pipe outlet temperature
Frequency	Compressor frequency


Graph Info Tab

ODU Electric

Tap the Graph Info tab and then tap the ODU tab to display ODU information in graph format. Tap the Temp → Elec / Elec → Temp tab to switch between ODU temperature and electric data.

You can “pinch” the screen in and out to change the time scale to display data for a longer or shorter data collection period.

Allow SIMs to run for 30 to 60 minutes to acquire enough data to show system operating trends.




Graph Info – ODU Electric

Item	Description
Current	Outdoor unit current
Voltage	Outdoor unit voltage

SIMs Troubleshooting Guide


The SIMs app contains a troubleshooting guide (TSG) for the air conditioning system. You can display the TSG by tapping the Help button at the bottom of the screen. If SIMs is displaying an error code, you can tap the error code display and the TSG will open to the TSG page that pertains to that error.




Troubleshooting SIMs Operation

Follow these troubleshooting procedures if the SIMs app does not function as expected.


Smart Phone will not Connect to WLAN Module



Connection Between Smart Phone and WLAN Module Drops Out



A Portion of Smart Phone Screen is too Wide or not Displayed



Data Guide

Open Source

If you would like to get the source code of GPL, LGPL, MPL, and others which are developed with open source license and installed in this product, please visit <http://opensource.lge.com>.

In addition to the source code, indications of all applicable license contents, copyright, and no responsibility on warranty can be downloaded.

If you request the open source code of the software that is installed on this product by sending email to opensource@lge.com within 3 years of purchasing this product, we will provide it in CD-ROM with a minimum cost of shipping and handling.

WLAN Module Specifications

Standard	IEEE 802.11 b/g/n
Frequency Range	2.412 – 2.462 GHz
Security	128 bits WEP, AES WPA, WPA2
Output Power	802.11b: 11 dBm (11 Mbps) 802.11g: 15 dBm (54 Mbps) 802.11n : 11 dBm (72.2 Mbps)
Data Rate	802.11b: 11 Mbps 802.11g: 54 Mbps 802.11n: 72.2 Mbps
Sensitivity	802.11b: -88 dBm (11 Mbps) 802.11g: -74 dBm (54 Mbps) 802.11n: -69 dBm (72.2 Mbps)
Modulation	QPSK + OFDM
Class of Emission	G1D, D2D
Number of Channels	11
Oscillator/Communication mode	Crystal/Half-duplex

⚠ Note: *This device is not available for laptop computers or similar portable systems.*

NOTICE

FCC (Certification)

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation

FCC WARNING: This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

U.S. Regulatory Wireless Notice

This product emits radio frequency energy, but the radiated output power of this device is far below the FCC radio frequency exposure limits. Nevertheless, the device should be used in such a manner that the potential for human contact with the antenna during normal operation is minimized.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 8 in (20 cm) between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Federal Communications Commission (FCC) Statement

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

End Product Labeling

The modular transmitter must be labeled with its own FCC ID number, and, if the FCC ID is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module. This exterior label can use wording such as the following: "Contains Transmitter Module FCC ID: BEJPCRCUDT2" or "Contains FCC ID: BEJPCRCUDT2." Any similar wording that expresses the same meaning may be used. The Grantee may either provide such a label, an example of which must be included in the application for equipment authorization, or, must provide adequate instructions along with the module which explain this requirement. In the latter case, a copy of these instructions must be included in the application for equipment authorization.

IC (Certification)

This device complies with RSS-210 of the Industry Canada Rules.

Operation is subject to the following two conditions:

1. This device may not cause Interference and
2. This device must accept any interference, including interference that may cause undesired operation of the device

IC Warning

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including Interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage, et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

IC Radiation Exposure Statement

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

